

For technology  
in Quality




# User Manual

## Windows CE 6.00 BSP for the TQMa35 module

### BSPa35-WinCE.UM.201

29.07.2011

	<b>Date:</b>	<b>Name:</b>	<b>Designation:</b>	
<b>Prepared:</b>	10.03.2011	H. Boerner	<b>Project:</b>	BSPa35-WinCE
<b>Checked:</b>	29.03.2011 29.05.2011	I. Loschelders M. Fischer	<b>Document no.:</b>	BSPa35-WinCE.UM.201
<b>Company:</b>			<b>Release status:</b>	Reviewed
			<b>Customer:</b>	TQC
				Page 1 of 58
<b>File:</b>	BSPa35-WinCE.UM.201.doc			
(C) TQ-Components GmbH. All information contained in these documents has to be treated confidentially. Distribution of presentation and information to third party requires written consent of TQ- Components GmbH.				

## **Table of Contents**

1	About This Manual .....	5
1.1	Terms and Conventions .....	5
1.2	Acronyms and Definitions .....	6
1.3	Liability Disclaimer .....	7
1.4	Copyright and Licensing Costs .....	7
1.5	Registered Trademarks .....	7
2	Introduction .....	7
3	Contents of the CD .....	8
4	Installation .....	9
4.1	Installation of the Platform Builder Updates .....	9
4.1.1	Which Updates are already installed .....	9
4.1.2	How to install missing updates .....	9
4.2	Installation of the BSP .....	10
4.3	Installation of the Demo Workspaces .....	10
4.3.1	Contents of the TQMa35 _SampleWorkspace .....	10
4.4	Removal of a Demo wWrkspaces .....	10
5	Creating a New OS Design Based on the TQMa35 BSP .....	11
5.1	Creating a New Workspace .....	11
5.2	How to Add Drivers and OS Components .....	15
5.3	OS Design Configuration .....	16
5.3.1	Debug Port Configuration .....	16
5.3.2	Touch Calibration .....	16
5.3.3	Build Options .....	17
5.3.4	Language Settings .....	17
5.3.5	Environment Variables .....	18
5.4	Building the OS Design .....	20
5.5	Downloading the Run Time Image via Ethernet .....	20
5.5.1	Connect the target .....	21
5.5.2	Configuring Ethernet Connection for Downloading and Debugging .....	22
5.5.3	Building and Downloading a Run Time Image into SDRAM Using EBOOT .....	24
5.5.4	Build and Downloading a Run Time Image into NOR Flash Using EBOOT .....	25
5.5.5	Running a Run Time Image from NOR Flash Using EBOOT .....	25
5.5.6	Debugging the download connection .....	26
6	EBOOT Boot Loader .....	27
6.1	Configuration Options of the EBOOT Boot Loader .....	27
6.2	Updating the EBOOT boot loader .....	30

## **Table of Contents**

7	Device Drivers .....	31
7.1	USB .....	31
7.1.1	USB OTG Drivers .....	31
7.1.1.1	Adding the USB OTG Drivers .....	31
7.1.1.2	USB OTG Drivers Configuration .....	31
7.1.2	USB Mouse and Keyboard Support .....	32
7.1.3	USB Printer Support .....	32
7.2	SD Host Controller .....	32
7.2.1	Adding the SD Host Controller Driver to Your OS Design .....	32
7.2.2	SD Host Controller Driver Configuration .....	32
7.3	Audio .....	32
7.3.1	Adding the Audio Driver to Your OS Design .....	32
7.3.2	SGTL5000 .....	32
7.3.3	Buzzer .....	33
7.4	LM75 Temperature Sensor .....	33
7.4.1	Adding the Temperature Sensor Driver to Your OS Design .....	33
7.4.2	How to Use the Temperature Sensor Driver .....	34
7.5	Serial Ports (UARTs) .....	35
7.5.1	Adding Serial Drivers to Your OS Design .....	35
7.5.2	Serial Driver Configuration .....	35
7.6	Touch Panel Support .....	36
7.6.1	Adding the Touch Panel Driver .....	36
7.6.2	Touch Panel Driver Configuration .....	36
7.7	I2C Bus Driver .....	36
7.7.1	Adding the I2C Bus Driver .....	36
7.7.2	I2C Bus Driver Configuration .....	36
7.8	GPT driver .....	36
7.8.1	Adding the GPT Driver .....	36
7.8.2	GPT Driver Configuration .....	36
7.9	Smart Backlight Control .....	37
7.9.1	Adding Smart Backlight Control .....	37
7.9.2	IPU Backlight Driver Configuration .....	37
7.10	RTC .....	37
7.10.1	Adding the RTC driver .....	37
7.10.2	RTC driver configuration .....	38
7.11	GPIO .....	38
7.11.1	Adding the GPIO driver .....	38
7.11.2	GPIO driver default configuration .....	38
7.11.3	How to use the GPIO driver .....	39
7.12	CAN Driver .....	39
7.12.1	Adding the MCP2515 CAN Driver to Your OS Design .....	39
7.12.2	Freescale CAN Driver Configuration and Usage .....	39
7.13	EEPROM Driver .....	40
7.13.1	Adding the EE Driver to Your OS Design .....	40
7.13.2	EEPROM Driver Configuration and Usage .....	40
7.14	SPI Bus Driver .....	41
7.14.1	Adding the SPI Bus Driver .....	41
7.14.2	CSPI Bus Driver Configuration .....	41

## **Table of Contents**


8	Developing Applications.....	41
8.1	Creating an SDK from Your OS Design.....	41
8.2	Developing with Visual Studio 2005 .....	42
8.2.1	Installation .....	42
8.2.2	Generate a Simple Project.....	43
8.2.3	Establish a Connection between VS 2005 and the CE Device.....	45
8.2.3.1	Startup over Active Sync / Transport over Ethernet .....	45
8.3	Application Deployment.....	49
8.3.1	Adding Applications and Files to Your OS Design .....	49
8.3.2	Auto Start-up of Windows CE applications .....	50
8.4	ActiveSync .....	52
8.4.1	Required Components.....	52
8.4.2	Establish a Active Sync Connection Over Serial Port .....	53
8.4.3	Establish a ActiveSync Connection over USB .....	54
9	Additional Customizations.....	55
9.1	Windows CE Components .....	55
9.1.1	Telnet Server.....	55
9.1.2	FTP Server.....	56
9.2	Changing of the Appearance of Windows CE.....	57
9.2.1	Changing the Desktop Wallpaper .....	57
9.2.2	Hiding the Taskbar .....	57
9.2.3	Changing the Folder Name of Storage Devices.....	57
9.2.4	Setting up the Time Zone to GMT.....	58

## Revision History

Rev.	Date	Name	Pos.	Modification
0.01	01.03.2011	Boerner		Initial draft

# 1 About This Manual

## 1.1 Terms and Conventions

Symbol/Tag	Description
 <b>Warning</b>	This symbol represents important details or aspects for working with the BSP.
<b>Note</b>	Helpful information for working with the BSP.
<b>Filename.ext</b>	This specification is used to state the complete file name with its corresponding extension.
<b>Instructions / Examples</b>	Examples of applications. E.g. <ul style="list-style-type: none"> <li>• Specifying memory partitions</li> <li>• Processing a script</li> </ul>
<b>Reference</b>	Cross-reference to another section, figure or table.

## 1.2 Acronyms and Definitions

The following terminology and abbreviations are used:

Acronym	Full Form
<b>BSP</b>	Board Support Package
<b>IDE</b>	Integrated Development Environment
<b>OS</b>	Operating System
<b>SDB</b>	Software Development Board
<b>HW</b>	Hardware
<b>OAL</b>	OEM Adaptation Layer
<b>OEM</b>	Original Equipment Manufacturer
<b>SDK</b>	Software Development Kit
<b>COM</b>	Communication Ports
<b>IRQ</b>	Interrupt Request

### **1.3 Liability Disclaimer**

The TQ-Components GmbH does not accept guarantee of any kind about the topics, accuracy, completeness or quality of information made available in this manual as well as its further use. Claims lodged against TQ-Components GmbH, related to damages of material or intellectual nature, arising out of the use or non-use of information contained in this manual, or out of the use of incorrect or incomplete information, would not be entertained so long as there is no evidence of intentional or negligent fault on the part of TQ-Components GmbH.

The TQ-Components GmbH reserves the right to change or supplement the contents of this manual, or parts of it, without prior indication to this effect.

### **1.4 Copyright and Licensing Costs**

The drivers and utilities that are used for the components as well as the boot loader are subject to the copyright of the respective manufacturer. Licensing conditions of the respective manufacturer should be observed.

Licensing costs for the operating system and applications are not included and must be calculated and stated separately.

There are no further licensing costs for general drivers or similar items.

#### **Remarks:**

Since we are dealing with an embedded system, no operating system licenses from OEM or office/consumer sphere need to be installed.

### **1.5 Registered Trademarks**

TQ strives to respect the copyrights of graphics used in other publications and texts, by using graphics created by themselves or accessing license-free graphics and text.

All brand names and trademarks used in this publication are under circumstance protected by third parties, without restriction, subject to conditions of the respective valid trademark law and ownership law of the respective owner or proprietor. Conclusions cannot be drawn on the basis of their mere mention that brand names and trademarks are not protected by third-party rights.

## **2 Introduction**

The TQM Board Support Package for Windows CE 6.0 contains all necessary software components to allow a simple and fast startup of application development with Windows CE 6.0 on your TQMa35 hardware platform.

A PC with minimum Windows XP and Microsoft Visual Studio with platform builder plug-in is necessary.

The TQMa35 BSP was created with all updates installed including the Rollup 2010 update. Please assure that your Platform Builder installation has all these updates installed.

### 3 Contents of the CD

```
\---CD
|
|   Stand.txt
|
+---DemoImage
|   +---128MByte
|   |       NK.bin
|   |
|   \---256MByte
|       NK.bin
|
+---DemoProject
|   tqs_src_proj.zip
|
+---eBoot
|   +---128MByte
|   |       EBOOT.bin
|   |
|   \---256MByte
|       EBOOT.bin
|
+---SDK
|   tqs_sdk.msi
|
```

## 4 Installation

The following chapters will guide you through the installation of the TQMa35 BSP for Windows CE 6.0. We assume that you have already installed the Microsoft Visual Studio with Platform Builder plug-in from the original Microsoft DVD or CD. If not please install it before proceeding to the next paragraph. The installation drive should be "C:!" No newer BSP should be installed!

### 4.1 Installation of the Platform Builder Updates

Microsoft delivers updates to the Platform Builder monthly. The TQM BSP was created with all updates installed including the Rollup 2010 Update. Please assure that your Platform Builder installation has all these Updates installed.

#### 4.1.1 Which Updates are already installed

You can check for installed updates by looking in the Platform Builder update folder (C:\WINCE600\Updates). For each installed update there should be file in HTML and Rich Text format with detailed information about the update.




Figure 1: Rollup updates

#### 4.1.2 How to install missing updates

All updates released by Microsoft until December 2010 may found on the [Microsoft Download center page](#). Please search for "Windows Embedded CE 6.0 Cumulative Product Update Rollup Package (through 12/31/2010)" and install them.

## 4.2 Installation of the BSP

The BSP consists of 2 parts. One is the original BSP of Freescale found on “Free Scale BSP” on the CD that includes the common part of the i.MX35 and should be installed first. The second is the TQS specific BSP, which is stored as “\SourceBSP” on the CD. This archive has to expand under the “c:\wince600\platform” directory.

During the installation the BSP the Visual Studio should be closed.

## 4.3 Installation of the Demo Workspaces

The demo workspaces for the TQMa35 BSP are included on the CD as “\DemoProject”. The workspaces are a good starting point for a new OS design. They include all special drivers, the platform options and so on.

The workspaces are located as an archive on the CD in the directory “\DemoProject”.

- Expand the archive to “c:\wince600\OSDesigns\”
- Browse to the “c:\wince600\TQS” folder and open the TQS.sn1 as a Project in the Visual Studio.

### 4.3.1 Contents of the TQMa35 SampleWorkspace

The demo workspace “TQS” is based on the „Industrial Controller“design. For detailed information about the included components please have a look into the project file in the folder \OsDesign\tqs\tqs\TQS.pbxml.

## 4.4 Removal of a Demo wWrkspaces

Close the Visual Studio.

Delete the appropriate demo workspace directory from the OSDesign directory of your Platform Builder installation (e.g. c:\wince600\osdesignTQS).

## 5 Creating a New OS Design Based on the TQMa35 BSP

The following steps will guide you through the whole process of creating, compiling and testing of a new Windows CE workspace for the TQMa35 hardware module based on the industrial controller design template.

### 5.1 Creating a New Workspace

Open Visual Studio and select *Project...* from the *File* menu. Choose the project type *Platform Builder 6.0* and choose name for the workspace.




Figure 2: Creating a new platform Step 2

The next dialog you should skip and then you can specify one or more BSPs on which your OS design should be based.




Figure 3: Creating a new platform Step 3

Please choose the FreeScale i.MX35 TQS BSP as base for your new OS design.

The next step is to choose a predefined design template of the OS design being created. You should select the configuration, which has the best conformity to the OS design you need.




Figure 4: Creating a new platform Step 4 & 5

We chose the *Industrial Device* and *Industrial Controller* as a base configuration for our OS design, as this configuration includes already TCP/IP networking, GUI support and most of the programming APIs.

With the following steps various components such as applications can be added to the OS design. You will be able to modify this configuration later on, however it will be more detailed and you will have to deal with dependencies of the modules. The figures below show a configuration example:




Figure 5: Creating a new platform Step 6

We deselect the *.NET Compact Framework* component and include the *Console Window*, the *Network User Interface* and the *Waveform Audio*.

On the next tab we add the FTP and Telnet server components.




Figure 6: Creating a new platform Step 7

When you click *Next*, a security warning about the FTP and Telnet servers will appear as these components allow network access to our device. FTP and Telnet security settings are discussed later on.




Figure 7: Appearance of Visual Studio after generating a new platform

Now you have a basic OS design configuration, which is ready for building and creating a run-time image, but still lacks the OS design specific hardware drivers.

## 5.2 How to Add Drivers and OS Components

Drivers can be added to your OS design by selecting the component in the Platform Builder's Catalog Item View.




Figure 8: Adding drivers and OS components

The selected component will now be shown as active in your OS Design View, otherwise with a right click and *Reasons for Exclusion of Item* will show the background of the deselection. Often components under *Core Os\CEBASE* are missed (i.e. for the USB device).

To remove a driver or component from your OS Design deselect the component.

### 5.3 OS Design Configuration

After we added all desired components and drivers, we have to do some configuration settings before we can build our OS design.

#### 5.3.1 Debug Port Configuration

The item *Debug enable* includes a control panel applet to enable or disable the debug functionality. On default the debug port is enabled!




Figure 9: Debug configuration

#### 5.3.2 Touch Calibration

To avoid the touch calibration mechanism on every start the *CalTouch Autostart ONCE* can be used to reduce the calibration uniquely.

Hint: after calibration the tool *flushreg* should be used to make the calibration data persistent.




Figure 10: Touch calibration configuration

### 5.3.3 Build Options

To set the build options for your OS design, open the *...Properties* dialog from the *Project* menu in Visual Studio and go to the *Build Options* tab.

The most important options are described in table 1. There is also a recommendation given for setting the build options for the *Debug* and *Release* configuration of your OS design.

Option	Description	Build configuration	
		Debug	Release
<b>Enable eBoot Space in Memory</b>	Should be checked if you use the eBoot boot loader (normally used for downloading the Image from the Visual Studio)	X	X
<b>Write run-time image to flash memory</b>	Select between RAM and Flash image. An image on SD-Card should be a RAM-Image.	(X)	X
<b>Enable Kernel Debugger</b>	Allows connecting the kernel debugger of Visual Studio with the target.	X	
<b>Enable KITL</b>	Enables the Kernel Independent Transport Layer (KITL). Needed for communication between the development workstation and the target device.	X	(X)

Table 5-1: build options

In *Release Builds* the KITL should always be turned off as it will slow down your platform performance!

### 5.3.4 Language Settings

To set the default language of your OS design open the *... Properties* dialog from the *Platform* menu in Visual Studio and go to the *Locale* tab.

Here you can set the locales that your OS design will support. The locales include information about currency formats, date and time formats, etc. specific to each country.




Figure 11: Locale settings

The default language specifies the language of the Windows CE user interface (buttons, menus, windows, etc.).

To set the default keyboard layout, which is independent from the default language, please refer to chapter *Setting the Default Keyboard Layout*.

### 5.3.5 Environment Variables

The build process of an OS design is controlled by environment variables. In the tab *Build* in *Open Release Directory in Build Window* you can set additional environment variables for your workspace.

To check which environment variables are set, open the release directory (*Build -> Open Release Directory in Build Window*):




Figure 12: Open Release Directory

Use the `set` command to get a list of currently set environment variables for your OS design:

```

TQS - Freescale i_MX35 TDS ARMV4I Release
PROJECTROOT=C:\Projekte\TQS\TQS\WinCE600\iMX35-TQS_ARMV4I
PROJECTSDKROOT=C:\Projekte\TQS\TQS\WinCE600\iMX35-TQS_ARMV4I\sdk
PROJPUBLICROOT=C:\Projekte\TQS\TQS\WINCE600\PUBLIC
PUBLICDRIVE=C:
PUBLICROOT=C:\WINCE600\public
SDKDRIVE=C:
SDKROOT=C:\WINCE600\sdk
TARGETPLATROOT=C:\WINCE600\platform\iMX35-TQS
TGT CPU=ARMV4I
TGT CPUFAMILY=ARM
TGT CPUISA=V4I
TGT HWREV=2
TGT OS=CE
TGT PLAT=iMX35-TQS
TGT PROJ=TQS
TOOLSSDKDRIVE=C:
TOOLSSDKROOT=C:\WINCE600\tools\public\ext
USER_SYSGEN_BAT_FILES=C:\Projekte\TQS\TQS\WinCE600\iMX35-TQS_ARMV4I\OAK\MISC\TQ
S.bat
WINCECALLED=1
WINCEDRIVE=C:
WINCEOSVER=600
WINCEROOT=C:\WINCE600
C:\Projekte\TQS\TQS\ReIDir\Freescale_i_MX35_TDS_ARMV4I_Release>

```

Figure 13: Viewing environment variables

Example:

If you want to set the *environment variable* `BSP_ASYNC_FILES` to include additional active sync components, please type:

*Set* `BSP_ASYNC_FILES=1`

*To delete the variable, just type:*

*Set* `BSP_ASYNC_FILES=`

or `IMGRAM256` to enable the second 128 Mbyte of RAM.

*All changes are only in the current command active!*

*Alternatively you can add the environment variable in the Environment tab of the Platform Settings dialog.*

## 5.4 Building the OS Design

To build your OS design, first choose the desired build configuration (Debug or Release) from the pull-down menu in the Visual Studio IDE.




Figure 14: Selecting the active configuration

Second start the system generation: click the choose *Sysgen* from the *Build* menu.

The build process can take more than 5 minutes to build the run-time image, depending on the number of included components, and the host CPU.

After a successful build, the Windows CE run-time image (a file called NK.BIN respectively NK.nb0) can be found in the release directory, i.e. for the sample workspace *TQS* and the release configuration would be:


```
$(_WINCEROOT)\OSDesign\TQS\TQS\ReIDir\Freescale_i_MX35_TDS_ARMV4I_Debug\NK.BIN
```

## 5.5 Downloading the Run Time Image via Ethernet

The Ethernet boot loader (EBOOT) is used to download and execute OS images. EBOOT is typically written into NOR flash memory on the TQMa35 module and executes immediately out of reset. Initially, the target hardware will have EBOOT resident in the NOR flash memory. In addition, the target hardware has non-volatile storage for the EBOOT network configuration (DHCP/static, MAC address, etc.) that must be initialized before using the boot loader with Visual Studio. This section will describe the procedure for updating, and configuring EBOOT on the target hardware.

### 5.5.1 Connect the target

To connect the target at a minimum following connections should exist.



*Figure 15: Connect a target*

Please examine whether after switching on the Network LED turns on.

### 5.5.2 Configuring Ethernet Connection for Downloading and Debugging

To configure an Ethernet connection that can be used for downloading and debugging images, follow these steps:

1. From the Visual Studio *Target* menu select *Connectivity Options...*  
Then select *Add Device* and choose a name for your target device. In our example we choose TDS as target device name.




Figure 16: Add a new target device name

After you clicked *Add* the *Kernel Service Map* tab will be opened automatically:




Figure 17: Target download settings

Make sure that *Ethernet* is selected for both *Download* and *Transport*. Click the *Settings* button of the *Download* option. A new dialog will appear where you can choose the device to connect to. At the moment the *Active Devices* list will be empty. Now start your TQMa35 module. When the Startup menu appears just press *Space* and '*D*' to choose the download option.

EBOOT sends a broadcast message to the Visual Studio and your device will show up in the *Active Devices* list as MX35XXXXX (where XXXXX is a number depending on your network card's MAC address). If your device does not show up in the list of active devices, precede to chapter *Debugging the download connection* and *Configuration Options of the EBOOT* . It is possible that the option *auto boot* is not set to *Disabled*.

Select the device and click *OK*. Now your device is selected for both *Downloading* and *Debugging*.




Figure 18: Selecting an active target device

Click *Apply* and then close the dialog.

Now you can select *Attach* from the *Target* menu in the Visual Studio IDE. A new dialog will appear and the download of the run-time image will start. If not then reboot the TQMa35 module and wait for the download to begin.




Figure 19: Downloading the Runtime Image

After the download is finished Windows CE should start up on your target device. For subsequent downloads just select again *Attach* from the *Target* menu (you don't need to configure the remote connection again unless you change targets).

### 5.5.3 **Building and Downloading a Run Time Image into SDRAM Using EBOOT**

To build and download a run-time image into the SDRAM of the target, follow these steps:

1. Open the desired workspace within Visual Studio.
2. Deselect **Project** → ... **Properties** → **Configuration Properties** → **Build Options** → **Write Run-time Image to Flash Memory**.
3. Build the run-time image following the steps provided in Building the OS Design.
4. Reset the TQMa35 module to launch EBOOT on the target.
5. If a target device connection has not been created within Visual Studio, follow the steps in Configuring Ethernet Connection to establish a connection.
6. From the Visual Studio *Target* menu, select *Attach Device* to begin the download.

#### 5.5.4 Build and Downloading a Run Time Image into NOR Flash Using EBOOT

To download a run-time image into the NOR Flash of the target, follow these steps:

1. Open the desired workspace within Visual Studio.
7. Select **Deselect Project** → ... **Properties** → **Configuration Properties** → **Build Options** → **Write Run-time Image to Flash Memory**.
2. Build the run-time image following the steps provided in Chapter *Building the OS Design*.
3. Reset the TQMa31 module to launch EBOOT on the target.
4. If a target device connection has not been created within Visual Studio, follow the steps in *Configuring Ethernet Connection for Downloading and Debugging* to establish a connection.
5. From the Visual Studio *Target* menu, select *Attach Device* to begin the download.
6. After the download is complete, switch over to your terminal emulation application. At this point EBOOT has downloaded the image (**NK.nb0**) temporarily into SDRAM and is ready to begin the flash programming procedure.
7. In the terminal emulation application, hit the 'y' key to begin programming the flash.
 

```
INFO: Downloading NK NOR image.
WARNING: Flash update requested.
Do you want to continue (y/n)?
```



#### **Warning:**

**DO NOT SWITCH OFF THE POWER SUPPLY DURING FLASH UPDATE!**

8. EBOOT will program the image into flash and provide status using serial debug messages. Once the programming is complete, you will see the following messages:
 

```
INFO: Flashing sequence complete.
Reboot the device manually...
Spin Forever...
```
9. To boot the programmed image automatically follow the Instructions given in Chapter *Running an OS Image from NOR Flash using EBOOT*.

#### 5.5.5 Running a Run Time Image from NOR Flash Using EBOOT

To execute an OS image from NOR flash that has been previously programmed using the procedure described in *Downloading an OS Image into NOR Flash using EBOOT*, follow these steps.

1. Reset the TQMa35 module to launch EBOOT on the target.
2. Quickly switch over to your terminal emulation application and wait for the debug message "Press [ENTER] to download now or [SPACE] to cancel." to appear.
3. Hit the space bar to bring up the EBOOT configuration menu.
4. Continue selecting the *auto boot* option of the EBOOT menu until "NK from NOR" is selected.
5. Specify the desired boot delay using the *Boot Delay* menu option.
6. Save the configuration using the EBOOT menu.
7. Reset the TQMa35 module to launch EBOOT again. EBOOT will automatically jump to the run-time image in NOR flash after the specified boot delay.

## 5.5.6 Debugging the download connection

If you have problems with connecting your device through Visual Studio, you can observe through a serial connection if the initiation of the network card by the boot loader works well. In order to do so, connect the UART1 port of your TQMa35 module with a serial port of your host computer by means of a null modem cable. Use the program `C:\WINCE600\PUBLIC\COMMON\OAK\BIN\386\ceterm.exe`, or *HyperTerminal* to open a connection at 115200/8/N/1.

```

INFO:OALLogSetZones: dpCurSettings.ulZoneMask: 0xb
OEM Init Done

Microsoft Windows CE Bootloader Common Library Version 1.4 Built Mar 17 2011 12:16:46
Microsoft Windows CE Ethernet Bootloader 1.0 for MX35 3DS (Mar 17 2011 12:37:16)
INFO: Bootloader launched from NOR
OALBspArgsInit: *** configFlags = 0x00000009 ***
BSP System Configuration:
  L2 CACHE ENABLED
  MCU PLL = 532000000 Hz
  PER PLL = 300000000 Hz
  ARM CLOCK = 532000000 Hz
  AHB CLOCK = 133000000 Hz
  IPU CLOCK = ~133000000 Hz
  MLB CLOCK = 266000000 Hz
  IPG CLOCK = 66500000 Hz
  PER CLOCK = 66500000 Hz
  SSI1 CLOCK = 100000000 Hz
  SSI2 CLOCK = 100000000 Hz
  CSI CLOCK = 100000000 Hz
  ESDHC1 CLOCK = 100000000 Hz
  ESDHC2 CLOCK = 100000000 Hz
  ESDHC3 CLOCK = 100000000 Hz
  SPDIF CLOCK = 100000000 Hz
  USB CLOCK = 60000000 Hz
  UART CLOCK = 100000000 Hz
  NFC CLOCK = 22166666 Hz
no sd-card present !
WARNING: OEMPlatformInit: Failed to initialize SDHC device.
INFO: Reading boot configuration in NOR flash (addr = 0xB1FE0000, size = 0x5C)
System ready!
Preparing for download...

Press [ENTER] to launch image stored in NOR flash or [SPACE] to cancel.

Initiating image launch in 3 seconds. ██████████2 seconds. ██████████1 seconds. ██████████0
seconds.
Launching flash image ...

```

## 6 EBOOT Boot Loader

### 6.1 Configuration Options of the EBOOT Boot Loader

First you have to configure one COM port of your development computer with following parameters (115200/8/N/1) as shown:




Figure 20: COM port configuration for EBOOT boot loader

After that, when the device is powered up and you have connected UART1 port of your TQMa35 module with a serial port of your development computer by means of a null modem cable, you can enter the configuration menu by hitting the *SPACE* key in your terminal program when you see the following message:

Press [ENTER] to download now or [SPACE] to cancel.

Hitting *SPACE* will bring up the boot loader configuration menu:

```
-----  
Freescale iMX SOC Menu Item  
-----
```

```
[0] IP Address : 0.0.0.0  
[1] Set IP Mask : 0.0.0.0  
[2] Boot Delay : 3  
[3] DHCP : Enabled  
[4] Reset to Factory Default Configuration  
[5] Select Boot Device : NK from NOR  
[6] Set MAC Address FEC : 0-13-45-12-33-12  
[7] Set MAC Address SMSC : 4-3-2-1-30-82  
[9] Bootloader Shell  
[I] KITL Work Mode : Interrupt  
[K] KITL Enable Mode : Disable  
[P] KITL Passive Mode : Disable  
[S] Save Settings  
[D] Download Image Now  
[L] Launch Existing Flash Resident Image Now  
[E] Select Ether Device : FEC  
[M] MMC and SD Utilities  
[G] L2CC Active Mode : Enable  
[W] L2CC Work Mode : WriteBack
```

Selection:

If no output is shown on your terminal, please check the serial cable (crossed ??) and the power supply.

Here you can modify settings described in table 2.

<b>Option</b>	<b>Description</b>
<b>IP Address</b>	Select IP address for the boot loader (Not used if DHCP is enabled).
<b>Subnet Mask</b>	Select subnet mask for the boot loader (Not used if DHCP is enabled).
<b>Boot delay</b>	Delay in seconds that the boot loader waits for the SPACE key to enter in the configuration menu before the option selected in "Auto boot" is executed.
<b>DHCP</b>	Enable/disable DHCP for the boot loader
<b>Reset to Factory Default Configuration</b>	Reset all setting to the factory defaults.
<b>Auto boot</b>	Select the boot option for normal startup (if not entered boot configuration). You can choose: NK from NOR                      Load run-time image from NOR flash NK from SD/MMC                Load run-time image from SDCard. Disabled                            Bootloader will try to download image
<b>Set MAC Address FEC</b>	Select the MAC address for i.MX35 network interface. (Upper slot of the network connector)
<b>Set MAC Address SMSC</b>	Select the MAC address for the onboard SMSC network interface. (Lower slot of the network connector)
<b>Bootloader Shell</b>	Some helper functions to modify similar memory addresses.
<b>KITL Work Mode</b>	If KITL is active the network adapter may be used as a polled or interrupt interface.
<b>KITL Enable Mode</b>	Enable/Disable KITL
<b>KITL Passive Mode</b>	Switch between active and passive KITL. Active KITL will try to connect a Visual Studio to establish a debug connection via Ethernet. Passive KITL will just print out the debug messages to UART1.
<b>Save configuration</b>	Saves the current configuration to NOR flash.
<b>Download image now</b>	Immediately starts a download connection to load a run-time image from Visual Studio.
<b>Launch Existing Flash Resident Image Now</b>	Launch the run-time image stored already in NOR flash.
<b>Select Ether Device</b>	Select the Ethernet device for eBoot (FES or SMSC)
<b>MMC and SD Utilities</b>	Some utilities to write / format to the eMMC Flash and SD-Card
<b>L2CC Active Mode</b>	Enable / Disable L2-Cache
<b>L2CC Work Mode</b>	L2 write strategy: write back / write trough

*Table 6-1: Bootloader options*

## 6.2 Updating the EBOOT boot loader

### WARNING:

Updating the EBOOT is dangerous. If the updated process does not finish successful, the EBOOT will not start anymore, and you will have to reprogram it again via JTAG debugger. Please contact TQ for more information.

Follow these steps to update the EBOOT image on the TQMa35 module:

1. Use the **File** menu of Visual Studio and choose **Open Workspace**.
2. Select the appropriate EBOOT.NB0 file you received from TQ.  
**Note:**  
 The selection of the EBOOT.nb0 file (see folder \EBOOT on the DVD) depends on the display (see Direct Draw display driver), RAM and NOR-Flash configuration (see also Memory configuration).
3. Follow the steps in Configuring Ethernet Connection for Downloading and Debugging to establish an Ethernet connection between the target and Visual Studio.
4. From the **Target** menu, select **Attach Device**.
5. Select (D)ownload on the terminal, and confirm the destination as 1 (NOR)  
 INFO: OEMMultiBINNotify (dwNumRegions = 1, dwRegionStart = 0x0).  
 Specify destination for EBOOT/SBOOT NB0 [1 = NOR, 2 = NAND, 3 = SD/MMC]:
6. The eBoot should be loaded into the RAM, confirm to write into the Flash-Memory with "Y"  
 Completed file(s):  
 -----  
 [0]: Address=0x90000000 Length=0x40000 Name="EBOOT.nb0" Target=FLASH  
 -----  
 WARNING: Flash update requested.  
 Do you want to continue (y/n)?
7. After the download is complete, from the *Target* menu, select *Detach Device*.
8. Switch over your terminal emulation application. At this point, EBOOT has downloaded the image temporarily into SDRAM and is ready to begin the flash programming procedure.
9. In the terminal emulation application, hit the 'y' key to begin programming the flash.
10. EBOOT will program the image into flash and provide status using serial debug messages. Once the programming is complete, you will see the following messages:  
 INFO: Flashing sequence complete.  
 Reboot the device manually...  
 SpinForever...Do you want to reset [Y\N]

### Warning: DO NOT SWITCH OFF THE POWER SUPPLY DURING FLASH UPDATE

11. Close the Visual Studio workspace for EBOOT.nb0. It is not necessary to save any workspace changes.
12. Reset the target hardware. If you see new EBOOT messages appear on the terminal, EBOOT has been properly programmed into NOR flash.

## 7 Device Drivers

This chapter describes the individual settings for the included device drivers of the BSP.

### **Note:**

If you want to create more than one workspace with different driver settings (e.g. one with DHCP and another one with static IP-Address) you will have to relocate the driver registry settings from the BSP (platform.reg) to your workspace (project.reg).

### 7.1 USB

#### 7.1.1 USB OTG Drivers

The USB OTG driver provides high speed USB 2.0 host and device support for the USB “On The Go” (OTG) port of the TQMa35 module. The OTG driver will automatically select either Host (master) or Device (slave) functionality for high speed at any given time, depending on the USB OTG-Pin configuration.

This is achieved by the set of three drivers: USB OTG host controller driver, USB client driver and/or USB transceiver controller (“Full Function”) driver, which performs the host/function client switching.

The USB host driver can be configured for class support for mass storage, HID, printer, and RNDIS peripherals. The device/client portion can be configured to provide one of mass storage, serial, or RNDIS function.

### **Note:**

The USB OTG port can only be configured in one of the 3 possible device roles (mass storage, serial or RNDIS). The role is set with “DefaultClientDriver” value under the [HKEY\_LOCAL\_MACHINE\Drivers\USB\FunctionDrivers] key.

The “Full Function” OTG transceiver driver automatically selects between the host or client driver. The host or client can also be configured as the only mode for the OTG port, using the *Pure Host* or *Pure Client* catalog item. All the OTG catalog items are exclusive.

##### 7.1.1.1 Adding the USB OTG Drivers

Depending on the desired functionality select one of the entries *Full OTG Function*, *Pure Client Function* or *Pure Host Function* in the Catalog (**Catalog Item View** → **Third party** → **BSPs** → **Freescale i.MX35 TQS: ARMV4I** → **Device Drivers** → **USB Devices** → **USB High Speed OTG Device**).

##### 7.1.1.2 USB OTG Drivers Configuration

There is nothing to configure for this driver.

### 7.1.2 USB Mouse and Keyboard Support

To have support for USB keyboards and mice add the “USB HID Keyboard and Mouse” component to your OS design (**Catalog Item View → Core OS Service → USB Host Support -> USB Human Input Device (HID) Class Driver -> USB HID Keyboard and Mouse**).

### 7.1.3 USB Printer Support

To have support for USB printers add the components “USB Printer Class Driver” (**Catalog Item View → CoreOS → CEBASE → Core OS Service → USB Host Support**) and “PCL Printer Driver” (**Catalog Item View Catalog → Device Drivers → Printer Devices**) to your OS design.

## 7.2 SD Host Controller

The SD Host Controller Driver adds support for SD-Card functions of the i.MX35 CPU to your OS design.

### 7.2.1 Adding the SD Host Controller Driver to Your OS Design

Select the *Enhanced SD Host Controller 1* or *eMMC Memory at SD3* component in the Catalog (**Catalog Item View → Third party → BSPs → Freescale i.MX35 TQS: ARMV4I → Device Drivers → SD Controller**).

### 7.2.2 SD Host Controller Driver Configuration

The device specific parameters i.e. the name of the directory entries are stored in  
`\drivers\esdhc\esdhc_mx35.reg`.

## 7.3 Audio

The Audio Driver adds support for the audio functions of the i.MX35 CPU to your OS design.

### 7.3.1 Adding the Audio Driver to Your OS Design

Select the *Audio Buzzer* and/or *SGTL5000 Stereo Audio* component in the Catalog (**Catalog Item View → Third party → BSPs → Freescale i.MX35 TQS: ARMV4I → Device Drivers → Audio**).

### 7.3.2 SGTL5000

The *SGTL5000 Stereo Audio* supports recording and playing audio data. The correct handling of the standard interface is described at the WinCE help. To support the different audio formats enable the codecs at **Catalog Item View → CoreOS → CEBASE → Core OS Service → Graphics and Multimedia Technologies**.

To test the *SGTL5000 Stereo Audio* may be used the application *testwavein.exe* located at \windows directory of the device. The application records 8 seconds from the line in into the file \test.wav. Subsequently the file is played.

### 7.3.3 Buzzer

The „Audio Buzzer“ is a simple PWM generator without any volume control. The driver is implemented as a stream interface device called *BUZ1*:

CreateFile – open a handle to the device

CloseHandle – close the handle

DeviceIOControl – access to the driver

- IOCTL\_XXX\_GETVERSIONINFO (defined at bsp\_verion.h) returns the driver version as a structure DRV\_VERSION\_INFORMATION
- IOCTL\_BUZ\_SET starts a tone generation, the frequency and duration defined at the structure DRV\_BUZZER. The caller of this IO-Controls is blocked until the tone generation is stopped !

Example:

```
HANDLE h = CreateFile(L"BUZ1:", GENERIC_READ | GENERIC_WRITE, 0, NULL, OPEN_EXISTING, 0, NULL);
if ( DeviceIoControl(h, IOCTL_XXX_GETVERSIONINFO, NULL, 0, &v, sizeof(v), &dummy, 0) ) {
    RETAILMSG(1, (TEXT("Versionsinformation:\r\n")));
    RETAILMSG(1, (TEXT("  Name: %S\r\n"), v.cName));
    RETAILMSG(1, (TEXT("  Build: %S\r\n"), v.cBuild));
    RETAILMSG(1, (TEXT("  Version: 0x%x\r\n"), v.ulVersion));
} else {
    RETAILMSG(1, (TEXT("Versionsinformation kann nicht gelesen werden !!!!\r\n")));
}
p.freq, = 1000;          // Ton von 1 Khz
p.length = 1000;       // Laenge 1 sek
DeviceIoControl(h, IOCTL_BUZ_SET, &p, sizeof(p), NULL, 0, NULL, 0);
CloseHandle(h);
```

To test the buzzer you can use the test application (windows)\testpwm.exe. The source code is of the test application is located at \testappl\testpwm.

Syntax (calling in a telnet session):

```
testpwm <frequency Hz> <duration msek>
```

## 7.4 LM75 Temperature Sensor

The temperature sensor driver adds support for reading the temperature from 2 temperature sensors. The sensor 1 is located on the rear side of the TQMa35 CPU module, and the sensor 2 is located on the baseboard. The driver is done as a stream interface device, for each sensor one instance.

Temperatures are given as 16bit signed values in units of 0.1°C.

### **Note:**

Adding the temperature sensor driver also adds the I2C driver to your OS design.

### 7.4.1 Adding the Temperature Sensor Driver to Your OS Design

Select the „ LM75 Temperature Sensor “ component in the Catalog (**Catalog Item View → Third party → BSPs → Freescale i.MX35 TQS: ARMV4I → Device Drivers → I2C Devices → Temp**).

## 7.4.2 How to Use the Temperature Sensor Driver

The LM75 temperature sensor driver supports the Windows CE standard stream driver interface (“TMP1:” and „TMP2:“).

CreateFile – open a handle to the device

CloseHandle – close the handle

DeviceIOControl – access to the driver

- IOCTL\_XXX\_GETVERSIONINFO (defined at bsp\_verion.h) returns the driver version as a structure DRV\_VERSION\_INFORMATION
- IOCTL\_GET\_TEMP read one value from the temperature IC (structure TEMP\_STRUCT)
- IOCTL\_SET\_TEMP write one value from the temperature IC (structure TEMP\_STRUCT)

reg	R/W	Value	Bezeichnung
0	R	temperature * 10°C ( value 550 corresponds 55,0 °C )	Temperature
1	R/W	Zu schreibender Registerwert	Config
2	R/W	temperature * 10°C (value 550 corresponds 55,0 °C )	THYST
3	R/W	temperature * 10°C ( value 550 corresponds 55,0 °C )	TOS

Table 7-1: LM75 Register

### Example

```

HANDLE h;
DWORD dummy;
DRV_VERSION_INFORMATION v;
TEMP_STRUCT t;

h = CreateFile(L"TMP1:", GENERIC_READ | GENERIC_WRITE, 0, NULL, OPEN_EXISTING, 0, NULL);

if ( DeviceIoControl(h, IOCTL_XXX_GETVERSIONINFO, NULL, 0, &v, sizeof(v), &dummy, 0) ) {
    RETAILMSG(1, (TEXT("Versionsinformation:\r\n")));
    RETAILMSG(1, (TEXT("  Name: %S\r\n"), v.cName));
    RETAILMSG(1, (TEXT("  Build: %S\r\n"), v.cBuild));
    RETAILMSG(1, (TEXT("  Version: 0x%x\r\n"), v.ulVersion));
} else {
    RETAILMSG(1, (TEXT("Versionsinformation kann nicht gelesen werden !!!!\r\n")));
}

t.reg = 0; // Temperatur lesen
if ( DeviceIoControl(h, IOCTL_GET_TEMP, &t, sizeof(t), &t, sizeof(t), &dummy, 0) )
    RETAILMSG(1, (TEXT("  Temp          = %d *10°C\r\n"), t.value ));
else
    RETAILMSG(1, (TEXT("Fehler !!\r\n")));

CloseHandle(h);

```

A demo program **testtemp.exe** is included in the BSP. To execute the demo please open a telnet window and type “testtemp.exe”. The program will display the temperature values read from the LM75 temperature sensors. The source code of this demo program can be found under \testapp\testtemp.

## 7.5 Serial Ports (UARTs)

Serial ports (one RS232, one RS485) are used e.g. for debug or to connect external devices.


### 7.5.1 Adding Serial Drivers to Your OS Design

You can add up to three serial ports through the Visual Studio IDE.

Select „UART1 “ and/or “UART2” component in the catalog (**Catalog Item View → Third party → BSPs → Freescale i.MX35 TQS: ARMV4I → Device Drivers → Serial**).

### 7.5.2 Serial Driver Configuration

Because the serial UART1 is also used as debug interface a control panel applet dbgena.cpl is included in the BSP. After enable / disable the debug interface the registry should make persistent (flushreg).



*Figure 21: Enable or disable debug port*

The source code of the CPL can be found under `\testapp\ldbgena`

## 7.6 Touch Panel Support

The BSP includes a driver for the i.MX35 integrated 4-wire resistive touch controller.

### 7.6.1 Adding the Touch Panel Driver

Select touch panel driver on the "Touch Driver" component in the **(Catalog Item View → Third party → BSPs → Freescale i.MX35 TQS: ARMV4I → Device Drivers → Touch)**.

### 7.6.2 Touch Panel Driver Configuration

The configuration is done by calling *caltouch* or *caltouchauto*. By default the *caltouch* is replaced by *caltouchauto* and run on system start if no calibration data stored in registry.

The source code of both applications can be found under `\testapp\caltouch*`.

## 7.7 I2C Bus Driver

The Inter-Integrated Circuit (I2C) module provides the generic functionality of a standard I2C slave and master. The I2C module is designed to be compatible with the standard Phillips I2C bus protocol.

### 7.7.1 Adding the I2C Bus Driver

Select one or both of the "I2C bus <x>" component in the **(Catalog Item View → Third party → BSPs → Freescale i.MX35 TQS: ARMV4I → Device Drivers → I2C Bus)**.

### 7.7.2 I2C Bus Driver Configuration

There is nothing to configure for this driver.

## 7.8 GPT driver

The general-purpose timer is a multipurpose module used to measure intervals or generate periodic output.

### 7.8.1 Adding the GPT Driver

Select the "GPT" component in the **(Catalog Item View → Third party → BSPs → Freescale i.MX35 TQS: ARMV4I → Device Drivers → GPT)**.

### 7.8.2 GPT Driver Configuration

There is nothing to configure for this driver.

## 7.9 Smart Backlight Control

The backlight driver interfaces with the Windows CE Power Manager to provide timed control over the display backlight. A timeout interval controls the length of time that the backlight stays on.

### 7.9.1 Adding Smart Backlight Control

Select the *IPU Backlight Control Support* on the appropriate driver component in the **(Catalog Item View → Third party → BSPs → Freescale i.MX35 TQS: ARMV4I → Device Drivers → IPU Backlight)**.

### 7.9.2 IPU Backlight Driver Configuration

The following registry keys are required to properly load backlight driver.

```
[HKEY_CURRENT_USER\ControlPanel\Backlight]
"BattBacklightLevel"=dword:FF ; Backlight level settings. 0xFF = Full On
"ACBacklightLevel"=dword:FF ; Backlight level settings. 0xFF = Full On

; Backlight control default settings for WinCE.
"UseExt"=dword:0 ; Enable timeout when on external power
"UseBattery"=dword:0 ; Enable timeout when on battery
"AdvancedCPL"="AdvBacklight" ; Enable Advanced Backlight control panel dialog
"BatteryTimeout"=dword:1E ; 30 Seconds
"ACTimeout"=dword:78 ; 2 Minutes
```

The timeouts are given in seconds. On a running Windows CE the backlight setting can also be changed by the display control panel applet.




Figure 22: Backlight Control

Hint: Don't forget to make the change persistent by calling *flushreg c*.

## 7.10 RTC

The RTC driver adds the real-time clock support to your OS design.

### 7.10.1 Adding the RTC driver

Select RTC driver on the *RTC* component in the **(Catalog Item View → Third party → BSPs → Freescale i.MX35 TQS: ARMV4I → Device Drivers → RTC)**.

## 7.10.2 RTC driver configuration

There is nothing to configure for this driver.

## 7.11 GPIO

The GPIO driver drives the buzzer pin of the TQMa35 module.

### 7.11.1 Adding the GPIO driver

Select the GPIO on the appropriate driver component in the **(Catalog Item View → Third party → BSPs → Freescale i.MX35 TQS: ARMV4I → Device Drivers→Buzzer)**.

### 7.11.2 GPIO driver default configuration

The GPIO driver uses a standard Windows CE stream driver interface. To access to the driver use the IO-Control interface. The configuration of the similar pins is done by the software. By default following states are active:

Pin name	Value	IC / PIN	Initial value	I/O
GPOUT1	0	D24/P0	0	O
GPOUT2	1	D24/P1	0	O
GPOUT3	2	D24/P2	0	O
GPOUT4	3	D24/P3	0	O
GPOUT5	4	D24/P4	0	O
GPOUT6	5	D24/P5	0	O
GPOUT7	6	D24/P6	0	O
GPOUT8	7	D24/P7	0	O
GPI1	8	D24/P0	X	I
GPI2	9	D26/P1	X	I
GPI3	10	D26/P2	X	I
GPI4	11	D26/P3	X	I
USER_LED1	12	D26/P4	0	O
USER_LED2	13	D26/P5	0	O
LD_BKL_ON	14	D26/P6	0	O
LCD_LVDS_ENA	15	D26/P7	0	O
OVERTEMP	16	GPIO1_12	X	I

*Table 7-2: Default states*

### 7.11.3 How to use the GPIO driver

The GPIO driver is included as *GPI1*:

CreateFile – open a handle to the device

CloseHandle – close the handle

DeviceIOControl – access to the driver

- IOCTL\_XXX\_GETVERSIONINFO (defined at bsp\_verion.h)  
returns the driver version as a structure DRV\_VERSION\_INFORMATION
- IOCTL\_GET\_LEVEL read one pin (structure GPIO\_LEVEL defined at bsp\_gpio.h)
- IOCTL\_SET\_LEVEL write one pin (structure GPIO\_LEVEL defined at bsp\_gpio.h)

Example:

```
GPIO_LEVEL gpio;
DWORD dummy;
HANDLE h = CreateFile(L"GPI1:", GENERIC_READ | GENERIC_WRITE, 0,
                    NULL, OPEN_EXISTING, 0, NULL);

if ( DeviceIoControl(h, IOCTL_XXX_GETVERSIONINFO, NULL, 0, &v, sizeof(v), &dummy, 0) ) {
    RETAILMSG(1, (TEXT("Versionsinformation:\r\n")));
    RETAILMSG(1, (TEXT("    Name: %S\r\n"), v.cName));
    RETAILMSG(1, (TEXT("    Build: %S\r\n"), v.cBuild));
    RETAILMSG(1, (TEXT("    Version: 0x%x\r\n"), v.ulVersion));
} else {
    RETAILMSG(1, (TEXT("Versionsinformation kann nicht gelesen werden !!!!\r\n")));
}
// Schalte USER-LED1 ein
gpio.pin = USER_LED1; // pin 12
gpio.level = 1; // an
DeviceIoControl(h, IOCTL_SET_LEVEL, &gpio, sizeof(gpio), NULL, 0, NULL, 0);

// Lese Pegel von IN1
gpio.pin = GPI1; // IC2, PIN 0
DeviceIoControl(h, IOCTL_GET_LEVEL, &gpio, sizeof(gpio), &gpio, sizeof(gpio), &dummy, 0)
RETAILMSG(1, (TEXT("Pegel = 0x%x\r\n"), gpio.level));
CloseHandle(h);
```

The source of a test program can be found under \testappl\testgpio.

## 7.12 CAN Driver

The CAN driver adds support to your OS design for the Freescale CAN controller located on the TQMa35 CPU module .

### 7.12.1 Adding the MCP2515 CAN Driver to Your OS Design

Select one or both CAN interfaces in the catalog (**Catalog Item View → Third party → BSPs → Freescale i.MX35 TQS: ARMV4I → Device Drivers → CAN**).

### 7.12.2 Freescale CAN Driver Configuration and Usage

There is nothing to configure for this driver.

For a detailed description of the CAN interface please look on the Freescale homepage.

## 7.13 EEPROM Driver

The TQMa35 EEPROM driver adds support for access the EEPROM as a standard file.

### 7.13.1 Adding the EE Driver to Your OS Design

Select the EEPROM driver component in the catalog (**Catalog Item View → Third party → BSPs → Freescale i.MX35 TQS: ARMV4I → Device Drivers→I2C Devices**).

### 7.13.2 EEPROM Driver Configuration and Usage

There is nothing to configure for this driver. All functions concerning the EEPROM are controlled via the stream interface at *EPR1*.

#### CreateFile

Open a handle to the device, up to 10 instances may open.

#### Seek

Move the read/write-pointer (*FILE\_END/FILE\_CURRENT/FILE\_BEGIN*) for the next command and returns the current “file” position.

#### WriteFile

Write the buffer into the EEPROM. A wrap around is blocked by the driver.

#### ReadFile

Read a number of bytes into the buffer.

#### CloseHandle

Close the current instance.

#### DeviceIOControl

*IOCTL\_XXX\_GETVERSIONINFO* (defined at *bsp\_verion.h*) returns the driver version at the structure *DRV\_VERSION\_INFORMATION*.

#### Example:

```
HANDLE h = CreateFile(L"EPR1:", GENERIC_READ | GENERIC_WRITE, 0, NULL, OPEN_EXISTING, 0, NULL);
printf ("EEPROM-Size: %d \r\n", SetFilePointer(h, 0, 0, FILE_END ) ); // lese Eprom-Groesse
SetFilePointer(h, 0, 0, FILE_BEGIN ); // Lese/Scheibzeiger auf Pos 0
BOOL bRet = ReadFile ( h, test, 1024, &dwRead, NULL); // Lese 1024 Bytes
CloseHandle(h); // Schliesse Handle
```

The source of a test program can be found under `\testappl\testeeprom`.

## 7.14 SPI Bus Driver

The SPI module provides the generic functionality of a standard SPI slave and master. The SPI module is designed to be compatible with the standard SPI bus protocol.

### 7.14.1 Adding the SPI Bus Driver

Select one or both of the “CSPI bus <x>” component in the **(Catalog Item View → Third party → BSPs → Freescale i.MX35 TQS: ARMV4I → Device Drivers→ CSPI Bus)**.

### 7.14.2 CSPI Bus Driver Configuration

There is nothing to configure for this driver.

## 8 Developing Applications

The following steps guide you through the creation of an SDK for your OS design and shows you how to use Visual Studio 2005 to develop, debug and download applications.

### 8.1 Creating an SDK from Your OS Design

**Note:**

Before building the SDK please do a Sysgen of a Release Run-Time Image of your OS Design.

Start the Visual Studio IDE, open your workspace and select “Add New SDK” from the “Project” menu.




Figure 23: Create a new SDK

Choose a unique name for the SDK, enter the name of your company and hit *Ok*.




Figure 24: Setting up the SDK properties

To finally build the SDK select *Build All SDKs...* from the *Build* menu.

Your SDK will be created as an MSI file located at:  $$(\_PBWORKSPACEROOT) \backslash SDK \backslash$ . It is self-installable by double clicking it and it is removable using *Add/Remove Programs* from the Windows XP Control Panel.

## 8.2 Developing with Visual Studio 2005

To develop and debug programs written in C++, C# and Visual Basic to run with Windows CE, you can use Microsoft Visual Studio 2005®.

### 8.2.1 Installation

Additionally to the installation DVD of Microsoft Visual Studio 2005 the following software components must be on-hand or installed:

- Microsoft .NET Framework 1.1
- Microsoft .NET Framework 2.0
- Service Pack 1 for Microsoft Visual Studio 2005
- Microsoft .NET Compact Framework 2.0
- Service Pack 1 for Microsoft .NET Compact Framework 2.0
- Service Pack 2 for Microsoft .NET Compact Framework 2.0
- i.MX35 TQS SDK
- Microsoft Windows Mobile Device Center or Active Sync

Steps for installation:

**Note:**

If one or more of the following software components are already installed, please skip the appropriate installation:

1. Microsoft .NET Framework 1.1
2. Microsoft .NET Framework 2.0
3. Microsoft Visual Studio 2005
4. Service Pack 1 for Microsoft Visual Studio 2005
5. Microsoft .NET Compact Framework 2.0
6. Service Pack 1 for Microsoft .NET Compact Framework 2.0
7. Service Pack 2 for Microsoft .NET Compact Framework 2.0
8. i.MX35 TQS SDK
9. Microsoft Windows Mobile Device Center or Active Sync

**8.2.2 Generate a Simple Project**

Run the visual studio and select a new project




Figure 25: Generate a new project




Figure 26: project type

Use the next menu to select the “TQS iMX35” SDK.




Figure 27: platform type




Figure 28: application type

Select the platform as a Console Application. The Visual Studio generates a simple Application, to see something on the target add

```
MessageBox(NULL, L"World", L"Hello", MB_OK);
```

to the source code:

```

// Test2.cpp : Defines the entry point for the console
//
#include "stdafx.h"
#include <windows.h>
#include <commctrl.h>

int _tmain(int argc, _TCHAR* argv[])
{
    MessageBox(NULL, L"World", L"Hello", MB_OK);
    return 0;
}

```

Figure 29: first Application

### 8.2.3 Establish a Connection between VS 2005 and the CE Device

#### 8.2.3.1 Startup over Active Sync / Transport over Ethernet

**Note:**

Before you start with the following steps, be sure that the run time image on the target device did built in the active sync support (see chapter *Establish a ActiveSync Connection over USB*).

Click on *Tools, Options* on the main menu.




Figure 30: Device Options

Select the SDK OS design from *Show devices for platform*.




Figure 31: selection platform device

Configure the IP address of the target depends from the network infrastructure (**Properties** → **Configure**).




Figure 32:configure the IP address of the target

Then attach to the device with the button *Connect to Device* on the toolbar.




Figure 33: connect to Device

Hint: Not ever the iMX35 TQS is selected as default !

The *Connecting...* message box appears and reports the connection status.




Figure 34: try to Connection

Afterwards you can start with debugging by clicking on the button *Start debugging* (green arrow).




Figure 35: start Debugging

Set a debug break on the line *MessageBox* and press *Run* on the toolbar.




Figure 36: signaling an active breakpoint

Press *F10* (step over) and on the target you will see a small message window with Hello World.




Figure 37: target Window

## 8.3 Application Deployment

This chapter shows how to include applications and associated files (e.g. DLLs) in your image. Further you will learn how to start your applications automatically when Windows CE has booted.

### 8.3.1 Adding Applications and Files to Your OS Design

You can include your applications and additional files (e.g. DLLs) in your Windows CE image by adding an entry in the MODULES/FILES section of your project.bib file.

E.g. : Include an application named myapp.exe with an additional DLL named myapp.dll and a bitmap file. In this example all files are located in a directory called `%_WINCEROOT%\MYAPP\`.

Add the following lines to your project.bib file:

```

MODULES
; Name          Path          Memory Type
; -----
MYAPP.EXE      $(_Winceroo) \MYAPP\MYAPP.EXE      NK SH
MYAPP.DLL      $(_Winceroo) \MYAPP\MYAPP.DLL      NK SH

FILES
; Name          Path          Memory Type
; -----
PLASH.BMP      $(_Winceroo) \MYAPP\PIC1.BMP      NK SH
    
```

MODULES is reserved for executables and DLLs. Any file in the MODULES area will be fixed up to execute in place (XIP). Those files won't be available via the file system. This is recommended especially for DLLs.

All files loaded by applications should be placed in the FILES section. Those files are compressed and available via the file system.

The major difference between the FILES section and the MODULES section is this: If a dynamic-link library (.dll) file is placed in the FILES section, as opposed to the MODULES section, it is loaded into every slot location instead of process slot 1 only, which decreases the virtual address space available to the process.

You can also rename files via the BIB file entries. As you can see in the example above, the bitmap file called PIC1.BMP will show up as SPLASH.BMP in the Windows CE file system.

If you want to learn more about how the Windows CE image is built up and about the different settings for memory types please refer to the Visual Studio help system for "MODULES Section" respectively "FILES Section".

### 8.3.2 Auto Start-up of Windows CE applications

After the Windows CE boot process has finished, your application must be started. To accomplish this, you have to insert appropriate entries into the *HKEY\_LOCAL\_MACHINE\init* registry key. This can be done using the *project.reg* file of your workspace.

To create a registry entry for starting an application under the Windows CE, add the following statements to the *HKEY\_LOCAL\_MACHINE\init* section of your *project.reg* file:

```
[HKEY_LOCAL_MACHINE\init]
"launchXX"="exe_name"
"dependXX"=hex:YY,00
```

Name	Values	Description
launchXX	Name of the application to start.	XX represents a number <b>in decimal</b> from 00 to 99. Only launch numbers from 80 to 89 are valid. All others are reserved.
dependXX	hex:xx,yy	Describes a dependency of the launched application. If some other application must be started before the application defined by the launch key can be successfully launched, then this entry should be used to identify that other application. XX,YY represents the launch number <b>in hexadecimal</b> of the application that must be loaded <i>first</i> . (YY is the most significant byte and therefore always 00). One or more dependent applications can be specified per <i>dependXX</i> value. The <i>dependXX</i> entry is optional; if there is no dependency you don't need to use it.

Table 8-1 Application auto start registry settings

The following code example shows a typical Init registry entry using dependencies:

```
[HKEY_LOCAL_MACHINE\Init]
"Launch10"="shell.exe"
"Launch20"="device.exe"
"Launch30"="gwes.exe"
"Depend30"=hex:14,00
"Launch50"="taskman.exe"
"Depend50"=hex:14,00, 1e,00
```

**Note:**

The application that must be started, first must call the function **SignalStarted()** to inform Windows CE when it is ready. The dependent application cannot run until after the function on which it depends on has issued the **SignalStarted** function.

**Note:**

If your application is located on a external media (CFCard, USB stick) you have to add the path to this media to the system path variable. Example:

```
[HKEY_LOCAL_MACHINE\init]
"Launch80"="test.exe"
"Depend80"=hex:14,00, 1e,00, 32,00

[HKEY_LOCAL_MACHINE\Loader]
"SystemPath"=multi_sz:"\\Release\\", "\\cfcard\\test\\"
```

## 8.4 ActiveSync

### 8.4.1 Required Components

The following components of the catalog must be added to your OS design:

1. Core OS / Windows CE devices / Applications – End User / File Sync




Figure 38: adding file sync to an OS design

2. Core OS / Windows CE devices / Shell and User Interface / Network User Interface




Figure 39: Adding Network User Interface to an OS design

In additional following (old) components add to the platform.bib:

```
IF BSP_ASYNC_FILES
  ConManClient2.exe $_WINCEROOT\PLATFORM\imx35-tqs\files\async\ConManClient2.exe NK N
  cmaccept.EXE $_WINCEROOT\PLATFORM\imx35-tqs\files\async\cmaccept.EXE NK N
  ClientShutdown.exe $_WINCEROOT\PLATFORM\imx35-tqs\files\async\ClientShutdown.exe NK N
  eDbgTL.dll $_WINCEROOT\PLATFORM\imx35-tqs\files\async\eDbgTL.dll NK N
  TcpConnectionA.dll $_WINCEROOT\PLATFORM\imx35-tqs\files\async\TcpConnectionA.dll NK N
  cemgrc.exe $_WINCEROOT\PLATFORM\imx35-tqs\files\async\cemgrc.exe NK N
  tcpipc.dll $_WINCEROOT\PLATFORM\imx35-tqs\files\async\tcpipc.dll NK N
  cetlstub.dll $_WINCEROOT\PLATFORM\imx35-tqs\files\async\cetlstub.dll NK N
ENDIF BSP_ASYNC_FILES
```

Set the environment variable BSP\_ASYNC\_FILES to 1, build the OS design, create a run-time image and download it to your device.

### 8.4.2 Establish a Active Sync Connection Over Serial Port

Disable the debug port as COM1: (Menu → Settings → Control Panel → Enable Debug)




Figure 40: Disable debug port

Call “flushreg w” on an command prompt or terminal to make the registry persistent. After rebooting the device the last messages on the terminal should be

```
OEMInit: L2 cache is enabled (AUXCR = 0x3001b)
OEMGetExtensionDRAM
OALPmicInit: Trying to init PMIC I2C Interface
OALI2cGenerateStop: Bus not cleared for 1000 cycles
INFO: OALPerRegRead: Registry read start
INFO: OALPerRegRead: Registry read start
INFO: OALPerRegRead: Registry read done (0)
Debug::configure debug port...

Debug::REGISTRY HKLM\DEBUG:dword:dbgSerial=0
```

On the target device open the start menu, select “Settings” and then “Network and Dial-up Connections”.




Figure 41: Network and Dial-up Connections

A new window opens with an icon named “Make New Connection”. Make a double click on this icon, in the new dialog type a name for the connection , select type “Direct Connection” and hit “Next >”.

The next dialog prompts for selecting a device (i.MX35 COM1 Unimodem).

After you hit *Finish* a new connection symbol with the name you chose appears in the *Network Connection* window.

Open the control panel and double click on PC connection. Click on the change button and select the connection you have just created.

By double clicking this symbol the system tries to establish a connection to the host PC. If no host PC running ActiveSync is available the device tries to connect a few times, then it waits for incoming connection requests. You can check this by running a terminal program (e.g. HyperTerminal which is included in Windows XP) instead of ActiveSync and set the baud rate to 19200. After clicking the connection symbol on the target device the terminal program should show some “CLIENT” messages it received. Closing the terminal program and running Active Sync will then lead to an established connection.

### 8.4.3 Establish a ActiveSync Connection over USB

Include either *OTG Pure Client Function* or *OTG Full OTG Function* in your OS Design.

Include also the *Serial USB Function Driver* in your OSDesign (**Catalog → Device Drivers → USB Function →USB Function Client**).

When you plug in a Type B Plug in your device and connect the cable with your host computer running ActiveSync the device will be recognized automatically.

## 9 Additional Customizations

The following chapters will give you hints for the usage of some Windows CE components and other useful settings regarding the appearance of Windows CE.

### 9.1 Windows CE Components

#### 9.1.1 Telnet Server

Telnet allows easy access to your Windows CE device over the network.

To add the Telnet server to your image Select on the „Telnet Server“ component in the catalog (**Catalog → Core OS → CEBASE → Communication Services and Networking → Servers**).

To enable the Telnet server you have to add additional registry keys (e.g. In your project.reg file) as shown below:

```
[HKEY_LOCAL_MACHINE\COMM\TELNETD]
    "IsEnabled"=dword:1          ; set to 0 to disable the telnet server
    "UseAuthentication"=dword:0 ;anonymous access allowed
```

#### **Note:**

The settings above will allow anonymous access to your system. There is no password required as long as the *UseAuthentication* Key is set to 0. If you wish to protect the integrity of your system by adding a degree of security, however, you may enable the password feature in Telnet. To do this, set the *UseAuthentication* key to one. The Telnet server will then ask for a login and password before establishing a connection.

To connect via Telnet simply open a Command Prompt in Windows XP and do a Telnet to the IP-address of your target system (e.g. *telnet 192.168.2.76*). You can close the connection by simply typing *exit* at the command prompt.




Figure 42: target connection via Telnet

## 9.1.2 FTP Server

FTP allows you to transfer files to and from your target system via the File Transfer Protocol without the need of using ActiveSync.

To add the FTP server to your image right-click on the *FTP Server* component in the Catalog (**Catalog -> Core OS -> Windows CE devices -> Communication Services and Networking -> Servers**) and choose *Add to OS Design*.

To enable the FTP server you have to add additional registry keys (e.g. In your project.reg file) as shown below:


```
[HKEY_LOCAL_MACHINE\COMM\FTPD]
    "IsEnabled"=dword:1
    "UseAuthentication"=dword:1
    "AllowAnonymous"=dword:1
    "AllowAnonymousUpload"=dword:1
    "DefaultDir"="\\"
```

### Note:

The registry settings shown above allow anonymous access to your target system. This should be disabled before you deploy your OS design. You should set the *AllowAnonymous* registry key to 0 and add a list of allowed users to the registry. Search the Visual Studio Help System for *FTP server User List* for more information.

To connect via FTP simply open a Command Prompt in Windows XP and do an ftp command to the IP-address of your target system (e.g. *ftp 192.168.2.76*). You can close the connection by simply typing *bye* at the command prompt.

The default user-ID is anonymous, on password you can write as you well.



```
C:\Windows\system32\ftp.exe
Verbindung mit 192.168.2.76 wurde hergestellt.
220 Service ready for new user.
Benutzer (192.168.2.76:(none)): anonymous
331 Anonymous access allowed, send identity (e-mail name) as password.
Kennwort:
230 User logged in, proceed.
ftp> ls -la
200 Command okay.
150 File status okay; about to open data connection.
01-01-98 04:00 <DIR> MMCMemory
01-01-00 12:00 <DIR> Application Data
01-01-00 04:00 <DIR> profiles
01-01-00 04:00 <DIR> Documents and Settings
01-01-00 04:00 23 Control Panel.lnk
01-01-00 04:00 <DIR> My Documents
01-01-00 04:00 <DIR> Program Files
01-01-00 04:00 <DIR> Temp
01-01-00 04:00 <DIR> Windows
226 Closing data connection.
FTP: 459 Bytes empfangen in 0,40Sekunden 1,15KB/s
ftp> _
```

Figure 43: target connection via FTP

## 9.2 Changing of the Appearance of Windows CE

### 9.2.1 Changing the Desktop Wallpaper

1. Add the following key to project.reg:

```
; ***** Wallpaper *****
[HKEY_CURRENT_USER\ControlPanel\Desktop]
    "wallpaper"="\\Windows\customer.bmp"
```

2. Add the file name and path for the new wallpaper bitmap to project.bib:

```
windowsce_qvgap.bmp $(_FLATRELEASEDIR)\customer.bmp          NK  S
```

3. Copy the bitmap file to the directory  
 \$(\_WINCEROOT)\PBWorkspaces\\$\_TGTPROJ)\WINCE500\TQMa31\_ARMV4\OAK\files.

### 9.2.2 Hiding the Taskbar

Add the following keys to project.reg:

```
; ***** Taskbar & desktop setting *****
[HKEY_LOCAL_MACHINE\Software\Microsoft\Shell\AutoHide]
; Taskbar auto-hide
@="1"

[HKEY_LOCAL_MACHINE\Software\Microsoft\Shell\OnTop]
; @="1" taskbar always visible (on top)
; @="" taskbar can be covered by other windows
@=""
```

### 9.2.3 Changing the Folder Name of Storage Devices

Example for modifying project.reg:

```
; ***** USB stick folder name *****
[HKEY_LOCAL_MACHINE\System\StorageManager\Profiles\USBHDProfile]
    "Folder"="USB Stick"

; ***** CFCard folder name *****
[HKEY_LOCAL_MACHINE\System\StorageManager\Profiles\PCMCIA]
    "Folder"="CFCard"

; ***** SDCard folder name *****
[HKEY_LOCAL_MACHINE\System\StorageManager\Profiles\SDMemory]
    "Folder"="SDCard"
```

## 9.2.4 Setting up the Time Zone to GMT

Add the following registry entries to project.reg:

```
; ***** Date/Time Settings *****
; Time zone default settings
[HKEY_LOCAL_MACHINE\Time Zones]
"Default"="GMT Standard Time"

;Clock Format
[HKEY_LOCAL_MACHINE\ntp\overrides]
"STime"=":"
"STFmt"="H:mm"

; STime STRING ":" - Time Separator
; STFmt STRING "h:mm:ss tt" - Time Format String
; S1159 STRING "am"
; S2359 STRING "pm"
; Time Format String
; h - Hours 12 Hour Clock with No Leading Zero
; hh - Hours 12 Hour Clock with Leading Zero
; H - Hours 24 Hour Clock with No Leading Zero
; HH - Hours 24 Hour Clock with Leading Zero
; m - Minutes with No Leading Zero
; mm - Minutes with Leading Zero
; s - Seconds with No Leading Zero
; ss - Seconds with Leading Zero
; t - am/pm indicator - First Letter Only
; tt - am/pm indicator - First Two Letters
; ttt - am/pm indicator - First Three Letters
```