




# TQMx110EB User's Manual

TQMx110EB UM 0101  
23.04.2025





## TABLE OF CONTENTS

|         |                                                         |    |
|---------|---------------------------------------------------------|----|
| 1.      | ABOUT THIS MANUAL .....                                 | 5  |
| 1.1     | Copyright and License Expenses .....                    | 5  |
| 1.2     | Registered Trademarks .....                             | 5  |
| 1.3     | Disclaimer .....                                        | 5  |
| 1.4     | Intended Use .....                                      | 5  |
| 1.5     | Imprint .....                                           | 6  |
| 1.6     | Service and Support .....                               | 6  |
| 1.7     | Tips on Safety .....                                    | 6  |
| 1.8     | Symbols and Typographic Conventions .....               | 6  |
| 1.9     | Handling and ESD Tips .....                             | 7  |
| 1.10    | Naming of Signals .....                                 | 7  |
| 1.11    | Further Applicable Documents / Presumed Knowledge ..... | 7  |
| 2.      | INTRODUCTION .....                                      | 8  |
| 2.1     | Overview .....                                          | 8  |
| 2.2     | Compliance .....                                        | 9  |
| 2.3     | Versions .....                                          | 9  |
| 2.4     | Accessories .....                                       | 12 |
| 3.      | FUNCTION .....                                          | 13 |
| 3.1     | Block Diagram .....                                     | 13 |
| 3.2     | Electrical Characteristics .....                        | 13 |
| 3.2.1   | Supply Voltage .....                                    | 13 |
| 3.2.2   | Power Consumption .....                                 | 14 |
| 3.2.3   | Real Time Clock Power Consumption .....                 | 16 |
| 3.3     | Environmental Conditions .....                          | 16 |
| 3.4     | System Components .....                                 | 17 |
| 3.4.1   | Processor .....                                         | 17 |
| 3.4.1.1 | Intel® Turbo Boost Technology .....                     | 19 |
| 3.4.1.2 | Intel® Configurable Thermal Design Power .....          | 19 |
| 3.4.2   | Graphics .....                                          | 19 |
| 3.4.3   | Chipset .....                                           | 19 |
| 3.4.4   | Memory .....                                            | 20 |
| 3.4.4.1 | DDR4 SDRAM SO-DIMM .....                                | 20 |
| 3.4.4.2 | M.2 BGA SSD .....                                       | 20 |
| 3.4.4.3 | SPI Boot Flash .....                                    | 20 |
| 3.4.4.4 | EEPROM .....                                            | 20 |
| 3.4.5   | Real Time Clock .....                                   | 21 |
| 3.4.6   | Trusted Platform Module .....                           | 21 |
| 3.4.7   | Hardware Monitor .....                                  | 21 |
| 3.4.8   | TQ Flexible I/O Configuration (TQ-flexiCFG) .....       | 21 |
| 3.4.9   | Ultra Deep Power State Green ECO-Off (optional) .....   | 21 |
| 3.5     | Interfaces .....                                        | 22 |
| 3.5.1   | PCI Express .....                                       | 22 |
| 3.5.2   | PCI Express for Graphics (PEG) .....                    | 22 |
| 3.5.3   | Gigabit Ethernet .....                                  | 23 |
| 3.5.4   | Serial ATA .....                                        | 23 |
| 3.5.5   | Digital Display Interface .....                         | 23 |
| 3.5.6   | LVDS / eDP Interface .....                              | 23 |
| 3.5.7   | USB Interfaces .....                                    | 24 |
| 3.5.8   | General Purpose Input / Output .....                    | 24 |
| 3.5.9   | High Definition Audio Interface .....                   | 24 |
| 3.5.10  | LPC / eSPI Bus .....                                    | 25 |
| 3.5.11  | I <sup>2</sup> C Bus .....                              | 25 |
| 3.5.12  | SMBus .....                                             | 25 |
| 3.5.13  | Serial Peripheral Interface .....                       | 25 |
| 3.5.14  | Serial Ports .....                                      | 26 |
| 3.5.15  | Watchdog Timer .....                                    | 26 |
| 3.6     | Connectors .....                                        | 27 |
| 3.6.1   | COM Express™ Connector .....                            | 27 |
| 3.6.2   | Debug Header .....                                      | 27 |
| 3.6.3   | TQM Debug Card .....                                    | 27 |
| 3.6.4   | Debug Module LED .....                                  | 28 |



|          |                                                                    |    |
|----------|--------------------------------------------------------------------|----|
| 3.7      | COM Express™ Connector Pinout .....                                | 29 |
| 3.7.1    | Signal Assignment Abbreviations .....                              | 29 |
| 3.7.2    | COM Express™ Connector Pin Assignment.....                         | 30 |
| 4.       | MECHANICS .....                                                    | 38 |
| 4.1      | Dimensions .....                                                   | 38 |
| 4.2      | Component Placement .....                                          | 39 |
| 4.3      | Heat Spreader .....                                                | 40 |
| 4.4      | Mechanical and Thermal Considerations.....                         | 40 |
| 4.5      | Protection against External Effects.....                           | 40 |
| 5.       | SOFTWARE .....                                                     | 41 |
| 5.1      | System Resources .....                                             | 41 |
| 5.1.1    | I²C Bus Devices.....                                               | 41 |
| 5.1.2    | SMBus Devices.....                                                 | 41 |
| 5.1.3    | Memory Mapping .....                                               | 41 |
| 5.1.4    | Interrupt Mapping .....                                            | 41 |
| 5.2      | Operating Systems .....                                            | 42 |
| 5.2.1    | Supported Operating Systems .....                                  | 42 |
| 5.2.2    | Driver Download.....                                               | 42 |
| 5.3      | TQ-Systems Embedded Application Programming Interface (EAPI) ..... | 42 |
| 5.4      | Software Tools .....                                               | 42 |
| 6.       | BIOS – MENU .....                                                  | 43 |
| 6.1      | Continue .....                                                     | 43 |
| 6.2      | Boot Manager .....                                                 | 43 |
| 6.3      | Device Manager .....                                               | 44 |
| 6.3.1    | Driver Health Manager.....                                         | 44 |
| 6.3.2    | Network Device List .....                                          | 44 |
| 6.4      | Boot from File.....                                                | 44 |
| 6.5      | Administer Secure Boot .....                                       | 44 |
| 6.6      | Setup Utility .....                                                | 45 |
| 6.6.1    | Main .....                                                         | 45 |
| 6.6.2    | Advanced .....                                                     | 46 |
| 6.6.2.1  | Boot Configuration.....                                            | 46 |
| 6.6.2.2  | SATA Configuration.....                                            | 46 |
| 6.6.2.3  | USB Configuration .....                                            | 47 |
| 6.6.2.4  | Chipset Configuration .....                                        | 47 |
| 6.6.2.5  | PCI Subsystem Settings.....                                        | 47 |
| 6.6.2.6  | ACPI Table/Features Control .....                                  | 48 |
| 6.6.2.7  | CPU Configuration.....                                             | 48 |
| 6.6.2.8  | Power & Performance.....                                           | 49 |
| 6.6.2.9  | Intel® Time Coordinated Computing.....                             | 52 |
| 6.6.2.10 | Memory Configuration.....                                          | 53 |
| 6.6.2.11 | System Agent (SA) Configuration .....                              | 53 |
| 6.6.2.12 | PCIe Configuration .....                                           | 57 |
| 6.6.2.13 | PCH-IO Configuration .....                                         | 57 |
| 6.6.2.14 | PCH-FW Configuration.....                                          | 61 |
| 6.6.2.15 | ACPI D3Cold settings.....                                          | 61 |
| 6.6.2.16 | SIO TQMx86 .....                                                   | 62 |
| 6.6.2.17 | SIO Hardware Monitor Nuvoton NCT7802Y .....                        | 63 |
| 6.6.2.18 | Console Redirection .....                                          | 64 |
| 6.6.2.19 | SIO F81214E .....                                                  | 65 |
| 6.6.3    | Security .....                                                     | 65 |
| 6.6.4    | Power.....                                                         | 65 |
| 6.6.5    | Boot.....                                                          | 65 |
| 6.6.6    | Exit.....                                                          | 66 |
| 7.       | BIOS – UPDATE .....                                                | 67 |
| 7.1.1    | Step 1: Preparing USB Stick.....                                   | 67 |
| 7.1.2    | Step 2: Preparing Management Engine (ME) FW for update .....       | 67 |
| 7.1.3    | Step 3a: Updating uEFI BIOS via EFI Shell.....                     | 69 |
| 7.1.4    | Step 3b: Updating uEFI BIOS via Windows Operating System .....     | 70 |
| 7.1.5    | Step 4: BIOS update check on the TQMx110EB Module .....            | 70 |
| 8.       | SAFETY REQUIREMENTS AND PROTECTIVE REGULATIONS.....                | 71 |
| 8.1      | EMC .....                                                          | 71 |
| 8.2      | ESD .....                                                          | 71 |
| 8.3      | Shock & Vibration .....                                            | 71 |
| 8.4      | Operational Safety and Personal Security .....                     | 71 |



|      |                                              |    |
|------|----------------------------------------------|----|
| 8.5  | Cyber Security.....                          | 71 |
| 8.6  | Export Control and Sanctions Compliance..... | 71 |
| 8.7  | Warranty .....                               | 71 |
| 8.8  | Reliability and Service Life.....            | 71 |
| 8.9  | RoHS.....                                    | 72 |
| 8.10 | WEEE® .....                                  | 72 |
| 8.11 | REACH® .....                                 | 72 |
| 8.12 | EuP.....                                     | 72 |
| 8.13 | Statement on California Proposition 65 ..... | 72 |
| 8.14 | Battery .....                                | 72 |
| 8.15 | Packaging.....                               | 72 |
| 8.16 | Other Entries.....                           | 72 |
| 9.   | APPENDIX.....                                | 74 |
| 9.1  | Acronyms and Definitions.....                | 74 |
| 9.2  | References.....                              | 76 |



## TABLE DIRECTORY

|           |                                                                                                  |    |
|-----------|--------------------------------------------------------------------------------------------------|----|
| Table 1:  | Terms and Conventions .....                                                                      | 6  |
| Table 2:  | TQMx110EB 11th Generation Intel® Core™ Embedded Series configurations and features.....          | 9  |
| Table 3:  | TQMx110EB 11th Generation Intel® XEON® H Embedded Series configurations and features .....       | 10 |
| Table 4:  | TQMx110EB 11th Generation Intel® XEON® H Low Power Embedded Series configurations and features.. | 11 |
| Table 5:  | TQMx110EB Power Consumption Turbo Mode ON.....                                                   | 15 |
| Table 6:  | TQMx110EB Power Consumption Turbo Mode OFF .....                                                 | 15 |
| Table 7:  | RTC Current Consumption.....                                                                     | 16 |
| Table 8:  | Operating Temperature .....                                                                      | 16 |
| Table 9:  | 11th Generation Intel® Core™ i7, i5, i3 Embedded Series .....                                    | 17 |
| Table 10: | 11th Generation Intel® XEON® Embedded Series .....                                               | 18 |
| Table 11: | 11th Generation Intel® XEON® Low Power Embedded Series.....                                      | 18 |
| Table 12: | Maximum Resolution Display Configuration.....                                                    | 19 |
| Table 13: | PCI Express port 0 – 7 Configuration Options .....                                               | 22 |
| Table 14: | Serial Port COM Express™ Port Mapping.....                                                       | 26 |
| Table 15: | LED Boot Messages.....                                                                           | 28 |
| Table 16: | Signal Assignment Abbreviations.....                                                             | 29 |
| Table 17: | COM Express™ Connector Pin Assignment .....                                                      | 30 |
| Table 18: | Labels on TQMx110EB.....                                                                         | 39 |
| Table 19: | I <sup>2</sup> C Address Mapping COM Express™ I <sup>2</sup> C Port .....                        | 41 |
| Table 20: | I <sup>2</sup> C Address Mapping COM Express™ SMBus Port .....                                   | 41 |
| Table 21: | Acronyms .....                                                                                   | 74 |
| Table 22: | Further Applicable Documents and Links .....                                                     | 76 |

## FIGURE DIRECTORY

|            |                                            |    |
|------------|--------------------------------------------|----|
| Figure 1:  | TQMx110EB block diagram .....              | 13 |
| Figure 2:  | TQM Debug Card.....                        | 27 |
| Figure 3:  | Debug Module LED.....                      | 28 |
| Figure 4:  | TQMx110EB three view drawing .....         | 38 |
| Figure 5:  | TQMx110EB Bottom View Drawing .....        | 38 |
| Figure 6:  | TQMx110EB Component Placement Top .....    | 39 |
| Figure 7:  | TQMx110EB Component Placement Bottom ..... | 39 |
| Figure 8:  | TQMx110EB-HSP Heat Spreader .....          | 40 |
| Figure 9:  | InsydeH2O BIOS Front Page.....             | 43 |
| Figure 10: | PCH-FW Configuration menu .....            | 68 |
| Figure 11: | Firmware Update Configuration menu .....   | 68 |
| Figure 12: | ME FW Image Re-Flash option.....           | 68 |
| Figure 13: | EFI Shell.....                             | 69 |
| Figure 14: | EFI Shell uEFI BIOS Update.....            | 69 |
| Figure 15: | Screen during BIOS Update.....             | 69 |
| Figure 16: | TQMx110EB Debug LED .....                  | 70 |
| Figure 17: | EFI BIOS Main Menu .....                   | 70 |

## REVISION HISTORY

| Rev. | Date       | Name    | Pos.                              | Modification                            |
|------|------------|---------|-----------------------------------|-----------------------------------------|
| 0100 | 11.03.2022 | KG      |                                   | First release                           |
| 0101 | 23.04.2025 | Kreuzer | 1.4, 8.5, 8.6, 8.7, 8.13<br>3.6.1 | Chapter adder<br>Connector source added |



## 1. ABOUT THIS MANUAL

### 1.1 Copyright and License Expenses

Copyright protected © 2025 by TQ-Systems GmbH.

This User's Manual may not be copied, reproduced, translated, changed or distributed, completely or partially in electronic, machine readable, or in any other form without the written consent of TQ-Systems GmbH.

The drivers and utilities for the components used as well as the BIOS are subject to copyrights of the respective manufacturers. The licence conditions of the respective manufacturer are to be adhered to.

BIOS-licence expenses are paid by TQ-Systems GmbH and are included in the price.

Licence expenses for the operating system and applications are not taken into consideration and have to be calculated/declared separately.

### 1.2 Registered Trademarks

TQ-Systems GmbH aims to adhere to copyrights of all graphics and texts used in all publications, and strives to use original or license-free graphics and texts.

All brand names and trademarks mentioned in this User's Manual, including those protected by a third party, unless specified otherwise in writing, are subjected to the specifications of the current copyright laws and the proprietary laws of the present registered proprietor without any limitation. One should conclude that brand and trademarks are rightly protected by a third party.

### 1.3 Disclaimer

TQ-Systems GmbH does not guarantee that the information in this User's Manual is up-to-date, correct, complete or of good quality. Nor does TQ-Systems GmbH assume guarantee for further usage of the information. Liability claims against TQ-Systems GmbH, referring to material or non-material related damages caused, due to usage or non-usage of the information given in this User's Manual, or due to usage of erroneous or incomplete information, are exempted, as long as there is no proven intentional or negligent fault of TQ-Systems GmbH.

TQ-Systems GmbH explicitly reserves the rights to change or add to the contents of this User's Manual or parts of it without special notification.

### 1.4 Intended Use

TQ DEVICES, PRODUCTS AND ASSOCIATED SOFTWARE ARE NOT DESIGNED, MANUFACTURED OR INTENDED FOR USE OR RESALE FOR THE OPERATION IN NUCLEAR FACILITIES, AIRCRAFT OR OTHER TRANSPORTATION NAVIGATION OR COMMUNICATION SYSTEMS, AIR TRAFFIC CONTROL SYSTEMS, LIFE SUPPORT MACHINES, WEAPONS SYSTEMS, OR ANY OTHER EQUIPMENT OR APPLICATION REQUIRING FAIL-SAFE PERFORMANCE OR IN WHICH THE FAILURE OF TQ PRODUCTS COULD LEAD TO DEATH, PERSONAL INJURY, OR SEVERE PHYSICAL OR ENVIRONMENTAL DAMAGE. (COLLECTIVELY, "HIGH RISK APPLICATIONS")

You understand and agree that your use of TQ products or devices as a component in your applications are solely at your own risk. To minimize the risks associated with your products, devices and applications, you should take appropriate operational and design related protective measures.

You are solely responsible for complying with all legal, regulatory, safety and security requirements relating to your products. You are responsible for ensuring that your systems (and any TQ hardware or software components incorporated into your systems or products) comply with all applicable requirements. Unless otherwise explicitly stated in our product related documentation, TQ devices are not designed with fault tolerance capabilities or features and therefore cannot be considered as being designed, manufactured or otherwise set up to be compliant for any implementation or resale as a device in high risk applications. All application and safety information in this document (including application descriptions, suggested safety precautions, recommended TQ products or any other materials) is for reference only. Only trained personnel in a suitable work area are permitted to handle and operate TQ products and devices. Please follow the general IT security guidelines applicable to the country or location in which you intend to use the equipment.





## 1.5 Imprint

TQ-Systems GmbH  
Gut Delling, Mühlstraße 2  
D-82229 Seefeld

Tel: +49 8153 9308-0  
Fax: +49 8153 9308-4223  
E-Mail: [Info@TQ-Group](mailto:Info@TQ-Group)  
Web: [TQ-Group](https://www.tq-group.com)

## 1.6 Service and Support

Please visit our website [www.tq-group.com](https://www.tq-group.com) for latest product documentation, drivers, utilities and technical support. You can register on our website [www.tq-group.com](https://www.tq-group.com) to have access to restricted information and automatic update services. For direct technical support you can contact our FAE team by email: [support@tq-group.com](mailto:support@tq-group.com). Our FAE team can also support you with additional information like 3D-STEP files and confidential information, which is not provided on our public website. For service/RMA, please contact our service team by email ([service@tq-group.com](mailto:service@tq-group.com)) or your sales team at TQ-Systems GmbH.

## 1.7 Tips on Safety

Improper or incorrect handling of the product can substantially reduce its life span.

## 1.8 Symbols and Typographic Conventions

Table 1: Terms and Conventions

| Symbol                                                                              | Meaning                                                                                                                                                                                                                                                                                         |
|-------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | This symbol represents the handling of electrostatic-sensitive modules and / or components. These components are often damaged / destroyed by the transmission of a voltage higher than about 50 V. A human body usually only experiences electrostatic discharges above approximately 3,000 V. |
|  | This symbol indicates the possible use of voltages higher than 24 V. Please note the relevant statutory regulations in this regard. Non-compliance with these regulations can lead to serious damage to your health and also cause damage / destruction of the component.                       |
|  | This symbol indicates a possible source of danger. Acting against the procedure described can lead to possible damage to your health and / or cause damage / destruction of the material used.                                                                                                  |
|  | This symbol represents important details or aspects for working with TQ-products.                                                                                                                                                                                                               |
| <b>Command</b>                                                                      | A font with fixed-width is used to denote commands, contents, file names, or menu items.                                                                                                                                                                                                        |

## 1.9 Handling and ESD Tips

### General handling of your TQ-products

|                                                                                   |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                               |
|-----------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <p>The TQ-product may only be used and serviced by certified personnel who have taken note of the information, the safety regulations in this document and all related rules and regulations.</p> <p>A general rule is: do not touch the TQ-product during operation. This is especially important when switching on, changing jumper settings or connecting other devices without ensuring beforehand that the power supply of the system has been switched off.</p> <p>Violation of this guideline may result in damage / destruction of the TQMx110EB and be dangerous to your health.</p> <p>Improper handling of your TQ-product would render the guarantee invalid.</p> |
|-----------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

### Proper ESD handling

|                                                                                   |                                                                                                                                                                                                                                                                                                                                          |
|-----------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|  | <p>The electronic components of your TQ-product are sensitive to electrostatic discharge (ESD).</p> <p>Always wear antistatic clothing, use ESD-safe tools, packing materials etc., and operate your TQ-product in an ESD-safe environment. Especially when you switch modules on, change jumper settings, or connect other devices.</p> |
|-----------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

## 1.10 Naming of Signals

A hash mark (#) at the end of the signal name indicates a low-active signal.

Example: RESET#

If a signal can switch between two functions and if this is noted in the name of the signal, the low-active function is marked with a hash mark and shown at the end.

Example: C / D#

If a signal has multiple functions, the individual functions are separated by slashes when they are important for the wiring.

The identification of the individual functions follows the above conventions.

Example: WE2# / OE#

## 1.11 Further Applicable Documents / Presumed Knowledge

- **Specifications and manual of the modules used:**  
These documents describe the service, functionality and special characteristics of the module used.
- **Specifications of the components used:**  
The manufacturer's specifications of the components used, for example CompactFlash cards, are to be taken note of. They contain, if applicable, additional information that has to be taken note of for safe and reliable operation. These documents are stored at TQ-Systems GmbH.
- **Chip errata:**  
It is the user's responsibility to make sure all errata published by the manufacturer of each component are taken note of. The manufacturer's advice should be followed.
- **Software behaviour:**  
No warranty can be given, nor responsibility taken for any unexpected software behaviour due to deficient components.
- **General expertise:**  
Expertise in electrical engineering / computer engineering is required for the installation and the use of the device.

Implementation information for the carrier board design is provided in the COM Express™ Design Guide (3), maintained by the PICMG®. This Carrier Design Guide includes a very good guideline to design a COM Express™ carrier board.

It includes detailed information with schematics and detailed layout guidelines.

Please refer to the official PICMG® documentation for additional information (2), (4).





## 2. INTRODUCTION

Based on the internationally established PICMG® standard COM Express™ (COM.0 R3.0), the TQMx110EB enables the design of not only powerful but also economical x86 based systems. The user has access to all essential interfaces of the CPU at the Type 6 compliant pin out connector. Hence all features of the 11th Generation Intel® Core™ and XEON® H can be used. The direct access to all interfaces gives the user the freedom to use the features of the CPU in the most suitable way for his application.

The compact and robust design as well as the option of conformal coating extends the use cases to applications within rugged industry, transportation and aviation environments. Based on the very low-power consumption and the extended temperature support it is also possible to realize outdoor applications in an easy and reliable way.

### 2.1 Overview

The following key functions are implemented on the TQMx110EB:

#### Processor:

11th Generation Intel® Core™ embedded series (TigerLake-H) with up to 8 processor cores

- Intel® Core™ i7-11850HE 8 × 2.6 GHz / 4.7 GHz Turbo, 24 MB Cache, 45 W (cTDP 35 W), 0 °C – 100 °C
- Intel® Core™ i5-11500HE 6 × 2.6 GHz / 4.5 GHz Turbo, 12 MB Cache, 45 W (cTDP 35 W), 0 °C – 100 °C
- Intel® Core™ i3-11100HE 4 × 2.4 GHz / 4.4 GHz Turbo, 8 MB Cache, 45 W (cTDP 35 W), 0 °C – 100 °C

11th Generation Intel® XEON® H embedded / industrial series (TigerLake-H) with up to 8 processor cores

- Intel® XEON® W-11865MRE 8 × 2.6 GHz / 4.7 GHz Turbo, 24 MB Cache, 45 W (cTDP 35 W), -40 °C – 100 °C
- Intel® XEON® W-11555MRE 6 × 2.6 GHz / 4.5 GHz Turbo, 12 MB Cache, 45 W (cTDP 35 W), -40 °C – 100 °C
- Intel® XEON® W-11155MRE 4 × 2.4 GHz / 4.4 GHz Turbo, 8 MB Cache, 45 W (cTDP 35 W), -40 °C – 100 °C

11th Generation Intel® XEON® H low power embedded / industrial series (TigerLake-H) with up to 8 processor cores

- Intel® XEON® W-11865MLE 8 × 1.5 GHz / 4.5 GHz Turbo, 24 MB Cache, 25 W, 0 °C – 100 °C
- Intel® XEON® W-11555MLE 6 × 1.9 GHz / 4.4 GHz Turbo, 12 MB Cache, 25 W, 0 °C – 100 °C
- Intel® XEON® W-11155MLE 4 × 1.8 GHz / 3.1 GHz Turbo, 8 MB Cache, 25 W, 0 °C – 100 °C

#### Memory:

- 2 × DDR4 SO-DIMM socket with max. 64 Gbyte, dual channel DDR4 up to 3200 MT/s SO-DIMM modules (optionally with ECC support, only on Intel® XEON® H CPU type)
- M.2 BGA SSD with PCIe Gen 3 x4 up to 1 Tbyte
- Support of Intel® Optane™ memory technology via PCIe
- EEPROM: 32 kbit (24AA32) (optional)

#### Graphics:

- 3 × Digital Display Interface / DP++ with up to 8K; DisplayPort 1.4a with support for Multi-Stream Transport (MST)
- 1 × Embedded Digital Display Interface (eDP) or dual channel LVDS interface (eDP 1.4b or dual LVDS)

#### Peripheral interfaces:

- 1 × 2.5 Gigabit Ethernet (Intel® i225)
- 4 × USB 3.2 Gen 2 (up to 10 Gb/s) with USB 3.0 compatibility
- 8 × USB 2.0
- 4 × SATA Gen 3 (up to 6 Gb/s) or 4x PCIe Gen 3 (up to 8 Gb/s)
- 8 × PCIe Gen 3 (up to 8 Gb/s) (8 (×1), 4 (×2), or 2 (×4))
- 1 × PCIe PEG port Gen 4 (up to 16 Gb/s) (1 (×16), 2 (×8), or 2 (×4) + 1 (×8))
- 1 × LPC or eSPI bus
- 1 × Intel® HD audio (HDA)
- 1 × I<sup>2</sup>C (2<sup>nd</sup> I<sup>2</sup>C optional) (master/slave capable)
- 1 × SMBus
- 1 × SPI (for external uEFI BIOS flash)
- 2 × Serial port (Rx/Tx, legacy compatible), 4-wire (Rx/Tx/RTS/CTS) optionally through TQ-flexiCFG
- 8 × GPIO through TQ-flexiCFG

#### Security components:

- TPM discrete SLB9670 TPM 2.0 controller or internal firmware TPM (FTPM)

**Others:**

- TQMx86 board controller with Watchdog and TQ-flexiCFG
- Hardware monitor

**Power supply voltage:**

- Nominal voltage 12 V (11.4 V to 12.6 V)
- 5 V Standby (optional) 5 V (4.75 V to 5.25 V)
- 3 V Battery for RTC

**Environment:**

- Operating Standard temperature: 0 °C to +60 °C
- Operating Extended temperature: –40 °C to +75 °C
- Storage temperature: –40 °C to +85 °C
- Relative humidity (operation): 10 % to 90 % (non-condensing)
- Relative humidity (storage): 5 % to 95 % (non-condensing, with conformal coating)

**Form factor / dimensions:**

- COMExpress™ Basic, Type 6, 125 × 95 mm<sup>2</sup>

## 2.2 Compliance

The TQMx110EB complies with PICMG® COM Express™ Module Base Specification (COM.0 R3.0).

## 2.3 Versions

The TQMx110EB is available in several standard configurations

Table 2: TQMx110EB 11th Generation Intel® Core™ Embedded Series configurations and features

| Feature               | TQMx110EB-AA                                                 | TQMx110EB-AB                                                 | TQMx110EB-AC                                                 |
|-----------------------|--------------------------------------------------------------|--------------------------------------------------------------|--------------------------------------------------------------|
| CPU                   | 8-core                                                       | 6-core                                                       | 4- Core                                                      |
| Intel                 | Core™ i7-11850HE                                             | Core™ i5-11500HE                                             | Core™ i3-11500HE                                             |
| CPU TDP               | 45 / 35 W                                                    | 45 / 35 W                                                    | 45 / 35 W                                                    |
| CPU Clock (Base)      | 2.4 GHz                                                      | 2.6 GHz                                                      | 2.4 GHz                                                      |
| L2 Cache              | 24 MB                                                        | 12 MB                                                        | 8 MB                                                         |
| Heat spreader         | TQMx110EB-HSP-AA                                             | TQMx110EB-HSP-AA                                             | TQMx110EB-HSP-AA                                             |
| Heatsink incl. fan    | TQMx110EB-KK-AA                                              | TQMx110EB-KK-AA                                              | TQMx110EB-KK-AA                                              |
| DRAM / SO-DIMM        | 16 / 32 / 64 GB                                              | 16 / 32 / 64 GB                                              | 16 / 32 / 64 GB                                              |
| DRAM / ECC            | no                                                           | no                                                           | no                                                           |
| Use Condition         | Embedded                                                     | Embedded                                                     | Embedded                                                     |
| Operating Temperature | 0 °C to +60 °C (Turbo ON)<br>0 °C to +75 °C (35 W Turbo OFF) | 0 °C to +60 °C (Turbo ON)<br>0 °C to +75 °C (35 W Turbo OFF) | 0 °C to +60 °C (Turbo ON)<br>0 °C to +75 °C (35 W Turbo OFF) |
| M.2 BGA SSD PCIe x4   | --                                                           | --                                                           | --                                                           |
| TPM 2.0               | 1                                                            | 1                                                            | 1                                                            |
| Independent displays  | 4                                                            | 4                                                            | 4                                                            |
| LVDS or eDP           | 1                                                            | 1                                                            | 1                                                            |
| DP or HDMI            | 3                                                            | 3                                                            | 3                                                            |
| 2.5 GbE               | 1                                                            | 1                                                            | 1                                                            |
| USB 2.0 host          | 8                                                            | 8                                                            | 8                                                            |
| USB 3.2 host          | 4                                                            | 4                                                            | 4                                                            |
| SATA Gen 3            | 4                                                            | 4                                                            | 4                                                            |
| PCIe Gen 3 x1         | 8                                                            | 8                                                            | 8                                                            |
| PEG Gen 4 x16         | 1                                                            | 1                                                            | 1                                                            |
| I2C / SPI             | 1 / 1                                                        | 1 / 1                                                        | 1 / 1                                                        |
| HDA                   | 1                                                            | 1                                                            | 1                                                            |
| LPC or eSPI           | 1                                                            | 1                                                            | 1                                                            |
| UART / GPIO           | 2 / 8                                                        | 2 / 8                                                        | 2 / 8                                                        |



Table 3: TQMx110EB 11th Generation Intel® XEON® H Embedded Series configurations and features

| Feature               | TQMx110EB-AD                                                     | TQMx110EB-AE                                                     | TQMx110EB-AF                                                     |
|-----------------------|------------------------------------------------------------------|------------------------------------------------------------------|------------------------------------------------------------------|
| CPU                   | 8-core                                                           | 6-core                                                           | 4- Core                                                          |
| Intel                 | XEON® W-11865MRE                                                 | XEON® W-11555MRE                                                 | XEON® W-11155MRE                                                 |
| CPU TDP               | 45 / 35 W                                                        | 45 / 35 W                                                        | 45 / 35 W                                                        |
| CPU Clock (Base)      | 2.4 GHz                                                          | 2.6 GHz                                                          | 2.4 GHz                                                          |
| L2 Cache              | 24 MB                                                            | 12 MB                                                            | 8 MB                                                             |
| Heat spreader         | TQMx110EB-HSP-AA                                                 | TQMx110EB-HSP-AA                                                 | TQMx110EB-HSP-AA                                                 |
| Heatsink incl. fan    | TQMx110EB-KK-AA                                                  | TQMx110EB-KK-AA                                                  | TQMx110EB-KK-AA                                                  |
| DRAM / SO-DIMM        | 16 / 32 / 64 GB                                                  | 16 / 32 / 64 GB                                                  | 16 / 32 / 64 GB                                                  |
| DRAM / ECC            | Yes                                                              | Yes                                                              | Yes                                                              |
| Use Condition         | Embedded w/Turbo ON<br>Industrial w/Turbo OFF                    | Embedded w/Turbo ON<br>Industrial w/Turbo OFF                    | Embedded w/Turbo ON<br>Industrial w/Turbo OFF                    |
| Operating Temperature | -40 °C to +60 °C (Turbo ON)<br>-40 °C to +75 °C (35 W Turbo OFF) | -40 °C to +60 °C (Turbo ON)<br>-40 °C to +75 °C (35 W Turbo OFF) | -40 °C to +60 °C (Turbo ON)<br>-40 °C to +75 °C (35 W Turbo OFF) |
| M.2 BGA SSD PCIe x4   | --                                                               | --                                                               | --                                                               |
| TPM 2.0               | 1                                                                | 1                                                                | 1                                                                |
| Independent displays  | 4                                                                | 4                                                                | 4                                                                |
| LVDS or eDP           | 1                                                                | 1                                                                | 1                                                                |
| DP or HDMI            | 3                                                                | 3                                                                | 3                                                                |
| 2.5 GbE               | 1                                                                | 1                                                                | 1                                                                |
| USB 2.0 host          | 8                                                                | 8                                                                | 8                                                                |
| USB 3.2 host          | 4                                                                | 4                                                                | 4                                                                |
| SATA Gen 3            | 4                                                                | 4                                                                | 4                                                                |
| PCIe Gen 3 x1         | 8                                                                | 8                                                                | 8                                                                |
| PEG Gen 4 x16         | 1                                                                | 1                                                                | 1                                                                |
| I2C / SPI             | 1 / 1                                                            | 1 / 1                                                            | 1 / 1                                                            |
| HDA                   | 1                                                                | 1                                                                | 1                                                                |
| LPC or eSPI           | 1                                                                | 1                                                                | 1                                                                |
| UART / GPIO           | 2 / 8                                                            | 2 / 8                                                            | 2 / 8                                                            |



Table 4: TQMx110EB 11th Generation Intel® XEON® H Low Power Embedded Series configurations and features

| Feature               | TQMx110EB-AG                                              | TQMx110EB-AH                                             | TQMx110EB-AI                                             |
|-----------------------|-----------------------------------------------------------|----------------------------------------------------------|----------------------------------------------------------|
| CPU                   | 8-core                                                    | 6-core                                                   | 4- Core                                                  |
| Intel                 | XEON® W-11865MLE                                          | XEON® W-11555MLE                                         | XEON® W-11155MLE                                         |
| CPU TDP               | 25 W                                                      | 25 W                                                     | 25 W                                                     |
| CPU Clock (Base)      | 1.5 GHz                                                   | 1.9 GHz                                                  | 1.8 GHz                                                  |
| L2 Cache              | 24 MB                                                     | 12 MB                                                    | 8 MB                                                     |
| Heat spreader         | TQMx110EB-HSP-AA                                          | TQMx110EB-HSP-AA                                         | TQMx110EB-HSP-AA                                         |
| Heatsink incl. fan    | TQMx110EB-KK-AA                                           | TQMx110EB-KK-AA                                          | TQMx110EB-KK-AA                                          |
| DRAM / SO-DIMM        | 16 / 32 / 64 GB                                           | 16 / 32 / 64 GB                                          | 16 / 32 / 64 GB                                          |
| DRAM / ECC            | Yes                                                       | Yes                                                      | Yes                                                      |
| Use Condition         | Embedded w/Turbo ON<br>Industrial w/Turbo OFF             | Embedded w/Turbo ON<br>Industrial w/Turbo OFF            | Embedded w/Turbo ON<br>Industrial w/Turbo OFF            |
| Operating Temperature | 0 °C to +60 °C (Turbo ON)<br>0 °C to +75 °C (Turbo OFF) * | 0 °C to +60 °C (Turbo ON)<br>0 °C to +75 °C (Turbo OFF)* | 0 °C to +60 °C (Turbo ON)<br>0 °C to +75 °C (Turbo OFF)* |
| M.2 BGA SSD PCIe x4   | --                                                        | --                                                       | --                                                       |
| TPM 2.0               | 1                                                         | 1                                                        | 1                                                        |
| Independent displays  | 4                                                         | 4                                                        | 4                                                        |
| LVDS or eDP           | 1                                                         | 1                                                        | 1                                                        |
| DP or HDMI            | 3                                                         | 3                                                        | 3                                                        |
| 2.5 GbE               | 1                                                         | 1                                                        | 1                                                        |
| USB 2.0 host          | 8                                                         | 8                                                        | 8                                                        |
| USB 3.2 host          | 4                                                         | 4                                                        | 4                                                        |
| SATA Gen 3            | 4                                                         | 4                                                        | 4                                                        |
| PCIe Gen 3 x1         | 8                                                         | 8                                                        | 8                                                        |
| PEG Gen 4 x16         | 1                                                         | 1                                                        | 1                                                        |
| I2C / SPI             | 1 / 1                                                     | 1 / 1                                                    | 1 / 1                                                    |
| HDA                   | 1                                                         | 1                                                        | 1                                                        |
| LPC or eSPI           | 1                                                         | 1                                                        | 1                                                        |
| UART / GPIO           | 2 / 8                                                     | 2 / 8                                                    | 2 / 8                                                    |

\*optional -40° C to +75 °C with screening

Please refer to [www.tq-group.com/](http://www.tq-group.com/) for a full list of standard versions.

Other configurations are available on request.

Hardware and software configuration features on request:

- Conformal coating
- Customized BIOS
- Ultra-deep power state Green ECO-Off feature



## 2.4 Accessories

- **TQMx110EB-HSP**

Heat spreader for TQMx110EB, according to COM Express™ specification.

- **Evaluation platform MB-COME6-4**

Mainboard for COM Express™ Basic and Compact, Type 6, 170 × 170 mm<sup>2</sup>, with the following interfaces:

- 3 × DP (2x up to 8k HBR3, 1x up to 4k HBR2)
- 1 x dual LVDS
- 1 x eDP (up to 4k HBR2)
- 2 × 2.5 Gbit Ethernet
- 2 x USB 3.2 USB-A
- 1 x USB 3.2 USB-C
- 3 x USB 2.0 internal
- 2 × Serial Port RS232
- 1x High Definition Audio (Line In, MIC In, HP Out)
- 1x M.2 Socket Key E (Wi-Fi/BT),
- 1x M.2 Socket Key B with μSIM (WWAN or SATA SSD)
- 1x M.2 Socket Key M PCIe x4 (SSD)
- 1x M.2 Socket Key M PCIe x2 (SSD)
- 1x PCIExpress x16 PEG port
- 1x SATA connector
- Fan header
- Debug header

- **Debug module**

POST debug card for TQMx110EB, see 3.6.3.

### 3. FUNCTION

#### 3.1 Block Diagram

The following figure shows the TQMx110EB block diagram.




Figure 1: TQMx110EB block diagram

#### 3.2 Electrical Characteristics

##### 3.2.1 Supply Voltage

The TQMx110EB supports a voltage inputs from 11.4 V to 12.6 V.

The following supply voltages are specified at the COM Express™ connector:

|                 |                  |                       |         |
|-----------------|------------------|-----------------------|---------|
| Standard input: | 11.4 V to 12.6 V | maximum input ripple: | ±100 mV |
| VCC_5V_SBY:     | 4.75 V to 5.25 V | maximum input ripple: | ±50 mV  |
| VCC_RTC:        | 2.0 V to 3.3 V   | maximum input ripple: | ±20 mV  |

The input voltages shall rise from 10 % to 90 % of nominal within 0.1 ms to 20 ms ( $0.1 \text{ ms} \leq \text{Rise Time} \leq 20 \text{ ms}$ ).

The increase of each DC output voltage has to be smooth and continuous from 10 % to 90 % of its final set point within the regulation range.

Note: Power source



For single supply operations, the 5 V Standby voltage is not required.  
VCC\_5V\_SBY can be left unconnected.



### 3.2.2 Power Consumption

The power consumption values below show the TQMx110EB voltage and power specifications.

The values were measured with two power supplies; one for the TQMx110EB and the other one for the MB-COME6-4 COM Express™ carrier board.

The power consumption of each TQMx110EB version was measured running Windows® 10, 64-bit and a dual DDR4 SO-DIMM configuration (2 × 16 Gbyte). All measurements were done at a temperature of +25 °C and an input voltage of +12 V.

The power consumption of the TQMx110EB depends on the application, the mode of operation and the operating system.

The power consumption was measured under the following test modes:

- **Green ECO-Off state:**  
The system is in Green ECO-Off state, all DC/DC power supplies on the TQMx110EB are switched off.
- **Suspend mode:**  
The system is in S5/S4 state, Ethernet port is disconnected.
- **Windows® 10, 64-bit, idle state:**  
Desktop idle state, Ethernet port is disconnected.
- **Windows® 10, 64-bit, maximum workload (cTDP down mode enabled):**  
These values show the maximum cTDP down power consumption using the Intel® stress test tool to stress the processor and graphic engine. Ethernet port is connected (1000Base-T Speed).
- **Windows® 10, 64-bit, maximum workload (nominal configuration):**  
These values show the maximum worst case power consumption using the Intel® stress test tool to stress the processor and graphic engine. Ethernet port is connected (1000Base-T Speed).
- **Windows® 10, 64-bit, maximum workload (turbo mode first 28 seconds)**  
These values show the maximum worst case power consumption using the Intel® stress test tool to stress the processor and graphic engine. This value was measured only for a short time (28 s) when the processor is in the turbo mode. This value should be used for designing the power supply for the TQMx110EB. Ethernet port is connected (1000Base-T Speed).



The following table shows the TQMx110EB power consumption with different CPUs.

Table 5: TQMx110EB Power Consumption **Turbo Mode ON**

| CPU        | Mode                |         |                    |                                   |                                 |                                     |
|------------|---------------------|---------|--------------------|-----------------------------------|---------------------------------|-------------------------------------|
|            | Standby 5 V         |         | Input 12 V         |                                   |                                 |                                     |
|            | Green ECO-Off state | Suspend | Win10, 64-bit idle | Win10, 64-bit cTDP down max. load | Win10, 64-bit nominal max. load | Win10, 64-bit Max load (Turbo mode) |
| i7-11850HE | 3.5 mW              | 400 mW  | 12 W               | 52 W                              | 63 W                            | 127 W                               |
| i5-11500HE | 3.5 mW              | 400 mW  | 11 W               | 46 W                              | 58 W                            | 87 W                                |
| i3-11100HE | 3.5 mW              | 400 mW  | 11 W               | 45 W                              | 55 W                            | 73 W                                |
| W-11865MRE | 3.5 mW              | 400 mW  | 12 W               | 52 W                              | 63 W                            | 127 W                               |
| W-11555MRE | 3.5 mW              | 400 mW  | 11 W               | 46 W                              | 58 W                            | 87 W                                |
| W-11155MRE | 3.5 mW              | 400 mW  | 11 W               | 45 W                              | 55 W                            | 73 W                                |
| W-11865MLE | 3.5 mW              | 400 mW  | 11 W               | --                                | 37 W                            | 111 W                               |
| W-11555MLE | 3.5 mW              | 400 mW  | 10 W               | --                                | 36 W                            | 86 W                                |
| W-11155MLE | 3.5 mW              | 400 mW  | 10 W               | --                                | 34 W                            | 71 W                                |

Table 6: TQMx110EB Power Consumption **Turbo Mode OFF**

| CPU        | Mode                |         |                    |                                   |                                 |                                     |
|------------|---------------------|---------|--------------------|-----------------------------------|---------------------------------|-------------------------------------|
|            | Standby 5 V         |         | Input 12 V         |                                   |                                 |                                     |
|            | Green ECO-Off state | Suspend | Win10, 64-bit idle | Win10, 64-bit cTDP down max. load | Win10, 64-bit nominal max. load | Win10, 64-bit Max load (Turbo mode) |
| i7-11850HE | 3.5 mW              | 400 mW  | 12 W               | 40 W                              | 51 W                            | --                                  |
| i5-11500HE | 3.5 mW              | 400 mW  | 11 W               | 37 W                              | 47 W                            | --                                  |
| i3-11100HE | 3.5 mW              | 400 mW  | 11 W               | 36 W                              | 46 W                            | --                                  |
| W-11865MRE | 3.5 mW              | 400 mW  | 12 W               | 40 W                              | 51 W                            | --                                  |
| W-11555MRE | 3.5 mW              | 400 mW  | 11 W               | 37 W                              | 47 W                            | --                                  |
| W-11155MRE | 3.5 mW              | 400 mW  | 11 W               | 36 W                              | 46 W                            | --                                  |
| W-11865MLE | 3.5 mW              | 400 mW  | 11 W               | --                                | 30 W                            | --                                  |
| W-11555MLE | 3.5 mW              | 400 mW  | 10 W               | --                                | 29 W                            | --                                  |
| W-11155MLE | 3.5 mW              | 400 mW  | 10 W               | --                                | 28 W                            | --                                  |

**Note: Power requirement**



The power supplies on the carrier board for the TQMx110EB have to be designed with enough reserve. The carrier board should be able to provide at least twice the maximum TQMx110EB workload power. The TQMx110EB supports several low-power states. The carrier board power supply has to be stable, even with no load.

Carrier power supply example:

Processor i7-11850HE max. load Turbo ON Power Consumption = 127 W **carrier power design 200 W**

Processor i7-11850HE max. load Turbo OFF Power Consumption = 51 W **carrier power design 100 W**

### 3.2.3 Real Time Clock Power Consumption

The RTC (VCC\_RTC) current consumption is shown below.

The values were measured at +25 °C under battery operating conditions.

Table 7: RTC Current Consumption

| Mode                                                           | Voltage | Current |
|----------------------------------------------------------------|---------|---------|
| 11th Generation Intel® Core™ and XEON® H series integrated RTC | 3.0 V   | 2 µA    |

The current consumption of the RTC in the 11th Generation Intel® Core™ and XEON® H series Product Family Datasheet is specified with 6 µA in average, but the measured values on several TQMx110EB are lower.

### 3.3 Environmental Conditions

- Operating Standard temperature: 0 °C to +60 °C
- Operating Extended temperature: -40 °C to +75 °C
- Storage temperature: -40 °C to +85 °C
- Relative humidity (operating): 10 % to 90 % (non-condensing)
- Relative humidity (storage): 5 % to 95 % (non-condensing)

Table 8: Operating Temperature

| CPU        | 0 °C to +60 °C  | 0 °C to +75 °C   | -40 °C to +60 °C          | -40 °C to +75 °C          |
|------------|-----------------|------------------|---------------------------|---------------------------|
| i7-11850HE | 45 W / Turbo ON | 35 W / Turbo OFF | --                        | --                        |
| i5-11500HE | 45 W / Turbo ON | 35 W / Turbo OFF | --                        | --                        |
| i3-11100HE | 45 W / Turbo ON | 35 W / Turbo OFF | --                        | --                        |
| W-11865MRE | 45 W / Turbo ON | 35 W / Turbo OFF | 45 W / Turbo ON           | 35 W / Turbo OFF          |
| W-11555MRE | 45 W / Turbo ON | 35 W / Turbo OFF | 45 W / Turbo ON           | 35 W / Turbo OFF          |
| W-11155MRE | 45 W / Turbo ON | 35 W / Turbo OFF | 45 W / Turbo ON           | 35 W / Turbo OFF          |
| W-11865MLE | 25 W / Turbo ON | 25 W / Turbo OFF | (optional with screening) | (optional with screening) |
| W-11555MLE | 25 W / Turbo ON | 25 W / Turbo OFF | (optional with screening) | (optional with screening) |
| W-11155MLE | 25 W / Turbo ON | 25 W / Turbo OFF | (optional with screening) | (optional with screening) |

#### Attention: Maximum operating temperature



Do not operate the TQMx110EB without properly attached heat spreader and heat sink.  
The heat spreader is not a sufficient heat sink.



### 3.4 System Components

#### 3.4.1 Processor

The TQMx110EB supports the 11th Generation Intel® Core™ and XEON® H processor series (TigerLake-H).

The following list illustrates some key features of the 11th Generation Intel® Core™ and XEON® H processor series:

- 8-core, 6-core and 4-core processor cores
- 10nm SuperFin technology processor up to 24MB LLC / 14nm PCH
- DDR4 up to 3200 MT/s optional with ECC (XEON® H versions only)
- Intel® Hyper-Threading Technology (Intel® HT Technology)
- Intel® Advanced Vector Extensions 512 Bit (Intel® AVX-512)
- Intel® Transactional Synchronization Extensions (Intel® TSX-NI)
- Intel® 64 Architecture
- Intel® Turbo Boost Max Technology 3.0
- Intel® Configurable Thermal Design Power (Intel® cTDP down)
- Intel® Enhanced Intel® SpeedStep® technology
- Intel® Iris®Xe Graphics
- High Definition Content Protection (HDCP) 2.3
- Four independent displays

Table 9: 11th Generation Intel® Core™ i7, i5, i3 Embedded Series

| Mode                                          | Core™<br>i7-11850HE     | Core™<br>i5-11500HE     | Core™<br>i3-11100HE     |
|-----------------------------------------------|-------------------------|-------------------------|-------------------------|
| Processor Cores / Threads                     | 8 / 16                  | 6 / 12                  | 4 / 8                   |
| Cache                                         | 24 Mbyte                | 12 Mbyte                | 8 Mbyte                 |
| Core Base frequency                           | 2.6 GHz                 | 2.6 GHz                 | 2.4 GHz                 |
| Core Base frequency (cTDP down)               | 2.1 GHz                 | 2.1 GHz                 | 1.9 GHz                 |
| Core Max. Turbo frequency                     | 4.7 GHz                 | 4.5 GHz                 | 4.4 GHz                 |
| T <sub>junction</sub>                         | 0 °C to +100 °C         | 0 °C to +100 °C         | 0 °C to +100 °C         |
| Memory speed DDR4                             | 3200 MT/s               | 3200 MT/s               | 3200 MT/s               |
| Max. memory                                   | 64 Gbyte                | 64 Gbyte                | 64 Gbyte                |
| Memory configuration                          | Dual, no ECC            | Dual, no ECC            | Dual, no ECC            |
| Graphics                                      | Intel® Iris®Xe Graphics | Intel® Iris®Xe Graphics | Intel® Iris®Xe Graphics |
| Graphics Execution Units                      | 32                      | 32                      | 16                      |
| Graphics Base frequency                       | 0.35 GHz                | 0.35 GHz                | 0.35 GHz                |
| Graphics Turbo frequency                      | 1.35 GHz                | 1.35 GHz                | 1.25 GHz                |
| Thermal Design Power (TDP nominal)            | 45 W                    | 45 W                    | 45 W                    |
| Configurable Thermal Design Power (cTDP down) | 35 W                    | 35 W                    | 35 W                    |
| Processor Power Limit 2 (PL2)                 | 109 W                   | 83 W                    | 65 W                    |
| Intel® Hyper-Threading Technology             | Yes                     | Yes                     | Yes                     |
| Intel® Turbo Boost Technology                 | Yes                     | Yes                     | Yes                     |
| TSN support                                   | No                      | No                      | No                      |
| Chipset                                       | HM570E                  | HM570E                  | HM570E                  |

Table 10: 11th Generation Intel® XEON® Embedded Series

| Mode                                          | XEON®<br>W-11865MRE     | XEON®<br>W-11555MRE     | XEON®<br>W-11155MRE     |
|-----------------------------------------------|-------------------------|-------------------------|-------------------------|
| Processor Cores / Threads                     | 8 / 16                  | 6 / 12                  | 4 / 8                   |
| Cache                                         | 24 Mbyte                | 12 Mbyte                | 8 Mbyte                 |
| Core Base frequency                           | 2.6 GHz                 | 2.6 GHz                 | 2.4 GHz                 |
| Core Base frequency (cTDP down)               | 2.1 GHz                 | 2.1 GHz                 | 1.9 GHz                 |
| Core Max. Turbo frequency                     | 4.7 GHz                 | 4.5 GHz                 | 4.4 GHz                 |
| T <sub>junction</sub>                         | -40 °C to +100 °C       | -40 °C to +100 °C       | -40 °C to +100 °C       |
| Memory speed DDR4                             | 3200 MT/s               | 3200 MT/s               | 3200 MT/s               |
| Max. memory                                   | 64 Gbyte                | 64 Gbyte                | 64 Gbyte                |
| Memory configuration                          | Dual, with ECC          | Dual, with ECC          | Dual, with ECC          |
| Graphics                                      | Intel® Iris®Xe Graphics | Intel® Iris®Xe Graphics | Intel® Iris®Xe Graphics |
| Graphics Execution Units                      | 32                      | 32                      | 16                      |
| Graphics Base frequency                       | 0.35 GHz                | 0.35 GHz                | 0.35 GHz                |
| Graphics Turbo frequency                      | 1.35 GHz                | 1.35 GHz                | 1.25 GHz                |
| Thermal Design Power (TDP nominal)            | 45 W                    | 45 W                    | 45 W                    |
| Configurable Thermal Design Power (cTDP down) | 35 W                    | 35 W                    | 35 W                    |
| Processor Power Limit 2 (PL2)                 | 109 W                   | 83 W                    | 65 W                    |
| Intel® Hyper-Threading Technology             | Yes                     | Yes                     | Yes                     |
| Intel® Turbo Boost Technology                 | Yes                     | Yes                     | Yes                     |
| TSN support                                   | Yes                     | Yes                     | Yes                     |
| Chipset                                       | RM590E                  | RM590E                  | RM590E                  |

Table 11: 11th Generation Intel® XEON® Low Power Embedded Series

| Mode                                          | XEON®<br>W-11865MLE     | XEON®<br>W-11555MLE     | XEON®<br>W-11155MLE     |
|-----------------------------------------------|-------------------------|-------------------------|-------------------------|
| Processor Cores / Threads                     | 8 / 16                  | 6 / 12                  | 4 / 8                   |
| Cache                                         | 24 Mbyte                | 12 Mbyte                | 8 Mbyte                 |
| Core Base frequency                           | 1.5 GHz                 | 1.9 GHz                 | 1.8 GHz                 |
| Core Base frequency (cTDP down)               | --                      | --                      | --                      |
| Core Max. Turbo frequency                     | 4.5 GHz                 | 4.4 GHz                 | 3.1 GHz                 |
| T <sub>junction</sub>                         | 0 °C to +100 °C         | 0 °C to +100 °C         | 0 °C to +100 °C         |
| Memory speed DDR4                             | 3200 MT/s               | 3200 MT/s               | 3200 MT/s               |
| Max. memory                                   | 64 Gbyte                | 64 Gbyte                | 64 Gbyte                |
| Memory configuration                          | Dual, with ECC          | Dual, with ECC          | Dual, with ECC          |
| Graphics                                      | Intel® Iris®Xe Graphics | Intel® Iris®Xe Graphics | Intel® Iris®Xe Graphics |
| Graphics Execution Units                      | 32                      | 32                      | 16                      |
| Graphics Base frequency                       | 0.35 GHz                | 0.35 GHz                | 0.35 GHz                |
| Graphics Turbo frequency                      | 1.35 GHz                | 1.35 GHz                | 1.25 GHz                |
| Thermal Design Power (TDP nominal)            | 25 W                    | 25 W                    | 25 W                    |
| Configurable Thermal Design Power (cTDP down) | --                      | --                      | --                      |
| Processor Power Limit 2 (PL2)                 | 109 W                   | 89 W                    | 57 W                    |
| Intel® Hyper-Threading Technology             | Yes                     | Yes                     | Yes                     |
| Intel® Turbo Boost Technology                 | Yes                     | Yes                     | Yes                     |
| TSN support                                   | Yes                     | Yes                     | Yes                     |
| Chipset                                       | RM590E                  | RM590E                  | RM590E                  |

### 3.4.1.1 Intel® Turbo Boost Technology

Intel® Turbo Boost Technology accelerates processor and graphics performance for peak loads, automatically allowing processor cores to run faster than the rated operating frequency if they are operating below power, current, and temperature specification limits. Whether the processor enters into Intel® Turbo Boost Technology and the amount of time the processor spends in that state depends on the workload and operating environment.

The Intel® Turbo Boost Technology allows the processor to operate at a power level that is higher than its Thermal Design Power (TDP) configuration for short durations to maximize performance.

The Intel® Turbo Boost Technology can be configured in the uEFI BIOS, the default setting is "enabled".

Only the Intel® Core™ i7, i5, i3 and XEON® processors support Intel® Turbo Boost Technology.

### 3.4.1.2 Intel® Configurable Thermal Design Power

The Intel® Configurable Thermal Design Power (cTDP) feature allows adjustment of the processor power consumption.

The cTDP consists of three modes:

1. The cTDP nominal mode specifies the processor rated frequency and power consumption.
2. The cTDP down mode specifies a lower processor power consumption and lower guaranteed frequency versus the nominal mode. This mode can be selected for ultra low-power applications, e.g. systems with reduced cooling solutions.

The cTDP up feature (35 W) is only available on the 11th Generation Intel® Core™ and XEON® H processor versions with 45 W TDP. The cTDP function can be configured in the uEFI BIOS. The default setting is "nominal".

## 3.4.2 Graphics

The 11th Generation Intel® Core™ and XEON® H series includes an integrated Intel® HD graphics accelerator.

It provides excellent 2D / 3D graphics performance with support of four simultaneous displays.

The following list illustrates some key features of the 11th Generation Intel® Core™ and XEON® H processor:

- Intel® Iris®Xe Graphics with 32 Execution Units
- Hardware accelerated video decoding/encoding for AVC/VC-1/MPEG2/HEVC/VP8/JPEG
- Direct3D11 Video API support
- OpenGL 4.5
- Open CL 2.1, Open CL 2.0, Open CL 1.2
- Single 8K60Hz (HBR3) panel support

The TQMx110EB supports three external Digital Display Interfaces (DDI1, DDI2 and DDI3) and one internal display, either dual channel LVDS or eDP interface at the COM Express™ connector, depending on TQMx110EB and carrier configuration.

The 11th Generation Intel® Core™ and XEON® H series supports up to four displays at the same time.

Table 12: Maximum Resolution Display Configuration

| Display   | Maximum Display Resolution |
|-----------|----------------------------|
| LVDS      | 1920 × 1200 @ 60 Hz        |
| eDP 1.4b  | 4096 × 2304 @ 60 Hz        |
| DP 1.4a   | 7680 × 4320 @ 60 Hz        |
| HDMI 2.0b | 4096 × 2160 @ 60 Hz        |

### 3.4.3 Chipset

The 11th Generation Intel® Core™ and XEON® H processor series includes the embedded Intel® RM590 and HM570 platform controller hub (PCH).

### 3.4.4 Memory

#### 3.4.4.1 DDR4 SDRAM SO-DIMM

The TQMx110EB supports a dual-channel DDR4 memory with optional error-correcting code (ECC), running at up to 3200 MT/s. It provides two 260-pin DDR4 SO-DIMM sockets for two DDR4 SO-DIMM modules that support system memory configurations of 16 Gbyte, 32 Gbyte or 64 Gbyte.

The ECC feature can only be used with the 11th Generation Intel® XEON H processor combined with the Intel® RM590 PCH.

#### Note: DDR4 SO-DIMM modules



Only DDR4 SO-DIMM modules qualified by TQ-Systems are authorized for use with the TQMx110EB. DDR4 SO-DIMM modules not released by TQ-Systems may cause functional issues.

#### 3.4.4.2 M.2 BGA SSD

The TQMx110EB supports an on-board M.2 BGA SSD flash device.

The M.2 BGA SSD device capacity is available from 30 Gbyte up to 1 Tbyte. The new M.2 BGA SSD offering a PCI Express Gen 3 x4 high speed interface supporting the NVMe protocol that is designed to address the needs of the industrial segment: longevity, reliability, quality and ruggedness.

##### Benefits of the M.2 BGA SSD

- High integration (single chip BGA)
- High speed interface PCI Express Gen 3 x4 (if M.2 BGA chips available Gen 4)
- Robust design optimized for rugged application
- Extended temperature ranges available (industrial and automotive)
- Intelligent power fail protection and recovery protects data from unexpected power loss
- Low power consumption
- Robust data security
- Sophisticated wear leveling and bad block management
- Pseudo Single Level Cell (pSLC) configuration available for high endurance

#### 3.4.4.3 SPI Boot Flash

The TQMx110EB provides a 256 Mbit SPI boot flash. It includes the Intel® Management Engine (Intel® ME) and the uEFI BIOS.

An external SPI boot flash on the carrier can be used instead of the on-board SPI boot flash.

The uEFI BIOS supports the following 3.3 V SPI flash devices on the carrier board:

- Macronix MX25L25645GM2I

#### 3.4.4.4 EEPROM

The TQMx110EB supports a COM Express™ Module EEPROM. The 2 kbit EEPROM AT24AA32 is connected to the general purpose I<sup>2</sup>C interface (COM Express™ pin names I2C\_DAT and I2C\_CK).



### 3.4.5 Real Time Clock

The TQMx110EB includes a standard RTC (Motorola MC146818B) integrated in the Intel PCH.

### 3.4.6 Trusted Platform Module

The TQMx110EB supports the Trusted Platform Module (TPM) 2.0 (Infineon SLB9670 controller).

The 11th Generation Intel® Core™ and XEON® H series also support a Firmware Trusted Platform Module (FTPM), which is a Trusted Platform Module 2.0 implementation in firmware. This feature can be configured in the BIOS.

### 3.4.7 Hardware Monitor

The TQMx110EB includes an integrated Hardware Monitor to monitor the on-board and processor die temperature, board voltages and manage the fan control of the COM Express™ interface.

### 3.4.8 TQ Flexible I/O Configuration (TQ-flexiCFG)

The TQ-Systems COM Express™ module TQMx110EB includes a flexible I/O configuration feature, TQ-flexiCFG.

Using the TQ-flexiCFG feature several COM Express™ I/O interfaces and functions can be configured via a programmable FPGA.

This feature enables the user to integrate special embedded features and configuration options in the TQMx110EB to reduce the carrier board design effort. Some examples of flexible I/O configuration are:

- GPIO interrupt configuration
- Interrupt configuration via LPC Serial IRQ
- Serial Port handshake signals via GPIOs
- Integration of additional I/O functions, (e.g. additional Serial, CAN, I<sup>2</sup>C, PWM controller or special power management configurations)

Please contact [support@tq-group.com](mailto:support@tq-group.com) for further information about the TQ-flexiCFG.

### 3.4.9 Ultra Deep Power State Green ECO-Off (optional)

The TQMx110EB supports the ultra-deep power state Green ECO-Off. In this configuration all DC/DC power supplies on the TQMx110EB are switched off. This results in lowest power consumption.

The Green ECO-Off mode can be configured in the uEFI BIOS setup.

To wake up the system from the Green ECO-Off mode the power button signal has to be pulled low for at least 100 msec.

## 3.5 Interfaces

### 3.5.1 PCI Express

The TQMx110EB supports up to eight PCI Express Gen 3 ports with 8 Gb/s speed at the COM Express™ connector port 0 – 3 and 4 – 7.

With a customized BIOS the PCI Express lane configuration can be set as follows:

Table 13: PCI Express port 0 – 7 Configuration Options

| COM Express™ Port 0 – 3 | Configuration                 |
|-------------------------|-------------------------------|
| (4) ×1 ports            | Standard BIOS                 |
| (1) ×2 and (2) ×1 ports | Configuration via custom BIOS |
| (1) ×4 port             | Configuration via custom BIOS |
| COM Express™ Port 4 – 7 | Configuration                 |
| (4) ×1 ports            | Configuration via custom BIOS |
| (1) ×2 and (2) ×1 ports | Configuration via custom BIOS |
| (1) ×4 port             | Standard BIOS                 |

The PCI Express COM Express™ connector port 4 to 7 supports a flexible I/O configuration to directly connect an M.2 SSD module with PCI Express 1 (×4) interface.

To support Intel® Optane™ or Rapid Storage Technology, the four PCI Express lanes of the 11th Generation Intel® Core™ and XEON® H series are connected to COM Express™ connector port 4 to 7 and used on an M.2 PCI Express socket.

### 3.5.2 PCI Express for Graphics (PEG)

At the COM Express™ connector PEG interface the TQMx110EB supports one Gen 4 PCI Express Graphics port with 16.0 Gb/s speed.

The default configuration for the PCI Express Graphic lanes is 1 (×16). In the BIOS the PCI Express Graphic lanes can be configured to 1 (×16), 2 (×8) or 2 (×4) + 1 (×8). This configuration increases the number of available PCI Express lanes.

The PCI Express Graphic port can be used for PCI Express graphics devices or high speed non-graphic PCI Express devices (e.g. quad Gigabit Ethernet or 10 Gigabit Ethernet controller).

#### Attention: PCI Express Gen 4 carrier design



The COM Express™ specification Revision 3.0 only supports the PCI Express Gen 3 (8 Gb/s) data rate. If the COM Express™ carrier is not designed for the PCI Express Gen 4 (16 Gb/s) operation, the PCI Express port should be configured to operate in Gen 3 (8 Gb/s) mode.



### 3.5.3 Gigabit Ethernet

The TQMx110EB provides an Intel® i225 Ethernet controller with 10/100/1000/2500 Mbps speed.

Features of the Intel® i225 Ethernet controller:

- Automatic speed configuration 10 BASE-T / 100 BASE-TX / 1000 BASE-T / 1000 BASE-T / 2500 BASE-T
- Automatic MDI/MDIX crossover at all speeds
- Jumbo frames (up to 9 kB)
- 802.1as/1588 conformance
- Reduced power consumption during normal operation
- Energy Efficient Ethernet (EEE)
- Ethernet TSN support

#### Attention: 2500 BASE-T Ethernet carrier design



The COM Express™ specification Revision 3.0 only supports the Gigabit Ethernet 1000 BASE-T data rate.  
If the COM Express™ carrier is not designed for the Gigabit Ethernet 2500 BASE-T operation, the Gigabit Ethernet ports should be configured to operate in 1000 BASE-T mode.

### 3.5.4 Serial ATA

The TQMx110EB supports four SATA Gen 3.0 (6 Gbit/s) interfaces. The integrated SATA host controller supports AHCI mode and it also supports RAID mode.

The SATA controller no longer supports legacy IDE mode using I/O space.

The RAID capability provides high-performance RAID 0, 1, 5, and 10 functionality on up to four SATA ports of the SATA host controller. Matrix RAID support is provided to allow multiple RAID levels to be combined on a single set of hard drives, such as RAID 0 and RAID 1 on two disks. Other RAID features include hot spare support, SMART alerting, and RAID 0 auto replace.

To support more PCI Express ports the four SATA ports can be configured to four PCI Express ports with Gen 3 (8 Gb/s) data rate. Please contact [support@tq-group.com](mailto:support@tq-group.com) for further information about the SATA / PCI Express port configuration.

### 3.5.5 Digital Display Interface

The TQMx110EB supports four Digital Display Interfaces at the COM Express™ connector DDI1, DDI2, DDI3 and eDP / LVDS port. The external Digital Display Interface supports Display Port (DP), High Definition Multimedia Interface (HDMI) and Digital Visual Interface (DVI). Any display combination is supported.

The internal eDP / LVDS port supports LVDS (via an eDP to LVDS Bridge)

Maximum display resolutions:

- DisplayPort 1.4a resolution up to 7680 × 4320 @ 60 Hz
- HDMI 2.0b up to 4096 × 2160 @ 60 Hz
- DVI up to 4096 × 2160 @ 24 Hz (HDMI without Audio)
- eDP up to 4 lanes eDP 1.4b up to 4096 × 2304 @ 60 Hz
- LVDS up to 1920 × 1200 @ 60 Hz in dual channel LVDS mode

### 3.5.6 LVDS / eDP Interface

The TQMx110EB supports a LVDS / eDP interface at the COM Express™ connector. The LVDS interface is provided through an on-board eDP to LVDS Bridge. The eDP to LVDS Bridge supports single or dual bus LVDS signalling with colour depths of 18 bits per pixel or 24 bits per pixel up to 112 MHz and a resolution up to 1920 × 1200 @ 60 Hz in dual channel LVDS mode.

The TQMx110EB includes a multiplexer to switch between the LVDS and the eDP interface on the COM Express™ connector pins. In the BIOS the LVDS or eDP interface can be configured.

The LVDS data output packing can be configured either in VESA or JEIDA format.

To support panels without EDID ROM, the eDP to LVDS bridge can emulate EDID ROM behaviour avoiding specific changes in system video BIOS.

Please contact [support@tq-group.com](mailto:support@tq-group.com) for further information about the LVDS configuration.

### 3.5.7 USB Interfaces

The TQMx110EB supports eight USB 2.0 and four USB 3.2 Gen 2 ports with data rate up to 10 Gb/s at the COM Express™ connector. All USB 3.2 Gen 2 ports are configurable to USB 3.2 Gen 1 (5 Gb/s).

Care must be taken in the COM Express™ carrier design, the carrier must support the USB 3.2 Gen 2 (10 Gb/s) high speed standard.

#### Attention: USB 3.1 Gen 2 (10 Gb/s) carrier design



The COM Express™ specification Revision 3.0 only supports the USB 3.2 Gen 1 (5 Gb/s) data rate. If the COM Express™ carrier is not designed for the USB 3.2 Gen 2 (10 Gb/s) operation, the USB 3.2 ports should be configured to operate in Gen 1 mode.

Please contact [support@tq-group.com](mailto:support@tq-group.com) for further information about USB 3.1 high-speed Design Guidelines.

#### Note: USB Port Mapping



The USB 2.0 port 0 must be paired with USB 3.2 SuperSpeedPlus port 0.  
 The USB 2.0 port 1 must be paired with USB 3.2 SuperSpeedPlus port 1.  
 The USB 2.0 port 2 must be paired with USB 3.2 SuperSpeedPlus port 2.  
 The USB 2.0 port 3 must be paired with USB 3.2 SuperSpeedPlus port 3.

### 3.5.8 General Purpose Input / Output

The TQMx110EB provides eight GPIO signals at the COM Express™ connector. The GPIO signals are shared with the SD card signals. The GPIO signals are integrated in the TQ-flexiCFG block and can be configured flexibly.

The signals can also be used for special functions (see 3.4.8).

### 3.5.9 High Definition Audio Interface

The TQMx110EB provides a High Definition Audio (HDA) interface, which supports two audio codecs at the COM Express™ connector. The HDA\_SDIN2 signal at the COM Express™ connector is not connected. The Audio Codec is assembled on the carrier board.



### 3.5.10 LPC / eSPI Bus

The TQMx110EB supports a Low Pin Count (LPC) legacy bus and the Enhanced Serial Peripheral (eSPI) bus on the same COM Express™ connector pins.

The TQMx110EB includes a multiplexer to switch between the LPC and the eSPI bus on the COM Express™ connector pins. With the ESPI\_EN# signal the carrier indicates the operating mode of the LPC / eSPI bus. If left unconnected on the carrier, LPC mode (default) is selected. If pulled to GND on the carrier, eSPI mode is selected.

The default COM Express™ interface configuration is LPC bus. For the eSPI option a BIOS configuration is necessary.

Please contact [support@tq-group.com](mailto:support@tq-group.com) for further information about the Serial Peripheral eSPI BIOS and Carrier integration.

### 3.5.11 I<sup>2</sup>C Bus

The TQMx110EB supports a general purpose I<sup>2</sup>C port via a dedicated LPC to I<sup>2</sup>C controller integrated in the TQ-flexiCFG block. The I<sup>2</sup>C host controller supports a transfer rate of up to 400 kHz and can be configured independently.

### 3.5.12 SMBus

The TQMx110EB provides a System Management Bus (SMBus).

### 3.5.13 Serial Peripheral Interface

The TQMx110EB provides a Serial Peripheral Interface (SPI) interface.

The SPI interface can only be used for SPI boot Flash devices.

### 3.5.14 Serial Ports

The TQMx110EB offers a dual Universal Asynchronous Receiver and Transmitter (UART) controller. The register set is based on the industry standard 16550 UART. The UART operates with standard serial port drivers without requiring a custom driver to be installed. The 16 byte transmit and receive FIFOs reduce CPU overhead and minimize the risk of buffer overflow and data loss. With the TQ-flexiCFG feature the serial ports can be configured to route the handshake signals to free pins at the COM Express™ connector.

Table 14: Serial Port COM Express™ Port Mapping

| COM Express™ Signal | COM Express™ Pin | TQMx110EB | Remark                            |
|---------------------|------------------|-----------|-----------------------------------|
| SER0_TX             | A98              | SER0_TX   | 3.3 V output (without protection) |
| SER0_RX             | A99              | SER0_RX   | 3.3 V input (without protection)  |
| SER1_TX             | A101             | SER1_TX   | 3.3 V output (without protection) |
| SER1_RX             | A102             | SER1_RX   | 3.3 V input (without protection)  |
| SER0_RTS#           | B98              | SER0_RTS# | 3.3 V output                      |
| SER0_CTS#           | B99              | SER0_CTS# | 3.3 V input                       |
| SER1_RTS#           | D24              | SER1_RTS# | 3.3 V output                      |
| SER1_CTS#           | D25              | SER1_CTS# | 3.3 V input                       |

#### Note: Protection circuits



In COM Express™ specification Revision 3.0 the signals A98, A99, A101 and A102 have been reclaimed from the VCC\_12V pool. Therefore protection on the carrier board is necessary to avoid damage to those when accidentally exposed to 12 V. The implementation of this circuitry causes lower transfer rates on the two serial ports.

On the TQMx110EB the protection circuit is removed by default and the serial ports provide transfer rates of up to 115 kbaud. Therefore the TQMx110EB can only be used in a COM Express™ COM.0 2.0 and 3.0 Type 6 pin-out carrier board.

### 3.5.15 Watchdog Timer

The TQMx110EB supports an independently programmable two-stage Watchdog timer integrated in the TQ-flexiCFG block. There are four operation modes available for the Watchdog timer:

- Dual-stage mode
- Interrupt mode
- Reset mode
- Timer mode

The Watchdog timer timeout ranges from 125 msec to 1 h.

The COM Express™ Specification does not support external hardware triggering of the Watchdog. An external Watchdog Trigger can be configured to GPIO pins at the COM Express™ connector with the TQ-flexiCFG feature.

## 3.6 Connectors

### 3.6.1 COM Express™ Connector

Two 220-pin 0.5 mm pitch receptacle connectors are used to interface the TQMx110EB on the carrier board.

On the carrier board two 220-pin 0.5 mm pitch plug connectors have to be used.

Two versions with 5 mm and 8 mm stack height are available.

| Attention: USB 3.1 Gen 2 (10 Gb/s), PCI Express Gen 4 (16 Gb/s) and DisplayPort HBR3 (8.1 GB/s) carrier design |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                         |
|----------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                               | <p>The COM Express™ specification Revision 3.0 only supports the USB 3.2 Gen 1 (5 Gb/s), PCI Express Gen 3 (8 Gb/s) and DisplayPort HBR2 (5.4 Gb/s) data rate.</p> <p>To support on the COM Express™ carrier the new high speed interfaces, USB 3.2 Gen 2 (10 Gb/s), PCI Express Gen 4 (16 Gb/s) and DisplayPort HBR3 (8.1 Gb/s) data rate, a COM Express™ optimized high speed connector must be used.</p> <p>The company EPT offers an optimized COM Express™ connector (Colibri) for applications up to 16 Gb/s, this connector is compatible with all popular COM Express™ connectors.</p> <p>The Carrier design also needs to be optimized to support the new high speed interfaces.</p> <p>Please contact <a href="mailto:support@tq-group.com">support@tq-group.com</a> for further information about the new high speed design requirements</p> |

Connector samples are available from: <https://www.ept.de/index.php?tq-colibri-lp>

### 3.6.2 Debug Header

The TQMx110EB includes a 14-pin flat cable connector to connect an external debug module (TQ specific) providing uEFI BIOS POST code information, debug LEDs and a JTAG interface for on-board FPGA.

The TQM debug card can be connected at this header.

### 3.6.3 TQM Debug Card

The TQM debug card is designed to provide access to several processor and chipset control signals.

When the COM Express module is powered up, the uEFI BIOS POST codes are shown.

If the COM Express module does not boot, the uEFI BIOS POST has detected a fatal error and stopped.

The number displayed on the TQM debug card is the number of the test, where the uEFI BIOS boot failed.



Figure 2: TQM Debug Card

Please contact [support@tq-group.com](mailto:support@tq-group.com) for more details and ordering information about the TQM debug card.



3.6.4 Debug Module LED

The TQMx110EB includes a dual colour LED providing boot and BIOS information.  
The following table illustrates some LED boot messages:

Table 15: LED Boot Messages

| Red LED  | Green LED | Remark                      |
|----------|-----------|-----------------------------|
| ON       | OFF       | Power supply error          |
| ON       | ON        | S4/S5 state                 |
| BLINKING | BLINKING  | S3 state                    |
| OFF      | BLINKING  | uEFI BIOS is booting        |
| OFF      | ON        | uEFI BIOS boot is completed |



Figure 3: Debug Module LED

### 3.7 COM Express™ Connector Pinout

This section describes the TQMx110EB COM Express™ connector pin assignment, which is compliant with COM.0 R3.0 Type 6 pin-out definitions.

#### 3.7.1 Signal Assignment Abbreviations

The following table lists the abbreviations used within this chapter:

Table 16: Signal Assignment Abbreviations

| Abbreviation | Description                   |
|--------------|-------------------------------|
| GND          | Ground                        |
| PWR          | Power                         |
| I            | Input                         |
| I PU         | Input with pull-up resistor   |
| I PD         | Input with pull-down resistor |
| O            | Output                        |
| OD           | Open drain output             |
| I/O          | Bi-directional                |

Note: Unused signals on the carrier board



Unused inputs at the COM Express™ connector can be left open on the carrier board, since these signals are terminated on the TQMx110EB.



### 3.7.2 COM Express™ Connector Pin Assignment

Table 17: COM Express™ Connector Pin Assignment

| Pin | Pin-Signal           | Description                                                      | Type  | Remark      |
|-----|----------------------|------------------------------------------------------------------|-------|-------------|
| A1  | GND(FIXED)           | Ground                                                           | GND   |             |
| A2  | GBE0_MDI3-           | Gigabit Ethernet Controller 0: Media Dependent Interface         | IO    |             |
| A3  | GBE0_MDI3+           | Gigabit Ethernet Controller 0: Media Dependent Interface         | IO    |             |
| A4  | GBE0_LINK100#        | Gigabit Ethernet Controller 0 100 / 2500 Mbit/s link indicator   | OD    |             |
| A5  | GBE0_LINK1000#       | Gigabit Ethernet Controller 0 1000 Mbit/s link indicator         | OD    |             |
| A6  | GBE0_MDI2-           | Gigabit Ethernet Controller 0: Media Dependent Interface         | IO    |             |
| A7  | GBE0_MDI2+           | Gigabit Ethernet Controller 0: Media Dependent Interface         | IO    |             |
| A8  | GBE0_LINK#           | Gigabit Ethernet Controller 0 link indicator                     | OD    |             |
| A9  | GBE0_MDI1-           | Gigabit Ethernet Controller 0: Media Dependent Interface         | IO    |             |
| A10 | GBE0_MDI1+           | Gigabit Ethernet Controller 0: Media Dependent Interface         | IO    |             |
| A11 | GND(FIXED)           | Ground                                                           | GND   |             |
| A12 | GBE0_MDI0-           | Gigabit Ethernet Controller 0: Media Dependent Interface         | IO    |             |
| A13 | GBE0_MDI0+           | Gigabit Ethernet Controller 0: Media Dependent Interface         | IO    |             |
| A14 | GBE0_CTREF           | Reference voltage for Carrier Board Ethernet channel 0           | Power |             |
| A15 | SUS_S3#              | Indicates system is in Suspend to RAM state. Active low output.  | O PD  | TQ-flexiCFG |
| A16 | SATA0_TX+            | SATA differential transmit pairs                                 | O     |             |
| A17 | SATA0_TX-            | SATA differential transmit pairs                                 | O     |             |
| A18 | SUS_S4#              | Indicates system is in Suspend to Disk state. Active low output. | O PD  | TQ-flexiCFG |
| A19 | SATA0_RX+            | SATA differential receive pairs                                  | I     |             |
| A20 | SATA0_RX-            | SATA differential receive pairs                                  | I     |             |
| A21 | GND(FIXED)           | Ground                                                           | GND   |             |
| A22 | SATA2_TX+            | SATA differential transmit pairs                                 | O     |             |
| A23 | SATA2_TX-            | SATA differential transmit pairs                                 | O     |             |
| A24 | SUS_S5#              | Indicates system is in Soft Off state. Active low output.        | O PD  | TQ-flexiCFG |
| A25 | SATA2_RX+            | SATA differential receive pairs                                  | I     |             |
| A26 | SATA2_RX-            | SATA differential receive pairs                                  | I     |             |
| A27 | BATLOW#              | Indicates that external battery is low                           | I PU  |             |
| A28 | (S)ATA_ACT#          | SATA activity indicator                                          | O     |             |
| A29 | HDA_SYNC             | Sample-synchronization signal to the CODEC(s)                    | O     |             |
| A30 | HDA_RST#             | Reset output to CODEC, active low.                               | O     |             |
| A31 | GND(FIXED)           | Ground                                                           | GND   |             |
| A32 | HDA_BITCLK           | Serial data clock generated by the external CODEC(s)             | IO    |             |
| A33 | HDA_SDOUT            | Serial TDM data output to the CODEC                              | O     |             |
| A34 | BIOS_DIS0#/ESPI_SAFS | Selection straps to determine the BIOS boot device               | I PU  |             |
| A35 | THRMTRIP#            | indicating that the CPU has entered thermal shutdown             | O     |             |
| A36 | USB6-                | USB differential pairs                                           | IO    |             |
| A37 | USB6+                | USB differential pairs                                           | IO    |             |
| A38 | USB_6_7_OC#          | USB over-current sense, USB channels 6 and 7                     | I PU  |             |
| A39 | USB4-                | USB differential pairs                                           | IO    |             |
| A40 | USB4+                | USB differential pairs                                           | IO    |             |
| A41 | GND(FIXED)           | Ground                                                           | GND   |             |
| A42 | USB2-                | USB differential pairs                                           | IO    |             |
| A43 | USB2+                | USB differential pairs                                           | IO    |             |
| A44 | USB_2_3_OC#          | USB over-current sense, USB channels 2 and 3                     | I PU  |             |
| A45 | USB0-                | USB differential pairs                                           | IO    |             |
| A46 | USB0+                | USB differential pairs                                           | IO    |             |
| A47 | VCC_RTC              | Real-time clock circuit-power input.                             | Power |             |
| A48 | RSVD                 | Reserved                                                         | O     | TQ-flexiCFG |
| A49 | GBE0_SDP             | Gigabit Ethernet Controller 0 Software-Definable Pin.            | IO    | TQ-flexiCFG |
| A50 | LPC_SERIRQ/ESPI_CS1# | LPC serial interrupt / eSPI CS1#                                 | IO    | 3.3V / 1.8V |
| A51 | GND(FIXED)           | Ground                                                           | GND   |             |
| A52 | PCIE_TX5+            | PCI Express differential transmit pairs                          | O     |             |
| A53 | PCIE_TX5-            | PCI Express differential transmit pairs                          | O     |             |
| A54 | GPIO/SD_DATA0        | GPIO                                                             | I PU  | TQ-flexiCFG |
| A55 | PCIE_TX4+            | PCI Express differential transmit pairs                          | O     |             |





## COM Express™ Connector Pin Assignment (continued)

| Pin  | Pin-Signal              | Description                                         | Type | Remark              |
|------|-------------------------|-----------------------------------------------------|------|---------------------|
| A56  | PCIE_TX4-               | PCI Express differential transmit pairs             | O    |                     |
| A57  | GND                     | Ground                                              | GND  |                     |
| A58  | PCIE_TX3+               | PCI Express differential transmit pairs             | O    |                     |
| A59  | PCIE_TX3-               | PCI Express differential transmit pairs             | O    |                     |
| A60  | GND(FIXED)              | Ground                                              | GND  |                     |
| A61  | PCIE_TX2+               | PCI Express differential transmit pairs             | O    |                     |
| A62  | PCIE_TX2-               | PCI Express differential transmit pairs             | O    |                     |
| A63  | GPI1/SD_DATA1           | GPI1                                                | I PU | TQ-flexiCFG         |
| A64  | PCIE_TX1+               | PCI Express differential transmit pairs             | O    |                     |
| A65  | PCIE_TX1-               | PCI Express differential transmit pairs             | O    |                     |
| A66  | GND                     | Ground                                              | GND  |                     |
| A67  | GPI2/SD_DATA2           | GPI2                                                | I PU | TQ-flexiCFG         |
| A68  | PCIE_TX0+               | PCI Express differential transmit pairs             | O    |                     |
| A69  | PCIE_TX0-               | PCI Express differential transmit pairs             | O    |                     |
| A70  | GND(FIXED)              | Ground                                              | GND  |                     |
| A71  | LVDS_A0+ / eDP_TX2+     | LVDS Channel A differential pairs 0 / eDP_TX2+      | O    |                     |
| A72  | LVDS_A0- / eDP_TX2-     | LVDS Channel A differential pairs 0 / eDP_TX2-      | O    |                     |
| A73  | LVDS_A1+ / eDP_TX1+     | LVDS Channel A differential pairs 1 / eDP_TX1+      | O    |                     |
| A74  | LVDS_A1- / eDP_TX1-     | LVDS Channel A differential pairs 1 / eDP_TX1-      | O    |                     |
| A75  | LVDS_A2+ / eDP_TX0+     | LVDS Channel A differential pairs 2 / eDP_TX0+      | O    |                     |
| A76  | LVDS_A2- / eDP_TX0-     | LVDS Channel A differential pairs 2 / eDP_TX0-      | O    |                     |
| A77  | LVDS_VDD_EN             | LVDS / eDP panel power enable                       | O PD |                     |
| A78  | LVDS_A3+                | LVDS Channel A differential pairs 3                 | O    |                     |
| A79  | LVDS_A3-                | LVDS Channel A differential pairs 3                 | O    |                     |
| A80  | GND(FIXED)              | Ground                                              | GND  |                     |
| A81  | LVDS_A_CK+ / eDP_TX3+   | LVDS Channel A differential clock / eDP_TX3+        | O    |                     |
| A82  | LVDS_A_CK- / eDP_TX3-   | LVDS Channel A differential clock / eDP_TX3-        | O    |                     |
| A83  | LVDS_I2C_CK / eDP_AUX+  | I2C clock output for LVDS display / eDP_AUX+        | IO   |                     |
| A84  | LVDS_I2C_DAT / eDP_AUX- | I2C data line for LVDS display / eDP_AUX-           | IO   |                     |
| A85  | GPI3/SD_DATA3           | GPI3 / SD_DATA3                                     | I PU | TQ-flexiCFG         |
| A86  | RSVD18                  | Reserved                                            | NC   |                     |
| A87  | eDP_HPD                 | eDP Detection of Hot Plug                           | I PD |                     |
| A88  | PCIE_CLK_REF+           | Reference clock output for all PCI Express lanes    | O    |                     |
| A89  | PCIE_CLK_REF-           | Reference clock output for all PCI Express lanes    | O    |                     |
| A90  | GND(FIXED)              | Ground                                              | GND  |                     |
| A91  | SPI_POWER               | Power supply for Carrier Board SPI Flash            | PWR  | 3.3V                |
| A92  | SPI_MISO                | Data in to Module from Carrier SPI                  | I PU |                     |
| A93  | GPO0/SD_CLK             | GPO0                                                | O PD | TQ-flexiCFG         |
| A94  | SPI_CLK                 | Clock from Module to Carrier SPI                    | O    |                     |
| A95  | SPI_MOSI                | Data out from Module to Carrier SPI                 | O    |                     |
| A96  | TPM_PP                  | Trusted Platform Module (TPM) Physical Presence pin | I PD | TQ-flexiCFG         |
| A97  | TYPE10#                 | Type 10 Module indication (NC)                      | NC   |                     |
| A98  | SER0_TX                 | Serial port 0 transmitter                           | O    | w/o protection 3.3V |
| A99  | SER0_RX                 | Serial port 0 receiver                              | I PU | w/o protection 3.3V |
| A100 | GND(FIXED)              | Ground                                              | GND  |                     |
| A101 | SER1_TX                 | Serial port 1 transmitter                           | O    | w/o protection 3.3V |
| A102 | SER1_RX                 | Serial port 1 receiver                              | I PU | w/o protection 3.3V |
| A103 | LID#                    | LID switch                                          | I PU |                     |
| A104 | VCC_12V                 | Primary wide power input                            | PWR  |                     |
| A105 | VCC_12V                 | Primary wide power input                            | PWR  |                     |
| A106 | VCC_12V                 | Primary wide power input                            | PWR  |                     |
| A107 | VCC_12V                 | Primary wide power input                            | PWR  |                     |
| A108 | VCC_12V                 | Primary wide power input                            | PWR  |                     |
| A109 | VCC_12V                 | Primary wide power input                            | PWR  |                     |
| A110 | GND(FIXED)              | Ground                                              | GND  |                     |



## COM Express™ Connector Pin Assignment (continued)

| Pin | Pin-Signal             | Description                                                      | Type | Remark      |
|-----|------------------------|------------------------------------------------------------------|------|-------------|
| B1  | GND(FIXED)             | Ground                                                           | GND  |             |
| B2  | GBE0_ACT#              | Gigabit Ethernet Controller 0 active indicator                   | OD   |             |
| B3  | LPC_FRAME#/ESPI_CS0#   | LPC frame indicates the start of an LPC cycle / eSPI CS0#        | IO   | 3.3V / 1.8V |
| B4  | LPC_AD0/ESPI_IO_0      | LPC multiplexed address, command and data bus / eSPI IO0         | IO   | 3.3V / 1.8V |
| B5  | LPC_AD1/ESPI_IO_1      | LPC multiplexed address, command and data bus / eSPI IO1         | IO   | 3.3V / 1.8V |
| B6  | LPC_AD2/ESPI_IO_2      | LPC multiplexed address, command and data bus / eSPI IO2         | IO   | 3.3V / 1.8V |
| B7  | LPC_AD3/ESPI_IO_3      | LPC multiplexed address, command and data bus / eSPI IO3         | IO   | 3.3V / 1.8V |
| B8  | LPC_DRQ0#/ESPI_ALERT0# | LPC serial DMA request / eSPI ALERT0#                            | IO   | 3.3V / 1.8V |
| B9  | LPC_DRQ1#/ESPI_ALERT1# | LPC serial DMA request / eSPI ALERT1#                            | IO   | 3.3V / 1.8V |
| B10 | LPC_CLK/ESPI_CLK       | LPC clock output / eSPI Clock                                    | O    | 3.3V / 1.8V |
| B11 | GND(FIXED)             | Ground                                                           | GND  |             |
| B12 | PWRBTN#                | Power button input                                               | I PU | TQ-flexiCFG |
| B13 | SMB_CLK                | System Management Bus bidirectional clock line                   | IO   |             |
| B14 | SMB_DAT                | System Management Bus bidirectional data line                    | IO   |             |
| B15 | SMB_ALERT#             | System Management Bus Alert                                      | I PU |             |
| B16 | SATA1_TX+              | SATA differential transmit pairs                                 | O    |             |
| B17 | SATA1_TX-              | SATA differential transmit pairs                                 | O    |             |
| B18 | SUS_STAT#/ESPI_RESET   | LPC Indicates suspend operation / eSPI RST#                      | O    | 3.3V / 1.8V |
| B19 | SATA1_RX+              | SATA differential receive pairs                                  | I    |             |
| B20 | SATA1_RX-              | SATA differential receive pairs                                  | I    |             |
| B21 | GND(FIXED)             | Ground                                                           | GND  |             |
| B22 | SATA3_TX+              | SATA differential transmit pairs                                 | O    |             |
| B23 | SATA3_TX-              | SATA differential transmit pairs                                 | O    |             |
| B24 | PWR_OK                 | Power OK from main power supply                                  | I PU | TQ-flexiCFG |
| B25 | SATA3_RX+              | SATA differential receive pairs                                  | I    |             |
| B26 | SATA3_RX-              | SATA differential receive pairs                                  | I    |             |
| B27 | WDT                    | watchdog time-out                                                | O    | TQ-flexiCFG |
| B28 | HDA_SDIN2              | Serial TDM data input                                            | I PU | N/A         |
| B29 | HDA_SDIN1              | Serial TDM data input                                            | I PU |             |
| B30 | HDA_SDIN0              | Serial TDM data input                                            | I PU |             |
| B31 | GND(FIXED)             | Ground                                                           | GND  |             |
| B32 | SPKR                   | PC Audio Speaker output                                          | O    |             |
| B33 | I2C_CLK                | General purpose I2C port clock output                            | IO   | TQ-flexiCFG |
| B34 | I2C_DAT                | General purpose I2C port data I/O line                           | IO   | TQ-flexiCFG |
| B35 | THRM#                  | Input from carrier temperature sensor                            | I PU |             |
| B36 | USB7-                  | USB differential pairs                                           | IO   |             |
| B37 | USB7+                  | USB differential pairs                                           | IO   |             |
| B38 | USB_4_5_OC#            | USB over-current sense, USB channels 4 and 5                     | I PU |             |
| B39 | USB5-                  | USB differential pairs                                           | IO   |             |
| B40 | USB5+                  | USB differential pairs                                           | IO   |             |
| B41 | GND(FIXED)             | Ground                                                           | GND  |             |
| B42 | USB3-                  | USB differential pairs                                           | IO   |             |
| B43 | USB3+                  | USB differential pairs                                           | IO   |             |
| B44 | USB_0_1_OC#            | USB over-current sense, USB channels 0 and 1                     | I PU |             |
| B45 | USB1-                  | USB differential pairs                                           | IO   |             |
| B46 | USB1+                  | USB differential pairs                                           | IO   |             |
| B47 | ESPI_EN#               | The Carrier shall tie ESPI_EN# to GND for eSPI operation, LPC NC | I PU | TQ-flexiCFG |
| B48 | USB0_HOST_PRESNT       | Module USB client may detect the presence of a USB host on USB0  | I PU | N/A         |
| B49 | SYS_RESET#             | Reset button input                                               | I PU | TQ-flexiCFG |
| B50 | CB_RESET#              | Reset output from Module to Carrier Board                        | O    | TQ-flexiCFG |
| B51 | GND(FIXED)             | Ground                                                           | GND  |             |
| B52 | PCIE_RX5+              | PCI Express differential receive pairs                           | I    |             |
| B53 | PCIE_RX5-              | PCI Express differential receive pairs                           | I    |             |
| B54 | GPO1/SD_CMD            | GPO1                                                             | O PD | TQ-flexiCFG |
| B55 | PCIE_RX4+              | PCI Express differential receive pairs                           | I    |             |



## COM Express™ Connector Pin Assignment (continued)

| Pin  | Pin-Signal       | Description                                        | Type | Remark      |
|------|------------------|----------------------------------------------------|------|-------------|
| B56  | PCIE_RX4-        | PCI Express differential receive pairs             | I    |             |
| B57  | GPO2 / SD_WP     | GPO2                                               | O PD | TQ-flexiCFG |
| B58  | PCIE_RX3+        | PCI Express differential receive pairs             | I    |             |
| B59  | PCIE_RX3-        | PCI Express differential receive pairs             | I    |             |
| B60  | GND(FIXED)       | Ground                                             | GND  |             |
| B61  | PCIE_RX2+        | PCI Express differential receive pairs             | I    |             |
| B62  | PCIE_RX2-        | PCI Express differential receive pairs             | I    |             |
| B63  | GPO3/SD_CD#      | GPO3                                               | O PD | TQ-flexiCFG |
| B64  | PCIE_RX1+        | PCI Express differential receive pairs             | I    |             |
| B65  | PCIE_RX1-        | PCI Express differential receive pairs             | I    |             |
| B66  | WAKE0#           | PCI Express wake up signal                         | I PU | TQ-flexiCFG |
| B67  | WAKE1#           | General purpose wake up signal                     | I PU | TQ-flexiCFG |
| B68  | PCIE_RX0+        | PCI Express differential receive pairs             | I    |             |
| B69  | PCIE_RX0-        | PCI Express differential receive pairs             | I    |             |
| B70  | GND(FIXED)       | Ground                                             | GND  |             |
| B71  | LVDS_B0+         | LVDS Channel B differential pairs 0                | O    |             |
| B72  | LVDS_B0-         | LVDS Channel B differential pairs 0                | O    |             |
| B73  | LVDS_B1+         | LVDS Channel B differential pairs 1                | O    |             |
| B74  | LVDS_B1-         | LVDS Channel B differential pairs 1                | O    |             |
| B75  | LVDS_B2+         | LVDS Channel B differential pairs 2                | O    |             |
| B76  | LVDS_B2-         | LVDS Channel B differential pairs 2                | O    |             |
| B77  | LVDS_B3+         | LVDS Channel B differential pairs 3                | O    |             |
| B78  | LVDS_B3-         | LVDS Channel B differential pairs 3                | O    |             |
| B79  | LVDS_BKLT_EN     | LVDS / eDP panel backlight enable                  | O PD |             |
| B80  | GND(FIXED)       | Ground                                             | GND  |             |
| B81  | LVDS_B_CK+       | LVDS Channel B differential clock                  | O    |             |
| B82  | LVDS_B_CK-       | LVDS Channel B differential clock                  | O    |             |
| B83  | LVDS_BKLT_CTRL   | LVDS / eDP panel backlight brightness control      | O PD |             |
| B84  | VCC_5V_SBY       | Standby power input: +5.0V nominal                 | PWR  |             |
| B85  | VCC_5V_SBY       | Standby power input: +5.0V nominal                 | PWR  |             |
| B86  | VCC_5V_SBY       | Standby power input: +5.0V nominal                 | PWR  |             |
| B87  | VCC_5V_SBY       | Standby power input: +5.0V nominal                 | PWR  |             |
| B88  | BIOS_DIS1#       | Selection straps to determine the BIOS boot device | I PU |             |
| B89  | VGA_RED          | Red for monitor                                    | O    | N/A         |
| B90  | GND(FIXED)       | Ground                                             | GND  |             |
| B91  | VGA_GRN          | Green for monitor                                  | O    | N/A         |
| B92  | VGA_BLU          | Blue for monitor                                   | O    | N/A         |
| B93  | VGA_HSYNC        | Horizontal sync output to VGA monitor              | O    | N/A         |
| B94  | VGA_VSYNC        | Vertical sync output to VGA monitor                | O    | N/A         |
| B95  | VGA_I2C_CK       | DDC clock line                                     | O    | N/A         |
| B96  | VGA_I2C_DAT      | DDC data line                                      | IO   | N/A         |
| B97  | SPI_CS#          | Chip select for Carrier Board SPI                  | O    |             |
| B98  | (RSVD) SER0_RTS# | Serial port 0 Request To Send                      | O    | TQ-flexiCFG |
| B99  | (RSVD) SER0_CTS# | Serial port 0 Clear To Send                        | I PU | TQ-flexiCFG |
| B100 | GND(FIXED)       | Ground                                             | GND  |             |
| B101 | FAN_PWMOUT       | Fan Pulse Width Modulation speed control output    | O    |             |
| B102 | FAN_TACHIN       | Fan tachometer input                               | I PU |             |
| B103 | SLEEP#           | Sleep button                                       | I PU |             |
| B104 | VCC_12V          | Primary wide power input                           | PWR  |             |
| B105 | VCC_12V          | Primary wide power input                           | PWR  |             |
| B106 | VCC_12V          | Primary wide power input                           | PWR  |             |
| B107 | VCC_12V          | Primary wide power input                           | PWR  |             |
| B108 | VCC_12V          | Primary wide power input                           | PWR  |             |
| B109 | VCC_12V          | Primary wide power input                           | PWR  |             |
| B110 | GND(FIXED)       | Ground                                             |      |             |



## COM Express™ Connector Pin Assignment (continued)

| Pin | Pin-Signal         | Description                                       | Type | Remark |
|-----|--------------------|---------------------------------------------------|------|--------|
| C1  | GND(FIXED)         | Ground                                            | GND  |        |
| C2  | GND                | Ground                                            | GND  |        |
| C3  | USB_SSRX0-         | SuperSpeed USB3.2 differential receive pairs      | I    |        |
| C4  | USB_SSRX0+         | SuperSpeed USB3.2 differential receive pairs      | I    |        |
| C5  | GND                | Ground                                            | GND  |        |
| C6  | USB_SSRX1-         | SuperSpeed USB3.2 differential receive pairs      | I    |        |
| C7  | USB_SSRX1+         | SuperSpeed USB3.2 differential receive pairs      | I    |        |
| C8  | GND                | Ground                                            | GND  |        |
| C9  | USB_SSRX2-         | SuperSpeed USB3.2 differential receive pairs      | I    |        |
| C10 | USB_SSRX2+         | SuperSpeed USB3.2 differential receive pairs      | I    |        |
| C11 | GND(FIXED)         | Ground                                            | GND  |        |
| C12 | USB_SSRX3-         | SuperSpeed USB3.2 differential receive pairs      | I    |        |
| C13 | USB_SSRX3+         | SuperSpeed USB3.2 differential receive pairs      | I    |        |
| C14 | GND                | Ground                                            | GND  |        |
| C15 | DDI1_PAIR6+        | DDI1 DP / HDMI / DVI differential pairs 6         | O    | N/A    |
| C16 | DDI1_PAIR6-        | DDI1 DP / HDMI / DVI differential pairs 6         | O    | N/A    |
| C17 | RSVD18             | Reserved                                          | NC   |        |
| C18 | RSVD18             | Reserved                                          | NC   |        |
| C19 | PCIE_RX6+          | PCI Express differential receive pairs            | I    |        |
| C20 | PCIE_RX6-          | PCI Express differential receive pairs            | I    |        |
| C21 | GND(FIXED)         | Ground                                            | GND  |        |
| C22 | PCIE_RX7+          | PCI Express differential receive pairs            | I    |        |
| C23 | PCIE_RX7-          | PCI Express differential receive pairs            | I    |        |
| C24 | DDI1_HPD           | DDI1 Detection of Hot Plug                        | I PD |        |
| C25 | DDI1_PAIR4+        | DDI1 DP / HDMI / DVI differential pairs 4         | O    | N/A    |
| C26 | DDI1_PAIR4-        | DDI1 DP / HDMI / DVI differential pairs 4         | O    | N/A    |
| C27 | RSVD18             | Reserved                                          | NC   |        |
| C28 | RSVD18             | Reserved                                          | NC   |        |
| C29 | DDI1_PAIR5+        | DDI1 DP / HDMI / DVI differential pairs 5         | O    | N/A    |
| C30 | DDI1_PAIR5-        | DDI1 DP / HDMI / DVI differential pairs 5         | O    | N/A    |
| C31 | GND(FIXED)         | Ground                                            | GND  |        |
| C32 | DDI2_CTRLCLK_AUX+  | DDI2_CTRLCLK_AUX+ signal DP AUX, HDMI DVI CLK     | IO   |        |
| C33 | DDI2_CTRLDATA_AUX- | DDI2_CTRLDATA_AUX- signal DP AUX, HDMI DVI DATA   | IO   |        |
| C34 | DDI2_DDC_AUX_SEL   | Selects the function of DDI2_CTRLx AUX+/- Signals | I PD |        |
| C35 | RSVD18             | Reserved                                          | NC   |        |
| C36 | DDI3_CTRLCLK_AUX+  | DDI3_CTRLCLK_AUX+ signal DP AUX, HDMI DVI CLK     | IO   |        |
| C37 | DDI3_CTRLDATA_AUX- | DDI3_CTRLDATA_AUX- signal DP AUX, HDMI DVI DATA   | IO   |        |
| C38 | DDI3_DDC_AUX_SEL   | Selects the function of DDI3_CTRLx AUX+/- Signals | I PU |        |
| C39 | DDI3_PAIR0+        | DDI3 DP / HDMI / DVI differential pairs 0         | O    |        |
| C40 | DDI3_PAIR0-        | DDI3 DP / HDMI / DVI differential pairs 0         | O    |        |
| C41 | GND(FIXED)         | Ground                                            | GND  |        |
| C42 | DDI3_PAIR1+        | DDI3 DP / HDMI / DVI differential pairs 1         | O    |        |
| C43 | DDI3_PAIR1-        | DDI3 DP / HDMI / DVI differential pairs 1         | O    |        |
| C44 | DDI3_HPD           | DDI3 Detection of Hot Plug                        | I PD |        |
| C45 | RSVD18             | Reserved                                          | NC   |        |
| C46 | DDI3_PAIR2+        | DDI3 DP / HDMI / DVI differential pairs 2         | O    |        |
| C47 | DDI3_PAIR2-        | DDI3 DP / HDMI / DVI differential pairs 2         | O    |        |
| C48 | RSVD18             | Reserved                                          | NC   |        |
| C49 | DDI3_PAIR3+        | DDI3 DP / HDMI / DVI differential pairs 3         | O    |        |
| C50 | DDI3_PAIR3-        | DDI3 DP / HDMI / DVI differential pairs 3         | O    |        |
| C51 | GND(FIXED)         | Ground                                            | GND  |        |
| C52 | PEG_RX0+           | PCI Express differential receive pairs            | I    |        |
| C53 | PEG_RX0-           | PCI Express differential receive pairs            | I    |        |
| C54 | TYPE0#             | Type 0 Module indication (NC)                     | NC   |        |
| C55 | PEG_RX1+           | PCI Express differential receive pairs            | I    |        |



## COM Express™ Connector Pin Assignment (continued)

| Pin  | Pin-Signal     | Description                                      | Type | Remark      |
|------|----------------|--------------------------------------------------|------|-------------|
| C56  | PEG_RX1-       | PCI Express differential receive pairs           | I    |             |
| C57  | TYPE1#         | Type 1 Module indication (NC)                    | NC   |             |
| C58  | PEG_RX2+       | PCI Express differential receive pairs           | I    |             |
| C59  | PEG_RX2-       | PCI Express differential receive pairs           | I    |             |
| C60  | GND(FIXED)     | Ground                                           | GND  |             |
| C61  | PEG_RX3+       | PCI Express differential receive pairs           | I    |             |
| C62  | PEG_RX3-       | PCI Express differential receive pairs           | I    |             |
| C63  | RSVD18         | Reserved                                         | NC   |             |
| C64  | RSVD18         | Reserved                                         | NC   |             |
| C65  | PEG_RX4+       | PCI Express differential receive pairs           | I    |             |
| C66  | PEG_RX4-       | PCI Express differential receive pairs           | I    |             |
| C67  | RAPID_SHUTDOWN | Trigger for Rapid Shutdown. Must be driven to 5V | I PD |             |
| C68  | PEG_RX5+       | PCI Express differential receive pairs           | I    |             |
| C69  | PEG_RX5-       | PCI Express differential receive pairs           | I    |             |
| C70  | GND(FIXED)     | Ground                                           | GND  |             |
| C71  | PEG_RX6+       | PCI Express differential receive pairs           | I    |             |
| C72  | PEG_RX6-       | PCI Express differential receive pairs           | I    |             |
| C73  | GND            | Ground                                           | GND  |             |
| C74  | PEG_RX7+       | PCI Express differential receive pairs           | I    |             |
| C75  | PEG_RX7-       | PCI Express differential receive pairs           | I    |             |
| C80  | GND(FIXED)     | Ground                                           | GND  |             |
| C77  | RSVD18         | Reserved                                         | NC   |             |
| C78  | PEG_RX8+       | PCI Express differential receive pairs           | I    |             |
| C79  | PEG_RX8-       | PCI Express differential receive pairs           | I    |             |
| C80  | GND(FIXED)     | Ground                                           | GND  |             |
| C81  | PEG_RX9+       | PCI Express differential receive pairs           | I    |             |
| C82  | PEG_RX9-       | PCI Express differential receive pairs           | I    |             |
| C83  | RSVD18         | Reserved                                         | NC   |             |
| C84  | GND            | Ground                                           | GND  |             |
| C85  | PEG_RX10+      | PCI Express differential receive pairs           | I    |             |
| C86  | PEG_RX10-      | PCI Express differential receive pairs           | I    |             |
| C87  | GND            | Ground                                           | GND  |             |
| C88  | PEG_RX11+      | PCI Express differential receive pairs           | I    |             |
| C89  | PEG_RX11-      | PCI Express differential receive pairs           | I    |             |
| C90  | GND(FIXED)     | Ground                                           | GND  |             |
| C91  | PEG_RX12+      | PCI Express differential receive pairs           | I    |             |
| C92  | PEG_RX12-      | PCI Express differential receive pairs           | I    |             |
| C93  | GND            | Ground                                           | GND  |             |
| C94  | PEG_RX13+      | PCI Express differential receive pairs           | I    |             |
| C95  | PEG_RX13-      | PCI Express differential receive pairs           | I    |             |
| C96  | GND            | Ground                                           | GND  |             |
| C97  | RSVD18         | Reserved                                         | I/O  | TQ-flexiCFG |
| C98  | PEG_RX14+      | PCI Express differential receive pairs           | I    |             |
| C99  | PEG_RX14-      | PCI Express differential receive pairs           | I    |             |
| C100 | GND(FIXED)     | Ground                                           | GND  |             |
| C101 | PEG_RX15+      | PCI Express differential receive pairs           | I    |             |
| C102 | PEG_RX15-      | PCI Express differential receive pairs           | I    |             |
| C103 | GND            | Ground                                           | GND  |             |
| C104 | VCC_12V        | Primary wide power input                         | PWR  |             |
| C105 | VCC_12V        | Primary wide power input                         | PWR  |             |
| C106 | VCC_12V        | Primary wide power input                         | PWR  |             |
| C107 | VCC_12V        | Primary wide power input                         | PWR  |             |
| C108 | VCC_12V        | Primary wide power input                         | PWR  |             |
| C109 | VCC_12V        | Primary wide power input                         | PWR  |             |
| C110 | GND(FIXED)     | Ground                                           | GND  |             |



## COM Express™ Connector Pin Assignment (continued)

| Pin  | Pin-Signal         | Description                                      | Type | Remark      |
|------|--------------------|--------------------------------------------------|------|-------------|
| D1   | GND(FIXED)         | Ground                                           | GND  |             |
| D2   | GND                | Ground                                           | GND  |             |
| D3   | USB_SSTX0-         | SuperSpeed USB3.2 differential transmit pairs    | O    |             |
| D4   | USB_SSTX0+         | SuperSpeed USB3.2 differential transmit pairs    | O    |             |
| D5   | GND                | Ground                                           | GND  |             |
| D6   | USB_SSTX1-         | SuperSpeed USB3.2 differential transmit pairs    | O    |             |
| D7   | USB_SSTX1+         | SuperSpeed USB3.2 differential transmit pairs    | O    |             |
| D8   | GND                | Ground                                           | GND  |             |
| D9   | USB_SSTX2-         | SuperSpeed USB3.2 differential transmit pairs    | O    |             |
| D10  | USB_SSTX2+         | SuperSpeed USB3.2 differential transmit pairs    | O    |             |
| D11  | GND(FIXED)         | Ground                                           | GND  |             |
| D12  | USB_SSTX3-         | SuperSpeed USB3.2 differential transmit pairs    | O    |             |
| D13  | USB_SSTX3+         | SuperSpeed USB3.2 differential transmit pairs    | O    |             |
| D14  | GND                | Ground                                           | GND  |             |
| D15  | DDI1_CTRLCLK_AUX+  | DDI1_CTRLCLK_AUX+ signal DP AUX, HDMI DVI CLK    | IO   |             |
| D16  | DDI1_CTRLDATA_AUX- | DDI1_CTRLDATA_AUX- signal DP AUX, HDMI DVI DATA  | IO   |             |
| D17  | RSVD18             | Reserved                                         | NC   |             |
| D18  | RSVD18             | Reserved                                         | NC   |             |
| D19  | PCIE_TX6+          | PCI Express differential transmit pairs          | O    |             |
| type | PCIE_TX6-          | PCI Express differential transmit pairs          | O    |             |
| D21  | GND(FIXED)         | Ground                                           | GND  |             |
| D22  | PCIE_TX7+          | PCI Express differential transmit pairs          | O    |             |
| D23  | PCIE_TX7-          | PCI Express differential transmit pairs          | O    |             |
| D24  | (RSVD) SER1_RTS#   | Serial port 1 Request To Send                    | O    | TQ-flexiCFG |
| D25  | (RSVD) SER1_CTS#   | Serial port 1 Clear To Send                      | I PU | TQ-flexiCFG |
| D26  | DDI1_PAIR0+        | DDI1 DP / HDMI / DVI differential pairs 0        | O    |             |
| D27  | DDI1_PAIR0-        | DDI1 DP / HDMI / DVI differential pairs 0        | O    |             |
| D28  | RSVD18             | Reserved                                         | NC   |             |
| D29  | DDI1_PAIR1+        | DDI1 DP / HDMI / DVI differential pairs 1        | O    |             |
| D30  | DDI1_PAIR1-        | DDI1 DP / HDMI / DVI differential pairs 1        | O    |             |
| D31  | GND(FIXED)         | Ground                                           | GND  |             |
| D32  | DDI1_PAIR2+        | DDI1 DP / HDMI / DVI differential pairs 2        | O    |             |
| D33  | DDI1_PAIR2-        | DDI1 DP / HDMI / DVI differential pairs 2        | O    |             |
| D34  | DDI1_DDC_AUX_SEL   | Selects the function of DDI1_CTRLxAUX+/- Signals | I PD |             |
| D35  | RSVD18             | Reserved                                         | NC   |             |
| D36  | DDI1_PAIR3+        | DDI1 DP / HDMI / DVI differential pairs 3        | O    |             |
| D37  | DDI1_PAIR3-        | DDI1 DP / HDMI / DVI differential pairs 3        | O    |             |
| D38  | RSVD18             | Reserved                                         | NC   |             |
| D39  | DDI2_PAIR0+        | DDI2 DP / HDMI / DVI differential pairs 0        | O    |             |
| D40  | DDI2_PAIR0-        | DDI2 DP / HDMI / DVI differential pairs 0        | O    |             |
| D41  | GND(FIXED)         | Ground                                           | GND  |             |
| D42  | DDI2_PAIR1+        | DDI2 DP / HDMI / DVI differential pairs 1        | O    |             |
| D43  | DDI2_PAIR1-        | DDI2 DP / HDMI / DVI differential pairs 1        | O    |             |
| D44  | DDI2_HPD           | DDI2 Detection of Hot Plug                       | I PD |             |
| D45  | RSVD18             | Reserved                                         | NC   |             |
| D46  | DDI2_PAIR2+        | DDI2 DP / HDMI / DVI differential pairs 2        | O    |             |
| D47  | DDI2_PAIR2-        | DDI2 DP / HDMI / DVI differential pairs 2        | O    |             |
| D48  | RSVD18             | Reserved                                         | NC   |             |
| D49  | DDI2_PAIR3+        | DDI2 DP / HDMI / DVI differential pairs 3        | O    |             |
| D50  | DDI2_PAIR3-        | DDI2 DP / HDMI / DVI differential pairs 3        | O    |             |
| D51  | GND(FIXED)         | Ground                                           | GND  |             |
| D52  | PEG_TX0+           | PCI Express differential transmit pairs          | O    |             |
| D53  | PEG_TX0-           | PCI Express differential transmit pairs          | O    |             |
| D54  | PEG_LANE_RV#       | PCI Express Graphics lane reversal input strap   | I PU |             |
| D55  | PEG_TX1+           | PCI Express differential transmit pairs          | O    |             |



## COM Express™ Connector Pin Assignment (continued)

| Pin  | Pin-Signal | Description                             | Type | Remark      |
|------|------------|-----------------------------------------|------|-------------|
| D56  | PEG_TX1-   | PCI Express differential transmit pairs | O    |             |
| D57  | TYPE2#     | Type 2 Module indication (GND)          | O    |             |
| D58  | PEG_TX2+   | PCI Express differential transmit pairs | O    |             |
| D59  | PEG_TX2-   | PCI Express differential transmit pairs | O    |             |
| D60  | GND(FIXED) | Ground                                  | GND  |             |
| D61  | PEG_TX3+   | PCI Express differential transmit pairs | O    |             |
| D62  | PEG_TX3-   | PCI Express differential transmit pairs | O    |             |
| D63  | RSVD18     | Reserved                                | NC   |             |
| D64  | RSVD18     | Reserved                                | NC   |             |
| D65  | PEG_TX4+   | PCI Express differential transmit pairs | O    |             |
| D66  | PEG_TX4-   | PCI Express differential transmit pairs | O    |             |
| D67  | GND        | Ground                                  | GND  |             |
| D68  | PEG_TX5+   | PCI Express differential transmit pairs | O    |             |
| D69  | PEG_TX5-   | PCI Express differential transmit pairs | O    |             |
| D70  | GND(FIXED) | Ground                                  | GND  |             |
| D71  | PEG_TX6+   | PCI Express differential transmit pairs | O    |             |
| D72  | PEG_TX6-   | PCI Express differential transmit pairs | O    |             |
| D73  | GND        | Ground                                  | GND  |             |
| D74  | PEG_TX7+   | PCI Express differential transmit pairs | O    |             |
| D75  | PEG_TX7-   | PCI Express differential transmit pairs | O    |             |
| D76  | GND        | Ground                                  | GND  |             |
| D77  | RSVD18     | Reserved                                | NC   |             |
| D78  | PEG_TX8+   | PCI Express differential transmit pairs | O    |             |
| D79  | PEG_TX8-   | PCI Express differential transmit pairs | O    |             |
| D80  | GND(FIXED) | Ground                                  | GND  |             |
| D81  | PEG_TX9+   | PCI Express differential transmit pairs | O    |             |
| D82  | PEG_TX9-   | PCI Express differential transmit pairs | O    |             |
| D83  | RSVD18     | Reserved                                | NC   |             |
| D84  | GND        | Ground                                  | GND  |             |
| D85  | PEG_TX10+  | PCI Express differential transmit pairs | O    |             |
| D86  | PEG_TX10-  | PCI Express differential transmit pairs | O    |             |
| D87  | GND        | Ground                                  | GND  |             |
| D88  | PEG_TX11+  | PCI Express differential transmit pairs | O    |             |
| D89  | PEG_TX11-  | PCI Express differential transmit pairs | O    |             |
| D90  | GND(FIXED) | Ground                                  | GND  |             |
| D91  | PEG_TX12+  | PCI Express differential transmit pairs | O    |             |
| D92  | PEG_TX12-  | PCI Express differential transmit pairs | O    |             |
| D93  | GND        | Ground                                  | GND  |             |
| D94  | PEG_TX13+  | PCI Express differential transmit pairs | O    |             |
| D95  | PEG_TX13-  | PCI Express differential transmit pairs | O    |             |
| D96  | GND        | Ground                                  | GND  |             |
| D97  | RSVD18     | Reserved                                | I PU | TQ-flexiCFG |
| D98  | PEG_TX14+  | PCI Express differential transmit pairs | O    |             |
| D99  | PEG_TX14-  | PCI Express differential transmit pairs | O    |             |
| D100 | GND(FIXED) | Ground                                  | GND  |             |
| D101 | PEG_TX15+  | PCI Express differential transmit pairs | O    |             |
| D102 | PEG_TX15-  | PCI Express differential transmit pairs | O    |             |
| D103 | GND        | Ground                                  | GND  |             |
| D104 | VCC_12V    | Primary wide power input                | PWR  |             |
| D105 | VCC_12V    | Primary wide power input                | PWR  |             |
| D106 | VCC_12V    | Primary wide power input                | PWR  |             |
| D107 | VCC_12V    | Primary wide power input                | PWR  |             |
| D108 | VCC_12V    | Primary wide power input                | PWR  |             |
| D109 | VCC_12V    | Primary wide power input                | PWR  |             |
| D110 | GND(FIXED) | Ground                                  | GND  |             |

## 4. MECHANICS

### 4.1 Dimensions

The TQMx110EB has a dimensions of 125 mm × 95 mm ( $\pm 0.2$  mm).  
The following figure shows the TQMx110EB three view drawing.




Figure 4: TQMx110EB three view drawing

The following illustration shows the TQMx110EB bottom view.




Figure 5: TQMx110EB Bottom View Drawing





### 4.3 Heat Spreader

A heat spreader "TQMx110EB-HSP" is available for the TQMx110EB.

The TQMx110EB is available with or without mounted heat spreader.

The provided heat spreader complies with the latest COM Express™ specification (13 mm  $\pm$  0.2 mm, including PCB).

The following illustration shows the heat spreader (TQMx110EB-HSP) for the TQMx110EB.




Figure 8: TQMx110EB-HSP Heat Spreader

The White Paper "Heat Spreader Mounting Instruction" provides information how to mount the heat spreader.

Please contact [support@tq-group.com](mailto:support@tq-group.com) for more details about 2D/3D STEP models.

### 4.4 Mechanical and Thermal Considerations

The TQMx110EB is designed to operate within a wide range of thermal environments.

An important factor for each system integration is the thermal design. The heat spreader provides the thermal coupling to the TQMx110EB. The heat spreader is thermally coupled to the processor and provides optimal heat transfer from the TQMx110EB to the heat sink. The heat spreader itself is not an appropriate heat sink.

System designers can implement passive and active cooling systems using the thermal connection to the heat spreader.

#### Attention: Thermal Considerations



Do not operate the TQMx110EB without properly attached heat spreader and heat sink!

If a special cooling solution has to be implemented an extensive thermal design analysis and verification has to be performed. TQ-Systems GmbH offers thermal analysis and simulation as a service.

### 4.5 Protection against External Effects

The TQMx110EB itself is not protected against dust, external impact and contact (IP00).

Adequate protection has to be guaranteed by the surrounding system and carrier board.

Conformal coating can be offered for harsh environment applications.



## 5. SOFTWARE

### 5.1 System Resources

#### 5.1.1 I<sup>2</sup>C Bus Devices

The TQMx110EB provides a general purpose I<sup>2</sup>C port via a dedicated LPC to I<sup>2</sup>C controller in the TQ-flexiCFG block. The following table shows the I<sup>2</sup>C address mapping for the COM Express™ I<sup>2</sup>C port.

Table 19: I<sup>2</sup>C Address Mapping COM Express™ I<sup>2</sup>C Port

| 8-bit Address | Function             | Remark                                      |
|---------------|----------------------|---------------------------------------------|
| 0xA0          | Module EEPROM        | –                                           |
| 0xAE          | Carrier board EEPROM | Embedded EEPROM configuration not supported |

#### 5.1.2 SMBus Devices

The TQMx110EB provides a System Management Bus (SMBus). The following table shows the I<sup>2</sup>C address mapping for the COM Express™ SMBus port.

Table 20: I<sup>2</sup>C Address Mapping COM Express™ SMBus Port

| 8-bit Address | Function                | Remark                    |
|---------------|-------------------------|---------------------------|
| 0xA0, 0xA4    | SO-DIMM SPD EEPROMs     | Only accessed by the BIOS |
| 0x30, 0x34    | SO-DIMM Thermal Sensors | –                         |
| 0x58          | Hardware Monitor        | –                         |

#### 5.1.3 Memory Mapping

The TQMx110EB supports the standard PC system memory and I/O memory map.

#### 5.1.4 Interrupt Mapping

The TQMx110EB supports the standard PC Interrupt routing. The integrated legacy devices (COM1, COM2) can be configured via the BIOS to IRQ3 and IRQ4.



## 5.2 Operating Systems

### 5.2.1 Supported Operating Systems

The TQMx110EB supports several Operating Systems:

- Microsoft® Windows® 10 (IoT) Enterprise(64-bit) LTSC RS5 or later
- Linux (i.e. Ubuntu 21.10 or later)

Other Operating Systems are supported on request.

Please contact [support@tq-group.com](mailto:support@tq-group.com) for further information about supported Operating Systems.

### 5.2.2 Driver Download

The TQMx110EB is well supported by the Standard Operating Systems, which already include most of the drivers required. It is recommended to use the latest Intel® drivers to optimize performance and make use of the full TQMx110EB feature set.

The White Paper “Windows Driver Installation Instructions” provides information how to install the Windows driver.

Please contact [support@tq-group.com](mailto:support@tq-group.com) for further driver download assistance.

## 5.3 TQ-Systems Embedded Application Programming Interface (EAPI)

The TQ-Systems Embedded Application Programming Interface (EAPI) is a driver package to access and control hardware resources on all TQ-Systems COM Express™ modules. The TQ-Systems EAPI is compatible with the PICMG® specification.

## 5.4 Software Tools

Please contact [support@tq-group.com](mailto:support@tq-group.com) for further information about available software tools.

## 6. BIOS – MENU

The TQMx110EB uses a 64-bit uEFI BIOS.

To access the InsydeH2O BIOS Front Page, the button <ESC> has to be pressed after System Power-Up during POST phase.

If the button is successfully pressed, you will get to the BIOS front page, which shows the main menu items.

For Help Dialog please press <F1>.




Figure 9: InsydeH2O BIOS Front Page

### 6.1 Continue

Continue boot process the same way if <ESC> was not pressed.

### 6.2 Boot Manager

Choose between possible boot options. One boot option will always be "Internal EFI Shell".

You can go back to "Boot Manager" by entering command "exit" and press <ENTER>.

## 6.3 Device Manager

### 6.3.1 Driver Health Manager

List all the driver health instances to manage.

### 6.3.2 Network Device List

Select the network device according the MAC address.

## 6.4 Boot from File

Boot from a specific mass storage device where a boot file is stored.

## 6.5 Administer Secure Boot

Enable and configure Secure Boot mode. This option can be also used to integrate PK, KEK, DB and DBx.

### Note: Secure Boot



This option should only be used by advanced users.



## 6.6 Setup Utility

A basic setup of the board can be done by Insyde Software Corp. "Insyde Setup Utility" stored inside an on-board SPI flash. To get access to InsydeH2O Setup Utility the button <ESC> has to be pressed after System Power Up during POST phase. After that, the sentence "ESC is pressed. Go to boot options" is displayed below the boot logo. Select "Setup Utility" on the splash screen that appears. The left frame of each menu page shows the option that can be configured, while the right frame shows the corresponding help.

### Key:

|             |                                                                                                                                                                                                                              |
|-------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ↑ / ↓       | Navigate between setup items.                                                                                                                                                                                                |
| ← / →       | Navigate between setup screens (Main, Advanced, Security, Power, Boot and Exit).                                                                                                                                             |
| <F1>        | Show general help screen (Key Legend).                                                                                                                                                                                       |
| <F5> / <F6> | In the main screen this buttons allow to change between different languages. Otherwise it allows to change the value of highlighted menu item.                                                                               |
| <ENTER>     | Press to display or change setup option listed for a certain menu or to display setup sub-screens.                                                                                                                           |
| <F9>        | Press to load the setup default configuration of the board which cannot be changed by the user. This option has to be confirmed and saved by <F10> afterwards. Leaving the InsydeH2O Setup Utility will discard the changes. |
| <F10>       | Press to save any changes made and exit setup utility by executing a restart.                                                                                                                                                |
| <ESC>       | Press to leave the current screen or sub-screen and discard all changes.                                                                                                                                                     |

### 6.6.1 Main

The Main screen shows details regarding the BIOS version, processor type, bus speed, memory configuration and further information. There are three options which can be configured.

| Menu Item   | Option                              | Description                                            |
|-------------|-------------------------------------|--------------------------------------------------------|
| Language    | English / French / Korean / Chinese | Configures the language of the InsydeH2O Setup Utility |
| System Time | HH:MM:SS                            | Use to change the system time to the 24-hour format    |
| System Date | MM:DD:YYYY                          | Use to change the system date                          |



## 6.6.2 Advanced

Use the right cursor to get from the main menu item to the advanced menu item.

| Menu Item                                | Option      | Description                                                    |
|------------------------------------------|-------------|----------------------------------------------------------------|
| Boot Configuration                       | See submenu | Configures settings for Boot Phase                             |
| SATA Configuration                       | See submenu | Shows Devices plugged                                          |
| USB Configuration                        | See submenu | Configure the USB support                                      |
| Chipset Configuration                    | See submenu | Advanced Chipset Configuration options                         |
| PCI Subsystem Settings                   | See submenu | PCI, PCI-X and PCI Express Settings                            |
| ACPI Table/Features Control              | See submenu | Configures ACPI Tables/Features setting                        |
| CPU Configuration                        | See submenu | CPU Configuration                                              |
| Power & Performance                      | See submenu | Power & Performance                                            |
| Intel® Time Coordinated Computing        | See submenu | Intel® Time Coordinated Computing (Intel® TCC) options         |
| Memory Configuration                     | See submenu | Memory Configuration Parameters                                |
| System Agent (SA) Configuration          | See submenu | System Agen (SA) Parameters                                    |
| PCIE Configuration                       | See submenu | PCIE Parameters                                                |
| PCH-IO Configuration                     | See submenu | PCH Parameters                                                 |
| PCH-FW Configuration                     | See submenu | Configure Management Engine Technology Parameters              |
| ACPI D3Cold Settings                     | See submenu | ACPI D3Cold related settings                                   |
| SIO TQMx86                               | See submenu | Configure CPLD UARTs, TQ Board specific configuration and LVDS |
| SIO Hardware Monitor<br>Nuvoton NCT7802Y | See submenu | Hardware Monitor and Fan parameters                            |
| Console Redirection                      | See submenu | Configure Console Redirection settings                         |
| SIO F81214E                              | See submenu | Configure UARTs of Fintek Super I/O F81214E                    |

### 6.6.2.1 Boot Configuration

*Setup Utility ⇒ Advanced ⇒ Boot Configuration*

| Menu Item | Option   | Description                                                                  |
|-----------|----------|------------------------------------------------------------------------------|
| Numlock   | On / Off | Allows to choose whether NumLock key at system boot must be turned On or Off |

### 6.6.2.2 SATA Configuration

*Setup Utility ⇒ Advanced ⇒ SATA Configuration*

| Menu Item         | Option | Description                |
|-------------------|--------|----------------------------|
| Serial ATA Port X | -      | Shows SATA devices plugged |





### 6.6.2.3 USB Configuration

*Setup Utility ⇒ Advanced ⇒ USB Configuration*

| Menu Item                | Option             | Description                                                |
|--------------------------|--------------------|------------------------------------------------------------|
| USB BIOS Support         | Enabled / Disabled | USB keyboard/mouse/storage support under UEFI environment. |
| USB Legacy SMI bit Clean | Enabled / Disabled | Clean USB Legacy SMI bit for xHCI and EHCI                 |

### 6.6.2.4 Chipset Configuration

*Setup Utility ⇒ Advanced ⇒ Chipset Configuration*

| Menu Item                 | Option             | Description                               |
|---------------------------|--------------------|-------------------------------------------|
| Platform Trust Technology | Enabled / Disabled | Enable/Disable Platform Trust Technology. |

### 6.6.2.5 PCI Subsystem Settings

*Setup Utility ⇒ Advanced ⇒ PCI Subsystem Settings*

| Menu Item                           | Option                                                                                                                                                                                  | Description                                                                                                                                          |
|-------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------|
| PCI ROM Priority                    | Legacy ROM / EFI Compatible ROM                                                                                                                                                         | In case of multiple Option ROMs (Legacy and EFI Compatible), specifies what PCI Option rom to launch.                                                |
| External DMA Allowed On Boot        | No / Yes                                                                                                                                                                                | External DMA Allowed On Boot for devices such as 1394, PCMC1A & CardBus.                                                                             |
| Install Ext OpRom Before BIOS Setup | Disabled /<br>Ext PCIE Storage OpRom /<br>Ext PCIE Other OpRom /<br>Ex PCIE Both Storage and Other OpRom                                                                                | Install Ext OpRom for Storage or Other device before BIOS Setup. That we can get the Ext PCIE Card OpRom Setup Menu and have chance to enter into it |
| PCI Latency Timer                   | 32 PCI Bus Clocks /<br>64 PCI Bus Clocks /<br>96 PCI Bus Clocks /<br>128 PCI Bus Clocks /<br>160 PCI Bus Clocks /<br>192 PCI Bus Clocks /<br>224 PCI Bus Clocks /<br>248 PCI Bus Clocks | Value to be programmed into PCI Latency Timer Register                                                                                               |



### 6.6.2.6 ACPI Table/Features Control

*Setup Utility ⇒ Advanced ⇒ ACPI Table/Features Control*

| Menu Item            | Option             | Description                                                                                                                                                                                                                                                                                             |
|----------------------|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ACPI Settings        | See submenu        | System ACPI Parameters                                                                                                                                                                                                                                                                                  |
| FACP – RTC S4 Wakeup | Enabled / Disabled | Value only for ACPI. Enable/Disable for S4 Wakeup from RTC.                                                                                                                                                                                                                                             |
| APIC – IO APIC Mode  | Enabled / Disabled | This item is valid only for WIN2k and WINXP. Also, a fresh install of the OS must occur when APIC Mode is desired. Test the IO ACPI by setting item to Enable. The APIC Table will then be pointed to by the RSDT, the Local APIC will be initialized, and the proper enable bits will be set in ICH4M. |

*Setup Utility ⇒ Advanced ⇒ RC Advanced Menu ⇒ ACPI Settings*

| Menu Item                      | Option                    | Description                                                                                                                                                                               |
|--------------------------------|---------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Enable ACPI Auto Configuration | [ ] / [X]                 | Enables or disables BIOS ACPI auto configuration                                                                                                                                          |
| Enable Hibernation             | [ ] / [X]                 | Enables or disables system ability to hibernate (OS/S4 Sleep State). This option may not be effective with some OSs.                                                                      |
| PTID Support                   | [ ] / [X]                 | PTID support will be loaded if enabled.                                                                                                                                                   |
| PECI Access Method             | Direct I/O / ACPI         | PECI access method is Direct I/O or ACPI.                                                                                                                                                 |
| ACPI S3 support                | Enabled / Disabled        | Enable ACPI S3 support.                                                                                                                                                                   |
| Native ASPM                    | Auto / Enabled / Disabled | Enabled – OS controlled ASPM<br>Disabled – BIOS controlled ASPM                                                                                                                           |
| BDAT ACPI Table Support        | Enabled / Disabled        | Enables support for the BDAT ACPI table                                                                                                                                                   |
| ACPI Debug                     | Enabled / Disabled        | Open a memory buffer for storing debug strings. Reenter SETUP after enabling to see the buffer address. Use method ADBG to write strings to buffer.                                       |
| Low Power S0 Idle Capability   | Enabled / Disabled        | This variable determines if ACPI Lower Power S0 Idle Capability is enabled (Mutually exclusive with Smart connect). While this is enabled, it also disable 8254 timer for SLP_S0 support. |
| SSDT table from file           | Enabled / Disabled        | SSDT table from file.                                                                                                                                                                     |
| PCI Delay Optimization         | Enabled / Disabled        | Experimental ACPI additions for FW latency optimizations.                                                                                                                                 |
| MSI enabled                    | Enabled / Disabled        | When disabled, MSI support is disabled in FADT.                                                                                                                                           |

### 6.6.2.7 CPU Configuration

*Setup Utility ⇒ Advanced ⇒ CPU Configuration*

| Menu Item                             | Options            | Description                                                                                             |
|---------------------------------------|--------------------|---------------------------------------------------------------------------------------------------------|
| Hardware Prefetcher                   | Enabled / Disabled | To turn on/off the MLC streamer prefetcher.                                                             |
| Adjacent Cache Line Prefetch          | Enabled / Disabled | To turn on/off prefetching of adjacent cache lines.                                                     |
| Intel (VMX) Virtualization Technology | Enabled / Disabled | When enabled, a VMM can utilize the additional hardware capabilities provided by Vanderpool Technology. |
| PECI                                  | Enabled / Disabled | Enable/Disable PECI.                                                                                    |
| AVX                                   | Enabled / Disabled | Enable/Disable AVX 2/3 Instructions.                                                                    |
| AVX3                                  | Enabled / Disabled | Enable/disable AVX 3 Instructions.                                                                      |
| Active Processor Cores                | All / 1 / 2 / 3    | Number of cores to enable in each processor package.                                                    |



| Menu Item       | Options            | Description                                           |
|-----------------|--------------------|-------------------------------------------------------|
| Hyper-Threading | Enabled / Disabled | Enable or Disable Hyper-Threading Technology.         |
| BIST            | Enabled / Disabled | Enable or Disable BIST (Built-In Self-Test) on reset. |
| AES             | Enabled / Disabled | Enable or Disable AES (Advanced Encryption Standard). |
| MachineCheck    | Enabled / Disabled | Enable or Disable Machine Check.                      |
| MonitorMWait    | Enabled / Disabled | Enable or Disable MonitorMWait.                       |

#### 6.6.2.8 Power & Performance

*Setup Utility ⇒ Advanced ⇒ Power & Performance*

| Menu Item                      | Options     | Description                            |
|--------------------------------|-------------|----------------------------------------|
| CPU – Power Management Control | See submenu | CPU – Power Management Control Options |
| GT – Power Management Control  | See submenu | GT – Power Management Control Options  |

*Setup Utility ⇒ Advanced ⇒ Power & Performance ⇒ CPU – Power Management Control*

| Menu Item                                       | Options                                                           | Description                                                                                                                                                                                                                                                  |
|-------------------------------------------------|-------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Boot performance mode                           | Max Battery /<br>Max Non-Turbo Performance /<br>Turbo Performance | Select the performance state that the BIOS will set starting from reset vector.                                                                                                                                                                              |
| Intel® SpeedStep™                               | Enabled / Disabled                                                | Allows more than two frequency ranges to be supported.                                                                                                                                                                                                       |
| Race To Halt (RTH)                              | Enabled / Disabled                                                | Enable or Disable Race To Halt feature. RTH will dynamically increase CPU frequency in order to enter pkg C-State faster to reduce overall power. (RTH is controlled through MSR 1FC bit 20)                                                                 |
| Intel® Speed Shift Technology                   | Enabled / Disabled                                                | Enable or Disable Intel® Speed Shift Technology support. Enabling will expose the CPPC v2 interface to allow for hardware controlled P-states.                                                                                                               |
| Intel® Speed Shift Technology Interrupt Control | Enabled / Disabled                                                | Enable/Disable Intel® Speed Shift Technology Interrupts                                                                                                                                                                                                      |
| Intel® Turbo Boost Max Technology 3.0           | Enabled / Disabled                                                | Enable/Disable Intel® Turbo Boost Max Technology 3.0 support. Disabling will report the maximum ratio of the slowest core in _CPC object.                                                                                                                    |
| Per Core P State OS control mode                | Enabled / Disabled                                                | Enable/Disable Per Core P state OS control mode. Disabling will set Bit 31 = 1 command 0x06. When set, the highest core request is used for all other core requests.                                                                                         |
| HwP Autonomous Per Core P State                 | Enabled / Disabled                                                | Disable Autonomous PCPS (Bit 30 = 1, command 0x11) Autonomous will request the same value for all cores all the time. Enable PCPS (default Bit 30 = 0, command 0x11)                                                                                         |
| HwP Autonomous EPP Grouping                     | Enabled / Disabled                                                | Enable EPP grouping (default Bit 29 = 0, command 0x11) Autonomous will request the same values for all cores with same ePP. Disable EPP grouping (Bit 29 = 1, command 0x11) autonomous will not necessarily request same values for all cores with same EPP. |
| HwP Fast MSR Support                            | Enabled / Disabled                                                | Enable/Disable HwP Fast MSR Support for IA32_HWP_REQUEST MSR.                                                                                                                                                                                                |
| HDC Control                                     | Enabled / Disabled                                                | This option allows HDC configuration.<br>Disabled: Disable HDC<br>Enabled: Can be enabled by OS if OS native support is available.                                                                                                                           |
| Turbo Mode                                      | Enabled / Disabled                                                | Enable or Disable processor Turbo Mode (requires Intel® Speed Step or Intel® Speed Shift to be available and enabled).                                                                                                                                       |
| View/Configure Turbo Options                    | See submenu                                                       | Configure Turbo Options.                                                                                                                                                                                                                                     |



| Menu Item                            | Options                                                              | Description                                                                                                                                                                                                     |
|--------------------------------------|----------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Config TDP Configurations            | See submenu                                                          | Configure TDP Options.                                                                                                                                                                                          |
| Platform PL1 Enable                  | Enabled / Disabled                                                   | Enable/Disable Platform Power Limit 1 programming. If this option is enabled. It activates the PL1 value to be used by the processor to limit the average power of given time window.                           |
| Platform PL2 Enable                  | Enabled / Disabled                                                   | Enable/Disable Platform Power Limit 2 programming. If this option is disabled, BIOS will program the default values for Platform Power Limit 2.                                                                 |
| Power Limit 3 Settings               | See submenu                                                          | Power Limit 3 Settings.                                                                                                                                                                                         |
| Power Limit 4 Override               | Enabled / Disabled                                                   | Enable/Disable Power Limit 4 override. If this option is disabled, BIOS will leave the default values for Power Limit 4.                                                                                        |
| C states                             | Enabled / Disabled                                                   | Enable or Disable CPU Power Management. Allows CPU to go to C states when it's not 100% utilized.                                                                                                               |
| C-State Auto Demotion                | Disabled / C1 / C3 / C1 and C3                                       | Configure C-State Auto Demotion.<br>This option will be hidden if C states is Disabled.                                                                                                                         |
| C-State Un-demotion                  | Disabled / C1 / C3 / C1 and C3                                       | Configure C-State Un-demotion.<br>This option will be hidden if C states is Disabled.                                                                                                                           |
| Package C-State Demotion             | Enabled / Disabled                                                   | Package C-State Demotion.<br>This option will be hidden if C states is Disabled.                                                                                                                                |
| Package C-State Un-demotion          | Enabled / Disabled                                                   | Package C-State Un-demotion.<br>This option will be hidden if C states is Disabled.                                                                                                                             |
| CState Pre-Wake                      | Enabled / Disabled                                                   | Disabled: Sets bit 30 of Power_CTL MSR (0x1FC) to 1 to disable the CState Pre-Wake.<br>This option will be hidden if C states is Disabled.                                                                      |
| IO MWAIT Redirection                 | Enabled / Disabled                                                   | When set, will map IO_read instructions sent to IO registers PMG_IO_BASE_ADDRBASE + offset to MWAIT(offset)                                                                                                     |
| Package C State Limit                | C0/C1 / C2 / C3 / C6 / C7 / C7S / C8 / C9 / C10 / CPU Default / Auto | Maximum Package C State Limit Setting.<br>CPU Default: Leaves to Factory default value.<br>Auto: Initializes to deepest available Package C State Limit.<br>This option will be hidden if C states is Disabled. |
| Thermal Monitor                      | Enabled / Disabled                                                   | Enable or Disable Thermal Monitor.<br>This option will be hidden if C states is Disabled.                                                                                                                       |
| Interrupt Redirection Mode Selection | Fixed Priority / Round robin / Hash Vector / No Change               | Interrupt Redirection Mode Select for Logical Interrupts.                                                                                                                                                       |
| Timed MWAIT                          | Enabled / Disabled                                                   | Enable/Disable Timed MWAIT Support.                                                                                                                                                                             |
| CPU Lock Configuration               | See submenu                                                          | CPU Lock Configuration.                                                                                                                                                                                         |

*Setup Utility ⇒ Advanced ⇒ Power & Performance ⇒ CPU – Power Management Control Submenu ⇒ View/Configure Turbo Options*

| Menu Item                    | Options            | Description                                                                                                                                                                                                                                                                                                                                                                                 |
|------------------------------|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Energy Efficient P-state     | Enabled / Disabled | Enable/Disable Energy Efficient P-state feature. When set to 0, will disable access to ENERGY_PERFORMANCE_BIAS MSR and CPUID Function 6 ECX[3] will read 0 indicating no support for Energy Efficient policy setting. When set to 1 will enable access to ENERGY_PERFORMANCE_BIAS MSR 1B0h and CPUID Function 6 ECX[3] will read 1 indicating Energy Efficient policy setting is supported. |
| Package Power Limit MSR Lock | Enabled / Disabled | Enable/Disable locking of Package Power Limit settings. When enabled, PACKAGE_POWER_LIMIT MSR will be locked and a reset will                                                                                                                                                                                                                                                               |



| Menu Item                                      | Options            | Description                                                                                                                                                                                                                                                       |
|------------------------------------------------|--------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                                                |                    | be required to unlock the register.                                                                                                                                                                                                                               |
| X-Core Turbo Ratio Limit Ratio (TRLR) override | [ X ]              | X-Core Turbo Ratio Limit Ratio (TRLR) with range of Max Non-Turbo Ratio up to 120.                                                                                                                                                                                |
| Energy Efficient Turbo                         | Enabled / Disabled | Enable/Disable Energy Efficient Turbo Feature. This feature will opportunistically lower the turbo frequency to increase efficiency. Recommended only to disable in overclocking situations where turbo frequency must remain constant. Otherwise, leave enabled. |

*Setup Utility ⇒ Advanced ⇒ Power & Performance ⇒ CPU – Power Management Control Submenu ⇒ Config TDP Configurations*

| Menu Item                        | Options                               | Description                                                                                                                                                                                                                                                                                                                 |
|----------------------------------|---------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Enable Configurable TDP          | Applies to non-cTDP / Applies to cTDP | Applies TDP initialization settings basen on non-cTDP or cTDP. Default is 1: Applies to cTDP; if 0 then applies to non cTDP and BIOS will bypass cTDP initialization flow.                                                                                                                                                  |
| Configurable TDP Boot Mode       | Nominal / Down / Up / Deactivate      | Configurable TDP Mode as Nominal/Up/Down/Deactivate TDP selection. Deactivate option will set MSR to Nominal and MMIO to Zero.                                                                                                                                                                                              |
| Configurable TDP Lock            | Enabled / Disabled                    | Configurable TDP Mode Lock sets the Lock bits on TURBO_ACTIVATION_RATIO and CONFIG_TDP_CONTROL.<br><u>Note:</u> When CTDP Lock is enabled Custom ConfigTDP Count will be forced to 1 and Custom ConfigTDP Boot index will be forced to 0.                                                                                   |
| Power Limit 1                    | 0 – X                                 | Power Limit 1 in milliwatts. BIOS will round to the nearest 1/8 W when programming.<br>0 = no custom override. For 12.50 W, enter 12500.<br>Overclocking SKU: Value must be between Max and Min Power Limits (specified by PACKAGE_POWER_SKU_MSR).<br>Other SKUs: This value must be between Min Power limit and TDP Limit. |
| Power Limit 2                    | 0 – X                                 | Power Limit 2 value in milliwatts. BIOS will round to the nearest 1/8 W when programming. 0 = no custom override. For 12.50 W, enter 12500. Processor applies control policies such that the package power does not exceed this limit.                                                                                      |
| Power Limit 1 Time Window        | 0 – 128                               | Power Limit 1 Time Window value in seconds.<br>The value may vary from 0 to 128.<br>0 = use default value (28 sec).<br>Defines time window which TDP value should be maintained.                                                                                                                                            |
| ConfigTDP Turbo Activation Ratio | 0 – 125                               | Custom value for Turbo Activation Ratio. Needs to be configured with valid values from LFM to Max Turbo. 0 means don't use custom value.                                                                                                                                                                                    |

*Setup Utility ⇒ Advanced ⇒ Power & Performance ⇒ CPU – Power Management Control Submenu ⇒ Power Limit 3 Settings*

| Menu Item                 | Options            | Description                                                                                                                                                                                                                                                                                                                                                                                |
|---------------------------|--------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Power Limit 3 Override    | Enabled / Disabled | Enable/Disable Power Limit 3 override. If this option is disabled, BIOS will leave the hardware default values for Power Limit 3 and Power limit 3 Time Window.                                                                                                                                                                                                                            |
| Power Limit 3             | [ X ]              | Power Limit 3 in Milli Watts. BIOS will round to the nearest 1/8W when programming. For 12.5W, enter 12500.<br>XE SKU: Any value can be programmed. Overclocking SKU: Value must be between Max and Min Power Limits (specified by PACKAGE_POWER_SKU_MSR).<br>Other SKUs: This value must be between Min Power Limit and TDP Limit. If value is 0, BIOS leaves the hardware default value. |
| Power Limit 3 Time Window | [ X ]              | Power Limit 3 Time Window value in Milli seconds. The value may vary from 3 to 64(max). Indicates the time window over which Power Limit 3 value should be maintained. If the value is 0, BIOS leaves the hardware default value.                                                                                                                                                          |



| Menu Item                | Options            | Description                                                                                                                                  |
|--------------------------|--------------------|----------------------------------------------------------------------------------------------------------------------------------------------|
| Power Limit 3 Duty Cycle | [ X ]              | Specify the duty cycle in percentage that the CPU is required to maintain over the configured time window. Range is 0-100                    |
| Power Limit 3 Lock       | Enabled / Disabled | Power Limit 3 MSR 615h Lock. When enabled PL3 configurations are locked during OS. When disabled PL3 configuration can be changed during OS. |

*Setup Utility ⇒ Advanced ⇒ Power & Performance ⇒ CPU – Power Management Control Submenu ⇒ CPU Lock Configuration*

| Menu Item         | Options            | Description                                                      |
|-------------------|--------------------|------------------------------------------------------------------|
| CFG Lock          | Enabled / Disabled | Configure MSR 0xE2[15]; CFG Lock bit                             |
| Overclocking Lock | Enabled / Disabled | Enable/Disable Overclocking Lock (BIT 20) in FLEX_RATIO(194) MSR |

*Setup Utility ⇒ Advanced ⇒ Power & Performance ⇒ GT – Power Management Control*

| Menu Item                  | Options                                | Description                                                                                                                                                    |
|----------------------------|----------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------|
| RC6 (Render Standby)       | Enabled / Disabled                     | Check to enable render standby support.                                                                                                                        |
| Maximum GT frequency       | Default Max Frequency / 100 – 1200 MHz | Maximum GT frequency limited by the user. Choose between 300 MHz (RPM) and 1150 MHz (RPO). Value beyond the range will be clipped to min/max supported by SKU. |
| Disable Turbo GT frequency | Enabled / Disabled                     | Enabled: Disables Turbo GT frequency.<br>Disabled: GT frequency is not limited.                                                                                |

#### 6.6.2.9 Intel® Time Coordinated Computing

*Setup Utility ⇒ Advanced ⇒ Intel® Time Coordinated Computing*

| Menu Item                 | Options            | Description                                                                                                                                                                                                                |
|---------------------------|--------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| #AC Split Lock            | Enabled / Disabled | Enable or Disable Alignment Check Exception (#AC). When enabled, this will assert an #AC when any atomic operation has an operand that crosses two cache lines.                                                            |
| IFU Enable                | Enabled / Disabled | Enable or Disable Instruction Fetch Unit (IFU). When enabled, Instructions will be prefetch to the cache.                                                                                                                  |
| Intel® TCC Authentication | OEM Enrolled Key   | Intel® TCC Authentication determines the key to be used. OEM Enrolled Key is built in by OEM. Non-OEM Enrolled Key can be add by user.                                                                                     |
| Intel® TCC Mode           | Enabled / Disabled | Enable or Disable Intel® TCC Mode. When enabled, this will modify system settings to improve real-time performance. The full list of settings and their current state are displayed below when Intel® TCC mode is enabled. |
| IO Fabric Low Latency     | Enabled / Disabled | Enable or Disable IO Fabric Low Latency. This will turn off some power management in the PCH IO fabrics. This option provides the most aggressive IO Fabric performance setting. S3 state is NOT supported!                |
| OPIO Recentering          | Enabled / Disabled | Enable or Disable Opio Recentering to improve PCIe latency.                                                                                                                                                                |



### 6.6.2.10 Memory Configuration

*Setup Utility ⇒ Advanced ⇒ Memory Configuration*

| Menu Item       | Option                                                         | Description                                                                               |
|-----------------|----------------------------------------------------------------|-------------------------------------------------------------------------------------------|
| REFRESH_2X_MODE | Disabled /<br>1-Enabled for WARM or HOT<br>2- Enabled HOT only | 0 – Disabled<br>1 – iMC enables 2xRef when Warm and Hot<br>2 – iMC enables 2xRef when Hot |

### 6.6.2.11 System Agent (SA) Configuration

*Setup Utility ⇒ Advanced ⇒ System Agent (SA) Configuration*

| Menu Item                       | Options            | Description                                                                                                                      |
|---------------------------------|--------------------|----------------------------------------------------------------------------------------------------------------------------------|
| Graphics Configuration          | See submenu        | Configure some graphical options.                                                                                                |
| DMI/OPI Configuration           | See submenu        | Control various DMI functions.                                                                                                   |
| VMD setup menu                  | See submenu        | VMD Configuration settings                                                                                                       |
| PCI Express Configuration       | See submenu        | PCI Express Configuration settings.                                                                                              |
| Stop Grant Configuration        | Auto / Manual      | Automatic/Manual stop grant configuration                                                                                        |
| VT-d                            | Enabled / Disabled | VT-d capability.                                                                                                                 |
| X2APIC Opt Out                  | Enabled / Disabled | Enable or Disable X2APIC_OPT_OUT bit.                                                                                            |
| DMA Control Guarantee           | Enabled / Disabled | Enable or Disable DMA_CONTROL_GUARANTEE bit.                                                                                     |
| Thermal Device (B0:D4:F0)       | Enabled / Disabled | Enable or Disable SA Thermal Device.                                                                                             |
| Cpu CrashLog (Device 10)        | Enabled / Disabled | Enable or Disable Cpu CrashLog Device.                                                                                           |
| GNA Device (B0:D8:F0)           | Enabled / Disabled | Enable or Disable SA GNA Device.                                                                                                 |
| CRID Support                    | Enabled / Disabled | Enable or Disable CRID control for Intel SIPP.                                                                                   |
| WRC Feature                     | Enabled / Disabled | Enable or Disable SA WRC (Write Cache) Feature of IOP. When enabled, supports IO devices allocating onto the ring and into LLC.  |
| VCRT mapping to PEG             | Enabled / Disabled | Enable or Disable VCRT mapping to PEG. When enabled, VCRT mapping to PEG.                                                        |
| Above 4 GB MMIO BIOS assignment | Enabled / Disabled | Enable or Disable above 4 GB MemoryMappedIO BIOS assignment. This is enabled automatically when Aperture Size is set to 2048 MB. |
| IPU Device (B0:D5:F0)           | Enabled / Disabled | Enable or Disable SA IPU Device.                                                                                                 |

*Setup Utility ⇒ Advanced ⇒ System Agent (SA) Configuration ⇒ Graphics Configuration*

| Menu Item                          | Option                                                                                                        | Description                                                                                                                                                                   |
|------------------------------------|---------------------------------------------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Graphics Turbo IMON Current        | [ X ]                                                                                                         | Graphics turbo IMON current values supported (14 – 31)                                                                                                                        |
| Skip Scanning of External Gfx Card | Enabled / Disabled                                                                                            | If enabled, it will not scan for External Gfx Card on PEG and PCH PCIE Ports.                                                                                                 |
| Internal Graphics                  | Auto / Enabled / Disabled                                                                                     | Keep IGFX enabled based on the setup options.                                                                                                                                 |
| GTT Size                           | 2MB / 4MB / 8MB                                                                                               | Select the GTT Size.                                                                                                                                                          |
| Aperture Size                      | 128MB / 256MB / 512MB /<br>1024MB / 2048MB                                                                    | Select the Aperture Size.<br>Note: Above 4 GB MMIO BIOS assignment is automatically enabled when selecting 2048 MB aperture. To use this feature, please disable CSM support. |
| PSMI SUPPORT                       | Enabled / Disabled                                                                                            | PSMI Enable/Disable                                                                                                                                                           |
| DVMT Pre-Allocated                 | 64M / 96M / 128M / 160M /<br>192M / 224M / 256M / 288M /<br>320M / 352M / 384M / 416M /<br>448M / 480M / 512M | Select DVMT5.0 (Dynamic Video Memory Technology) Pre-Allocated (fixed) Graphics Memory size used by the Internal Graphic Device.                                              |



| Menu Item                       | Option                                                                    | Description                                                                                                             |
|---------------------------------|---------------------------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------------|
| DVMT Total Gfx Mem              | 128M / 256M / MAX                                                         | Select the DVMT5.0 (Dynamic Video Memory Technology) total graphics memory size used by the Internal Graphics Device.   |
| DFD Restore                     | Enabled / Disabled                                                        | Select Display memory map programming for DFD Restore.                                                                  |
| DiSM Size                       | 0GB / 1GB / 2GB / 3GB / 4GB / 5GB / 6GB / 7GB                             | DiSM Size for 2LM Sku.                                                                                                  |
| Intel Graphics Pei Display Peim | Enabled / Disabled                                                        | Enable/Disable Pei (Early) Display.                                                                                     |
| VDD Enable                      | Enabled / Disabled                                                        | Enable/Disable forcing of VDD in the BIOS.                                                                              |
| Configure GT for use            | Enabled / Disabled                                                        | Enable/Disable GT configuration in BIOS.                                                                                |
| RC1p Support                    | Enabled / Disabled                                                        | Enable/Disable RC1p support. If RC1p is enabled, send a RC1p frequency request to PMA based other conditions being met. |
| PAVP Enable                     | Enabled / Disabled                                                        | Enable/Disable PAVP.                                                                                                    |
| Cdynmax Clamping Enable         | Enabled / Disabled                                                        | Enable/Disable Cdynmax Clamping.                                                                                        |
| Cd Clock Frequency              | 307.2 MHz / 556.8 MHz / 652 MHz / Max CdClock freq basen on Reference Clk | Select the highest Cd Clock frequency supported by the platform.                                                        |
| Skip Full CD Clock Init         | Enabled / Disabled                                                        | Enabled: Skip Full CD clock initialization.<br>Disabled: Initialize the full CD clock if not initialized by Gfx PEIM.   |
| IUER Button Enable              | Enabled / Disabled                                                        | Enable/Disable IUER Button Functionality.                                                                               |
| LCD Control                     | See submenu                                                               | LCD Control options.                                                                                                    |

*Setup Utility ⇒ Advanced ⇒ System Agent (SA) Configuration ⇒ Graphics Configuration ⇒ LCD Control*

| Menu Item                 | Option                                                                                                                                                                                                                                                                                                                                                                                     | Description                                                                                                                                                                                                                                       |
|---------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Primary IGFX Boot Display | VBIOS Default / EFP / LFP / EFP3 / EFP2 / EFP4                                                                                                                                                                                                                                                                                                                                             | Select the Video Device which will be activated during POST.<br>This has no effect if external graphics present.<br>Secondary boot display selection will appear based on your selection.<br>VGA modes will be supported only on primary display. |
| LCD Panel Type            | VBIOS Default /<br>640 × 480 LVDS /<br>800 × 600 LVDS /<br>1024 × 768 LVDS /<br>1280 × 1024 LVDS /<br>1400 × 1050 LVDS1 /<br>1400 × 1050 LVDS2 /<br>1600 × 1200 LVDS /<br>1366 × 768 LVDS /<br>1680 × 1050 LVDS /<br>1920 × 1200 LVDS /<br>1440 × 900 LVDS /<br>1600 × 900 LVDS /<br>1024 × 768 LVDS /<br>1280 × 800 LVDS /<br>1920 × 1080 LVDS /<br>2048 × 1536 LVDS /<br>1366 × 768 LVDS | Select LCD panel used by Internal Graphics Device by selecting the appropriate setup item.                                                                                                                                                        |
| Panel Scaling             | Auto / Off / Force Scaling                                                                                                                                                                                                                                                                                                                                                                 | Select the LCD panel scaling option used by the Internal Graphics Device.                                                                                                                                                                         |
| Backlight Control         | PWM Inverted / PWM Normal                                                                                                                                                                                                                                                                                                                                                                  | Back light control setting.                                                                                                                                                                                                                       |
| Active LFP                | No eDP / eDP Port-A                                                                                                                                                                                                                                                                                                                                                                        | Select the Active LFP configuration.                                                                                                                                                                                                              |
| Panel Color Depth         | 18 Bit / 24 Bit                                                                                                                                                                                                                                                                                                                                                                            | Select the LFP Panel Color Depth                                                                                                                                                                                                                  |
| Backlight Brightness      | [ X ]                                                                                                                                                                                                                                                                                                                                                                                      | Sel VBIOS Brightness.                                                                                                                                                                                                                             |





| Menu Item | Option | Description  |
|-----------|--------|--------------|
|           |        | Range: 0-255 |

*Setup Utility ⇒ Advanced ⇒ System Agent (SA) Configuration ⇒ DMI/OPI Configuration*

| Menu Item                | Option                                                        | Description                    |
|--------------------------|---------------------------------------------------------------|--------------------------------|
| DMI Gen3 ASPM            | Disabled /<br>Auto /<br>ASPM L0s /<br>ASPM L2 /<br>ASPM L0sL1 | GMI Gen3 ASPM Support          |
| DMI Gen3 ASPM Control    | Disabled /<br>Auto /<br>ASPM L0s /<br>ASPM L2 /<br>ASPM L0sL1 | DMI Gen3 ASPM Control Support. |
| DMI Gen3 L1 Exit Latency | [ X ]                                                         | DMI Gen3 L1 Exit Latency.      |

*Setup Utility ⇒ Advanced ⇒ System Agent (SA) Configuration ⇒ VMD setup menu*

| Menu Item                                       | Option             | Description                                                              |
|-------------------------------------------------|--------------------|--------------------------------------------------------------------------|
| Enable VMD Controller                           | Enabled / Disabled | Enable/Disable VMD Controller.<br>When enabled VMD options were unhided. |
| Enable VMD Global Mapping                       | Enabled / Disabled | Enable/Disable VMD Global Mapping.                                       |
| Map this Root Port under VMD                    | Enabled / Disabled | Map/UnMap this Root Port to VMD                                          |
| Raid 0                                          | Enabled / Disabled | Enable/Disable RAID0 support.                                            |
| Raid 1                                          | Enabled / Disabled | Enable/Disable RAID1 support.                                            |
| Raid 5                                          | Enabled / Disabled | Enable/Disable RAID5 support.                                            |
| Raid 10                                         | Enabled / Disabled | Enable/Disable RAID10 support.                                           |
| Intel Rapid Recovery Technology                 | Enabled / Disabled | Enable/Disable Intel Rapid Recovery Technology.                          |
| RRT volumes can span internal and eSATA drivers | Enabled / Disabled | Enable/Disable RRT volumes can span internal and eSATA drivers.          |
| Intel® Optane™ Memory                           | Enabled / Disabled | Enable/Disable System Acceleration with Intel® Optane™ Memory feature.   |

*Setup Utility ⇒ Advanced ⇒ System Agent (SA) Configuration ⇒ PCI Express Configuration*

| Menu Item                | Option             | Description                                                                                                                                       |
|--------------------------|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|
| PCI Express Clock Gating | Enabled / Disabled | PCI Express Clock Gating Enable/Disable for each root port.                                                                                       |
| Fia Programming          | Enabled / Disabled | Load Fia Configuration if Enabled for each root port.                                                                                             |
| PCI Express Power Gating | Enabled / Disabled | PCI Express Power Gating Enable/Disable for each root port.                                                                                       |
| Compliance Test Mode     | Enabled / Disabled | Enable when using Compliance Load Board.                                                                                                          |
| PCIe function swap       | Enabled / Disabled | When Disabled, prevents PCIE root port function swap. If any function other than 0 <sup>th</sup> is enabled, 0 <sup>th</sup> will become visible. |
| CDR Relock for PEG60     | Enabled / Disabled | Enable/Disable CDR Relock.                                                                                                                        |
| NewFOM for PEG60         | Enabled / Disabled | Enable/Disable New FOM                                                                                                                            |
| CDR Relock for PEG10     | Enabled / Disabled | Enable/Disable CDR Relock.                                                                                                                        |
| NewFOM for PEG10         | Enabled / Disabled | Enable/Disable New FOM                                                                                                                            |



| Menu Item                  | Option             | Description                                                                  |
|----------------------------|--------------------|------------------------------------------------------------------------------|
| PCIE Resizable BAR Support | Enabled / Disabled | Enable/Disable PCIE Resizable BAR Support.                                   |
| PCI Express Root Port X    | See submenu        | PCI Express Root Port Settings. Port 1 – onboard SSD. Port2, 3, 4 – PEG Port |

*Setup Utility ⇒ Advanced ⇒ System Agent (SA) Configuration ⇒ PCI Express Configuration ⇒ PCI Express Root Port X*

| Menu Item                     | Options                            | Description                                                                                                                                                                             |
|-------------------------------|------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| PCI Express Root Port X       | Enabled / Disabled                 | Control the PCI Express root port.                                                                                                                                                      |
| Connection Type               | Built-in / Slot                    | Built-In: a built-in device is connected to this rootport. SlotImplemented bit will be clear.<br>Slot: this rootport connects to user-accessible slot. SlotImplemented bit will be set. |
| ASPM                          | Disabled / L0s / L1 / L0sL1 / Auto | PCI Express Active State Power Management settings.                                                                                                                                     |
| L1 Substates                  | Disabled / L1.1 / L1.1 & L1.2      | PCI Express L1 Substates settings.                                                                                                                                                      |
| Gen3 Eq Phase3 Method         | Hardware / Static Coeff.           | PCIe Gen3 Equalization Phase 3 Method.                                                                                                                                                  |
| Gen4 Eq Phase3 Method         | Hardware / Static Coeff.           | PCIe Gen4 Equalization Phase 3 Method.                                                                                                                                                  |
| ACS                           | Enabled / Disabled                 | Enable or Disable Access Control Services extended capability.                                                                                                                          |
| PTM                           | Enabled / Disabled                 | Enable or Disable Precision Time Measurement.                                                                                                                                           |
| DPC                           | Enabled / Disabled                 | Enable or Disable Downstream Port Containment.                                                                                                                                          |
| FOM Scoreboard Control Policy | Auto / Gen3 / Gen4 / Gen3/Gen4     | Select the FOM Scoreboard Control Policy, when set to Auto, speed is based on TLS                                                                                                       |
| VC                            | Enabled / Disabled                 | Enable/Disable Virtual Channel                                                                                                                                                          |
| Multi-VC                      | Enabled / Disabled                 | Enable/Disable Multi Virtual Channel.                                                                                                                                                   |
| EDPC                          | Enabled / Disabled                 | Enable or Disable Rootport extensions for Downstream Port Containment.                                                                                                                  |
| URR                           | Enabled / Disabled                 | PCI Express Unsupported Request Reporting enable/disable.                                                                                                                               |
| FER                           | Enabled / Disabled                 | PCI Express Device Fatal Error Reporting enable/disable.                                                                                                                                |
| NFER                          | Enabled / Disabled                 | PCI Express Device Non-Fatal Error Reporting enable/disable.                                                                                                                            |
| CER                           | Enabled / Disabled                 | PCI Express Device Correctable Error Reporting enable/disable.                                                                                                                          |
| CT0                           | Enabled / Disabled                 | PCI Express Completion Timer T0 Enable/Disable.                                                                                                                                         |
| SEFE                          | Enabled / Disabled                 | Root PCI Express System Error on Fatal Error enable/disable.                                                                                                                            |
| SENF                          | Enabled / Disabled                 | Root PCI Express System Error on Non-Fatal Error enable/disable.                                                                                                                        |
| SECE                          | Enabled / Disabled                 | Root PCI Express System Error on Correctable Error enable/disable.                                                                                                                      |
| PME SCI                       | Enabled / Disabled                 | PCI Express PME SCI enable/disable.                                                                                                                                                     |
| Hot Plug                      | Enabled / Disabled                 | PCI Express Hot Plug enable/disable.                                                                                                                                                    |
| Advanced Error Reporting      | Enabled / Disabled                 | Advanced Error Reporting enable/disable.                                                                                                                                                |
| PCIe Speed                    | Auto / Gen1 / Gen2 / Gen3          | Configure PCIe Speed.                                                                                                                                                                   |
| IOTG Mode                     | Enabled / Disabled                 | IOTG Mode Enable/Disable                                                                                                                                                                |
| Transmitter Half Swing        | Enabled / Disabled                 | Transmitter Half Swing enable/disable.                                                                                                                                                  |
| Detect Timeout                | [ X ]                              | The number of milliseconds reference code will wait for link to exit Detect state for enabled ports before assuming there is no device and potentially disabling the port.              |
| P2P Support                   | Enabled / Disabled                 | Program P2P Support Registers according to setup option.                                                                                                                                |
| LTR                           | Enabled / Disabled                 | PCH PCIe Latency Reporting enable/disable.                                                                                                                                              |
| Snoop Latency Override        | Auto / Manual / Disabled           | Snoop Latency Override for PCH PCIe.<br>Disabled: Disable override                                                                                                                      |



| Menu Item                  | Options                  | Description                                                                                                                                                                            |
|----------------------------|--------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                            |                          | Manual: Manually enter override values.<br>Auto (default): Maintain default BIOS flow.                                                                                                 |
| Non Snoop Latency Override | Auto / Manual / Disabled | Non Snoop Latency Override for PCH PCIE.<br>Disabled: Disable override<br>Manual: Manually enter override values.<br>Auto (default): Maintain default BIOS flow.                       |
| Force LTR Override         | Enabled / Disabled       | Force LTR Override for PCH PCIE.<br>Disabled: LTR Override values will not be forced.<br>Enabled: LTR override values will be forced and LTR messages from the device will be ignored. |
| LTR Lock                   | Enabled / Disable        | PCIE LTR Configuration Lock.                                                                                                                                                           |
| UPTP                       | [ X ]                    | Upstream Port Transmitter Preset.                                                                                                                                                      |
| DPTP                       | [ X ]                    | Downstream Port Transmitter Preset                                                                                                                                                     |

#### 6.6.2.12 PCIE Configuration

*Setup Utility ⇒ Advanced ⇒ PCIE Configuration ⇒ IMR Configuration*

| Menu Item                | Options            | Description                                                                |
|--------------------------|--------------------|----------------------------------------------------------------------------|
| PCIE IMR                 | Enabled / Disabled | Enable/Disable PCIE IMR                                                    |
| PCIE IMR Size            | [ X ]              | PCIE Reserved Memory Size to be requested in MB. Maximum value of 1024 MB. |
| PCIE RP Location for IMR | PCH PCIE / SA PCIE | Select SA or PCH root port associated with IMR.                            |
| RP Index for IMR         | [ X ]              | Selects which root port will be associated with IMR.                       |

#### 6.6.2.13 PCH-IO Configuration

*Setup Utility ⇒ Advanced ⇒ PCH-IO Configuration*

| Menu Item                  | Options             | Description                                                                                                                                       |
|----------------------------|---------------------|---------------------------------------------------------------------------------------------------------------------------------------------------|
| PCI Express Configuration  | See submenu         | PCI Express Configuration settings.                                                                                                               |
| SATA And RST Configuration | See submenu         | SATA Device Options settings.                                                                                                                     |
| USB Configuration          | See submenu         | USB Configuration settings.                                                                                                                       |
| HD Audio Configuration     | See submenu         | HD Audio Subsystem Configuration Settings.                                                                                                        |
| PXE ROM                    | Enabled / Disabled  | Enable or Disable PXE Option ROM execution.                                                                                                       |
| State After G3             | S0 State / S5 State | Specify what state to go to when power is re-applied after a power failure (G3 state).                                                            |
| Compatible Revision ID     | Enabled / Disabled  | Enable/Disable Compatible Revision ID                                                                                                             |
| Enable TCO Timer           | Enabled / Disabled  | Enable/Disable TCO timer. When disabled, it disables PCH ACPI timer, stops TCO timer, and ACPI WDAT table will not be published                   |
| Enable Timed GPIO0         | Enabled / Disabled  | Enable/Disable timed GPIO0. When disabled, it disables cross time slamp time synchronization as extension of Hammock Harbor time synchronization. |
| Enable Timed GPIO1         | Enabled / Disabled  | Enable/Disable timed GPIO1. When disabled, it disables cross time slamp time synchronization as extension of Hammock Harbor time synchronization. |
| Pcie PII SSC               | Auto / X% / Disable | Pcie PII SSC percentage.<br>Auto – Keep HW default, no BIOS override<br>Range is 0.0% - 2.0%                                                      |



| Menu Item                               | Options            | Description                                                                                                                                                         |
|-----------------------------------------|--------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Enable 8254 Clock Gate                  | Enabled / Disabled | Enable/Disable 8254 clock gate in early phase. Set 8254CGE is necessary for SLP_S0 support. Platform is able to disable this policy and set 8254CGE in late phase.  |
| Lock PCH Sideband Access                | Enabled / Disabled | Lock PCH Sideband access, include SideBand interface lock and SideBand PortID mask for certain end point (e.g. PSFx). The option is invalid if POSTBOOT SAL is set. |
| Flash Protection Range Registers (FPRR) | Enabled / Disabled | Enable Flash Protection Range Registers.                                                                                                                            |
| SPD Write Disable                       | True / False       | Enable/Disable setting SPD Write Disable. For security recommendations, SPD write disable bit must be set.                                                          |
| LGMR                                    | Enabled / Disabled | 64KB memory block for LGMR (LPC Memory Range Decode)                                                                                                                |
| OS IDLE Mode                            | Enabled / Disabled | Enable/Disable OS idle Mode Feature.                                                                                                                                |

### PCI Express Configuration

*Setup Utility ⇒ Advanced ⇒ PCH-IO Configuration ⇒ PCI Express Configuration*

| Menu Item                | Option                             | Description                                                                                                                                      |
|--------------------------|------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------|
| DMI Link ASPM Control    | Disabled / L0s / L1 / L0xL1 / Auto | The control of Active State Power Management of the DMI Link.                                                                                    |
| Peer Memory Write Enable | Enabled / Disabled                 | Peer Memory Write Enable/Disable.                                                                                                                |
| Compliance Test Mode     | Enabled / Disabled                 | Enable when using Compliance Load Board.                                                                                                         |
| PCIe function swap       | Enabled / Disabled                 | When disabled, prevents PCIe rootport function swap. If any function other than 0 <sup>th</sup> is enabled, 0 <sup>th</sup> will become visible. |
| PCIe EQ settings         | See submenu                        | This form contains options for controlling PCIe EQ process.                                                                                      |
| PCI Express Root Port X  | See submenu                        | Configuration of the corresponding PCI Express Root Port X.                                                                                      |

*Setup Utility ⇒ Advanced ⇒ PCH-IO Configuration ⇒ PCI Express Configuration ⇒ PCIe EQ settings*

| Menu Item                                             | Options                                            | Description                                                                                                                                                                                                    |
|-------------------------------------------------------|----------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| PCIe EQ override                                      | [ ] / [X]                                          | Choose your own PCIe EQ settings, only for users who have a thorough understanding of equalization process.                                                                                                    |
| PCIe EQ method                                        | PCIe hardware EQ / PCIe fixed EQ                   | Choose PCIe EQ method                                                                                                                                                                                          |
| PCIe EQ mode                                          | Use presets during EQ / Use coefficients during EQ | Choose EQ mode.<br>Preset mode – root port will use presets during EQ process<br>Coefficient mode – root port will use coefficients during EQ process                                                          |
| EQ PH1 downstream port transmitter preset             | 0 – 10                                             | Choose the value of the preset that will be used during phase 1 of the equalization                                                                                                                            |
| EQ PH1 upstream port transmitter preset               | 0 – 10                                             | Choose the value of the preset that will be used during phase 1 of the equalization                                                                                                                            |
| Enable EQ phase 2 local transmitter override          | [ ] / [X]                                          | EQ Phase 2 local transmitter override can be used to debug issues with PCI devices equalization                                                                                                                |
| Number of presets of coefficients used during phase 3 | 0 – 11                                             | Select how many presets or coefficients will be used during phase 3 of EQ. Please note that you have to set all of the list entries to valid values. The interpretation of this field depends on PCIe EQ mode. |
| Prese X                                               | 0 – 63                                             | Choose the target preset value.                                                                                                                                                                                |



*Setup Utility ⇒ Advanced ⇒ PCH-IO Configuration ⇒ PCI Express Configuration ⇒ PCI Express Root Port X*

| Menu Item                | Options                            | Description                                                                                                                                                                             |
|--------------------------|------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| PCI Express Root Port X  | Enabled / Disabled                 | Control the PCI Express root port.                                                                                                                                                      |
| Connection Type          | Built-in / Slot                    | Built-In: a built-in device is connected to this rootport. SlotImplemented bit will be clear.<br>Slot: this rootport connects to user-accessible slot. SlotImplemented bit will be set. |
| ASPM                     | Disabled / L0s / L1 / L0sL1 / Auto | PCI Express Active State Power Management settings.                                                                                                                                     |
| L1 Substates             | Disabled / L1.1 / L1.1 & L1.2      | PCI Express L1 Substates settings.                                                                                                                                                      |
| ACS                      | Enabled / Disabled                 | Enable or Disable Access Control Services extended capability.                                                                                                                          |
| PTM                      | Enabled / Disabled                 | Enable or Disable Precision Time Measurement.                                                                                                                                           |
| DPC                      | Enabled / Disabled                 | Enable or Disable Downstream Port Containment.                                                                                                                                          |
| EDPC                     | Enabled / Disabled                 | Enable or Disable Rootport extensions for Downstream Port Containment.                                                                                                                  |
| URR                      | Enabled / Disabled                 | PCI Express Unsupported Request Reporting enable/disable.                                                                                                                               |
| FER                      | Enabled / Disabled                 | PCI Express Device Fatal Error Reporting enable/disable.                                                                                                                                |
| NFER                     | Enabled / Disabled                 | PCI Express Device Non-Fatal Error Reporting enable/disable.                                                                                                                            |
| CER                      | Enabled / Disabled                 | PCI Express Device Correctable Error Reporting enable/disable.                                                                                                                          |
| SEFE                     | Enabled / Disabled                 | Root PCI Express System Error on Fatal Error enable/disable.                                                                                                                            |
| SENFEE                   | Enabled / Disabled                 | Root PCI Express System Error on Non-Fatal Error enable/disable.                                                                                                                        |
| SECE                     | Enabled / Disabled                 | Root PCI Express System Error on Correctable Error enable/disable.                                                                                                                      |
| PME SCI                  | Enabled / Disabled                 | PCI Express PME SCI enable/disable.                                                                                                                                                     |
| Hot Plug                 | Enabled / Disabled                 | PCI Express Hot Plug enable/disable.                                                                                                                                                    |
| Advanced Error Reporting | Enabled / Disabled                 | Advanced Error Reporting enable/disable.                                                                                                                                                |
| PCIe Speed               | Auto / Gen1 / Gen2 / Gen3          | Configure PCIe Speed.                                                                                                                                                                   |
| Detect Timeout           | [ X ]                              | The number of milliseconds reference code will wait for link to exit Detect state for enabled ports before assuming there is no device and potentially disabling the port.              |

### SATA And RST Configuration

*Setup Utility ⇒ Advanced ⇒ PCH-IO Configuration ⇒ SATA And RST Configuration*

| Menu Item                           | Options                                                        | Description                                                                                                                                                                    |
|-------------------------------------|----------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| SATA Controller(s)                  | Enabled / Disabled                                             | Enable or disable SATA Device.                                                                                                                                                 |
| SATA Mode Selection                 | AHCI / Intel RST Premium With Intel Optane System Acceleration | Determine how SATA controller(s) operate.                                                                                                                                      |
| SATA Test Mode                      | Enabled / Disabled                                             | Test Mode enable/disable (Loop Back).                                                                                                                                          |
| Software Feature Mask Configuration | See submenu                                                    | RST Legacy OROM/RST UEFI driver will refer to the SWFM configuration to enable/disable the storage features.                                                                   |
| Aggressive LPM Support              | Enabled / Disabled                                             | Enable PCH to aggressively enter link power state.                                                                                                                             |
| Serial ATA Port X                   | Enabled / Disabled                                             | Enable or Disable SATA Port.                                                                                                                                                   |
| Hot Plug                            | Enabled / Disabled                                             | Designates this port as Hot Pluggable.                                                                                                                                         |
| External                            | Enabled / Disabled                                             | Marks this port as external.                                                                                                                                                   |
| Spin Up Device                      | Enabled / Disabled                                             | If enabled for any of ports Staggered Spin Up will be performed and only the drives which have this option enabled will spin up at boot. Otherwise all drives spin up at boot. |
| SATA Device Type                    | Hard Disk Drive /                                              | Identify the SATA port is connected to Solid State Drive or Hard Disk                                                                                                          |



| Menu Item          | Options                                      | Description                                                                                                                                                                                                         |
|--------------------|----------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                    | Solid State Drive                            | Drive.                                                                                                                                                                                                              |
| Topology           | Unknown / ISATA / Direct Connect / Flex / M2 | Identify the SATA topology if it is Default or ISATA or Flex or DirectConnect or M2.                                                                                                                                |
| SATA Port X DevSlp | Enabled / Disabled                           | Enable/Disable SATA Port 0 DevSlp. For DevSlp to work, both hard drive and SATA port need to support DevSlp function, otherwise an unexpected behaviour might happen. Please check board design before enabling it. |
| DITO Configuration | Enabled / Disabled                           | Enable or Disable DITO configuration.                                                                                                                                                                               |
| DITO Value         | 0 – 999                                      | DITO Value.<br><u>Note:</u> This option is only configurable if “DITO Configuration” is enabled.                                                                                                                    |
| DM Value           | 0 – 15                                       | DM Value.<br><u>Note:</u> This option is only configurable if “DITO Configuration” is enabled.                                                                                                                      |

## USB Configuration

*Setup Utility ⇒ Advanced ⇒ PCH-IO Configuration ⇒ USB Configuration*

| Menu Item                       | Options                   | Description                                                                                                                                            |
|---------------------------------|---------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------|
| xDCI Support                    | Enabled / Disabled        | Enable/Disable xDCI (USB OTG Device)                                                                                                                   |
| USB PD0 Programming             | Enabled / Disabled        | Select ‘Enabled’ if Port Disable Override functionality is used.                                                                                       |
| XHCI LTR Mode                   | Enabled / Disabled        | Enable/Disable XHCI LTR Mode.                                                                                                                          |
| USB Overcurrent                 | Enabled / Disabled        | Select ‘Disabled’ for pin-based debug. If pin based debug is enabled but USB overcurrent is not disabled, USB DbC does not work.                       |
| USB Overcurrent Lock            | Enabled / Disabled        | Select ‘Enabled’ if Overcurrent functionality is used. Enabling this will make xHCI controller consume the Overcurrent mapping data.                   |
| USB Port Disable Override       | Select per Pin / Disabled | Selectively Enable/Disable the corresponding USB port from reporting a Device Connection to the controller.                                            |
| USB SS/HS Physical Connector #X | Enabled / Disabled        | Enable/Disable this USB Physical Connector (physical port). Once disabled, any USB devices plug into the connector will not be detected by BIOS or OS. |

## Security Configuration

*Setup Utility ⇒ Advanced ⇒ PCH-IO Configuration ⇒ Security Configuration*

| Menu Item                     | Options            | Description                                                                                                |
|-------------------------------|--------------------|------------------------------------------------------------------------------------------------------------|
| RTC Memory Lock               | Enabled / Disabled | Enable will lock bytes 38h-3Fh in the lower/upper 128-byte bank of RTC RAM.                                |
| BIOS Lock                     | Enabled / Disabled | Enable/Disable the PCH BIOS Lock Enable feature. Required to be enabled to ensure SMM protection of flash. |
| Force unlock on all GPIO pads | Enabled / Disabled | If enabled BIOS will force all GPIO pads to be in unlocked state.                                          |



## HDA Audio Configuration

*Setup Utility ⇒ Advanced ⇒ PCH-IO Configuration ⇒ HD Audio Configuration*

| Menu Item             | Options                         | Description                                                                                                                                   |
|-----------------------|---------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------|
| HD Audio              | Enabled / Disabled              | Control detection of the HD-Audio device.<br>Disabled: HAD will be unconditionally disabled.<br>Enabled: HAD will be unconditionally enabled. |
| Audio DSP             | Enabled / Disabled              | Enable or disable Audio DSP.                                                                                                                  |
| HDA-Link Codec Select | Platform Onboard / External Kit | Selects whether Platform Onboard Codec (single Verb Table Installed) or External Codec Kit (multiple Verb Tables Installed) will be used.     |

### 6.6.2.14 PCH-FW Configuration

*Setup Utility ⇒ Advanced ⇒ PCH-FW Configuration*

| Menu Item                          | Option             | Description                                                                       |
|------------------------------------|--------------------|-----------------------------------------------------------------------------------|
| ME State                           | Enabled / Disabled | When Disabled ME will be put into ME Temporarily Disabled Mode.                   |
| Firmware Update Configuration      | See submenu        | Configure Management Engine Technology parameters.                                |
| Extend CSME Measurement to TPM-PCR | Enabled / Disabled | Enable/Disable Extend CSME Measurement to TPM-PCR[0] and AMT Config to TPM-PCR[1] |

*Setup Utility ⇒ Advanced ⇒ PCH-FW Configuration ⇒ Firmware Update Configuration*

| Menu Item            | Option             | Description                                                                            |
|----------------------|--------------------|----------------------------------------------------------------------------------------|
| Me FW Image Re-Flash | Enabled / Disabled | Enable/Disable Me FW Image Re-Flash function. This option is only valid for next boot. |
| FW Update            | Enabled / Disabled | Enable/Disable ME FW Update function.                                                  |

### 6.6.2.15 ACPI D3Cold settings

*Setup Utility ⇒ Advanced ⇒ ACPI D3Cold settings*

| Menu Item                               | Option                              | Description                                                                                                                                                                              |
|-----------------------------------------|-------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| ACPI D3 Cold Support                    | Enabled / Disabled                  | Enable/Disable ACPI D3Cold support to be executed on D3 entry and exit.                                                                                                                  |
| VR Ramp up delay                        | [ X ]                               | Delay between subsequent VR ramp ups if they are all turn ON at the same time.                                                                                                           |
| PCIE Slot 5 Device Power-on delay in ms | [ X ]                               | Delay between applying core power and Deasserting PERST#.                                                                                                                                |
| Audio Delay                             | [ X ]                               | Delay after applying power to HD Audio (Realtek) codec device.                                                                                                                           |
| SensorHub                               | [ X ]                               | Delay after applying power to SensorHub device.                                                                                                                                          |
| TouchPad                                | [ X ]                               | Delay after applying power to TouchPad device.                                                                                                                                           |
| TouchPanel                              | [ X ]                               | Delay after applying power to TouchPanel device.                                                                                                                                         |
| P-state capping                         | Enabled / Disabled                  | Set _PPC and send ACPI notification.                                                                                                                                                     |
| USB Port 1                              | High Speed / Super Speed / Disabled | USB RTD3 support.<br>Super Speed: USB3.0 devices will be exposed as RTD3 capable.<br>High Speed: USB2.0 devices will be exposed as RTD3 capable.<br>Disabled: USB RTD3 support disabled. |



| Menu Item         | Option                                    | Description                                                                                                                                                                              |
|-------------------|-------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| USB Port 2        | High Speed /<br>Super Speed /<br>Disabled | USB RTD3 support.<br>Super Speed: USB3.0 devices will be exposed as RTD3 capable.<br>High Speed: USB2.0 devices will be exposed as RTD3 capable.<br>Disabled: USB RTD3 support disabled. |
| ZPODD             | Enabled / Disabled                        | Zero Power ODD option is applicable only for the board with ZPODD support.                                                                                                               |
| Bluetooth         | Enabled / Disabled                        | Enable/Disable RTD3 support for BT.                                                                                                                                                      |
| Sata Port 0       | Enabled / Disabled                        | Setup option to control the SATA port RTD3 functionality.                                                                                                                                |
| Sata Port 1       | Enabled / Disabled                        | Setup option to control the SATA port RTD3 functionality.                                                                                                                                |
| Sata Port 2       | Enabled / Disabled                        | Setup option to control the SATA port RTD3 functionality.                                                                                                                                |
| Sata Port 3       | Enabled / Disabled                        | Setup option to control the SATA port RTD3 functionality.                                                                                                                                |
| Sata Port 4       | Enabled / Disabled                        | Setup option to control the SATA port RTD3 functionality.                                                                                                                                |
| Sata Port 5       | Enabled / Disabled                        | Setup option to control the SATA port RTD3 functionality.                                                                                                                                |
| PCIe Remapped CR1 | Enabled / Disabled                        | PCIe RTD3 setup conflicts with SATA RTD3. Platform specific.                                                                                                                             |
| PCIe Remapped CR2 | Enabled / Disabled                        | PCIe RTD3 setup conflicts with SATA RTD3. Platform specific.                                                                                                                             |
| PCIe Remapped CR3 | Enabled / Disabled                        | PCIe RTD3 setup conflicts with SATA RTD3. Platform specific.                                                                                                                             |

#### 6.6.2.16 SIO TQMx86

*Setup Utility ⇒ Advanced ⇒ SIO TQMx86*

| Menu Item                                   | Option                                                | Description                                                                                                                                                        |
|---------------------------------------------|-------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Serial Port X                               | Enabled / Disabled / Auto                             | Disabled: No configuration<br>Enabled: User Configuration<br>Auto: EFI/OS chooses configuration                                                                    |
| Base I/O Address                            | 2E8 / 2F8 / 3E8 / 3F8                                 | Configure Base I/O Address of corresponding Serial Port X.                                                                                                         |
| Interrupt                                   | IRQ3 / IRQ4 / IRQ5 / IRQ6 /<br>IRQ7                   | Configure Interrupt of corresponding Serial Port X.                                                                                                                |
| Handshake RTS/CTS                           | Connected / Disconnected                              | Connect or disconnect the COM Express Serial Port Handshake RTS/CTS for Serial Port X.                                                                             |
| Power State S5                              | Normal / Ultra Low Power                              | Configure Power State S5.<br>Normal: Wakeup over LAN (WOL), timer, external Wake and Power Button possible.<br>Ultra Low Power: Wakeup over Power Button possible. |
| PEG PCI Express Configuration               | 1x16 /<br>2x8 /<br>2x4, 1x8                           | Configure different PEG PCI Express Configurations. Note: A cold reset is required to assume this configuration.                                                   |
| COM Express eDP/LVDS Configuration          | LVDS / eDP                                            | Configure if eDP or LVDS is connected to the COM Express Connector.                                                                                                |
| Enable LVDS bridge                          | Enabled / Disabled                                    | Enable or Disable the eDP-to-LVDS bridge.                                                                                                                          |
| LVDS Configuration                          | Enabled / Disabled                                    | Enable or Disable the configuration of eDP-to-LVDS bridge.                                                                                                         |
| LVDS Colour depth and data packing format   | VESA 24 bpp / JEIDA 24 bpp /<br>VESA and JEIDA 18 bpp | Configure the LVDS Colour depth in eDP-to-LVDS bridge.                                                                                                             |
| LVDS dual/single mode                       | Single LVDS bus mode /<br>Dual LVDS bus mode          | Configure LVDS dual/single mode.                                                                                                                                   |
| LVDS clock frequency center spreading depth | No Spreading /<br>0.5 % /<br>1.0 % /<br>1.5 % /       | Configure LVDS clock frequency center spreading depth.                                                                                                             |




| Menu Item             | Option                                                                                                                                                                                                                                                           | Description                                                                                                                                                               |
|-----------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
|                       | 2.0 % /<br>2.5 %                                                                                                                                                                                                                                                 |                                                                                                                                                                           |
| LVDS EDID information | EDID Emulation off – read from DDC<br>EDID Emulation on – read from internal Flash                                                                                                                                                                               | Configure if the EDID information should be read from DDC or internal flash of eDP-to-LVDS bridge.                                                                        |
| LVDS Resolution       | 1024 × 768 @ 60 Hz NXP Generic /<br>800 × 480 @ 60 Hz NXP Generic /<br>480 × 272 @ 60 Hz NXP Generic /<br>1600 × 900 @ 60 Hz Samsung LTM200 KT /<br>1920 × 1080 @ 60 Hz Samsung LTM230 HT /<br>1366 × 768 @ 60 Hz NXP Generic /<br>320 × 240 @ 60 Hz NXP Generic | Configure the Resolution of eDP-to-LVDS bridge.<br>Note: This option is only visible if 'LVDS EDID information' is set on 'EDID Emulation on – read from internal Flash.' |

#### 6.6.2.17 SIO Hardware Monitor Nuvoton NCT7802Y

Setup Utility ⇒ Advanced ⇒ SIO Hardware Monitor Nuvoton NCT7802Y

| Menu Item          | Options                     | Description                                                                                                                                          |
|--------------------|-----------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------|
| Hardware Monitor   | See submenu                 | Set Hardware Monitor parameters.                                                                                                                     |
| Fan PWM Frequency  | Low (32 Hz) / High (25 kHz) | Select PWM Frequency for the FAN.                                                                                                                    |
| Enable Fan Scaling | [ ] / [X]                   | Enabling Fan Scaling unhides a menu to define trip points to configure the Fan Speed / Temperature curve. The default is shown in the diagram below. |





### 6.6.2.18 Console Redirection

Setup Utility ⇒ Advanced ⇒ Console Redirection

| Menu Item               | Options            | Description                                                                                |
|-------------------------|--------------------|--------------------------------------------------------------------------------------------|
| Console Serial Redirect | Enabled / Disabled | Enable or disable the Console Redirection. This options unhide CR parameters when enabled. |

If enabled:

| Menu Item                       | Options                                                                       | Description                                                                                                                                                                                                                                                                                                                                              |
|---------------------------------|-------------------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Terminal Type                   | VT_100 / VT_100+ / VT_UTF8 / PC_ANSI                                          | Select the Console Redirection terminal type.                                                                                                                                                                                                                                                                                                            |
| Baud Rate                       | 115200 / 57600 / 38400 / 19200 / 9600 / 4800 / 2400 / 1200                    | Select the Console Redirection Baud Rate.                                                                                                                                                                                                                                                                                                                |
| Data Bits                       | 7 Bits / 8 Bits                                                               | Select the Console Redirection Data Bits.                                                                                                                                                                                                                                                                                                                |
| Parity                          | None / Even / Odd                                                             | Select the Console Redirection Parity Bits.                                                                                                                                                                                                                                                                                                              |
| Stop Bits                       | 1 Bit / 2 Bits                                                                | Select the Console Redirection Stop Bits.                                                                                                                                                                                                                                                                                                                |
| Flow Control                    | None / RTS/CTS / XON/XOFF                                                     | Select the Console Redirection Flow Control type.                                                                                                                                                                                                                                                                                                        |
| Information Wait Time           | 0 Second / 2 Second / 5 Second / 10 Second / 30 Second                        | Select the Console Redirection Port information display time.                                                                                                                                                                                                                                                                                            |
| C.R. After Legacy Boot          | Yes / No                                                                      | Console Redirection continue works after Legacy Boot.                                                                                                                                                                                                                                                                                                    |
| Text Mode Resolution            | AUTO / Force 80x25 / Force 80x24 (DEL FIRST ROW) / Force 80x24 (DEL LAST ROW) | Console Redirection Text Mode Resolution.<br>Auto: Follow VGA text mode<br>Force 80x25: Don't care about VGA and force text mode to be 80x25<br>Force 80x24 (DEL FIRST ROW): Don't care about VGA and force text mode to be 80x24 and Del first row<br>Force 80x24 (DEL LAST ROW): Don't care about VGA and force text mode to be 80x24 and Del last row |
| Auto Refresh                    | Enabled / Disabled                                                            | When feature enable, screen will be auto refresh once after detect remote terminal was connected.                                                                                                                                                                                                                                                        |
| Auto adjust Terminal resolution | Enabled / Disabled                                                            | Through send extra ESC sequence code                                                                                                                                                                                                                                                                                                                     |
| COM_X                           | See submenu                                                                   | Set parameters of COM Express Serial Port X. Whereby X stands for COM Express Serial Port 0 (Insyde name COMA) or 1 (Insyde name COMB).                                                                                                                                                                                                                  |

Note: All COM / HSUART submenu are identical and thus will be listed only once.

| Menu Item        | Options            | Description                                                                                                     |
|------------------|--------------------|-----------------------------------------------------------------------------------------------------------------|
| PortEnable       | Enabled / Disabled | Enable or disable corresponding port.                                                                           |
| UseGlobalSetting | Enabled / Disabled | If enabled use settings defined in superordinate CR menu. Disabling this option unhides corresponding settings. |



### 6.6.2.19 SIO F81214E

*Setup Utility ⇒ Advanced ⇒ SIO F81214E*

| Menu Item                 | Option      | Description        |
|---------------------------|-------------|--------------------|
| UART Port X Configuration | See submenu | UART Configuration |

*Setup Utility ⇒ Advanced ⇒ SIO F81214E ⇒ UART Port X Configuration*

| Menu Item        | Option                                                   | Description                                                                                                       |
|------------------|----------------------------------------------------------|-------------------------------------------------------------------------------------------------------------------|
| UART Port X      | Enabled / Disabled                                       | Configure UART Port using options:<br>Disabled – Disable device<br>Enabled – Enable device and use below settings |
| Base I/O Address | 3F8h / 2F8h / 3E8h / 2E8h /<br>338h / 228h / 220h / 238h | System I/O base resources.                                                                                        |
| Interrupt        | IRQ3 / IRQ4 / IRQ5 / IRQ6 /<br>IRQ7 / IRQ10 / IRQ11      | System interrupt resources.                                                                                       |
| Peripheral Type  | RS232 / RS485                                            | Choose port mode.                                                                                                 |

### 6.6.3 Security

| Menu Item               | Options            | Description                                                                                                               |
|-------------------------|--------------------|---------------------------------------------------------------------------------------------------------------------------|
| TrEE Protocol Version   | 1.0 / 1.1          | TrEE Protocol Version: 1.0 or 1.1.                                                                                        |
| TPM Availability        | Available / Hidden | When Hidden, do not exposes TPM to 0.                                                                                     |
| Clear TPM               | [ ] / [ X ]        | Clear TPM. Removes all TPM context associated with a specific Owner.                                                      |
| Set Supervisor Password | 123456             | Install or change the BIOS password. The length of password must be greater than one and smaller or equal ten characters. |

### 6.6.4 Power

| Menu Item          | Options                                      | Description                                                                                                            |
|--------------------|----------------------------------------------|------------------------------------------------------------------------------------------------------------------------|
| ACPI S3            | Enabled / Disabled                           | Enable/Disable ACPI S1/S3 Sleep state.                                                                                 |
| Wake on PME        | Enabled / Disabled                           | Determines the action taken when the system power is off and a PCI Power Management Enable (PME) wake up event occurs. |
| Wake on Modem Ring | Enabled / Disabled                           | Determines the action taken when the system power is off and a modem connected to the serial port is ringing.          |
| Auto Wake on S5    | Disabled / By Every Day / By<br>Day of Month | Auto wake on S5, By Day of Month or Fixed time of every day.                                                           |
| S5 Long Run Test   | Enabled / Disabled                           | Enable: force to enable RTC S5 wake up, even if OS disables it. Support ipwrtest to do RTC S5 wakeup.                  |

### 6.6.5 Boot

| Menu Item  | Options            | Description                                                                                                    |
|------------|--------------------|----------------------------------------------------------------------------------------------------------------|
| Quick Boot | Enabled / Disabled | Allow InsydeH2O to skip certain tests while booting. This will decrease the time needed to boot the system.    |
| Quite Boot | Enabled / Disabled | Enable or disable booting in Text mode. No textual outputs are given while booting if this option is disabled. |



| Menu Item                                   | Options                                                          | Description                                                                                                                                                                                                                                         |
|---------------------------------------------|------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Network Stack                               | Enabled / Disabled                                               | Enable or disable Network stack Support:<br>Windows 8 BitLocker Unlock<br>UEFI IPv4/IPv6 PXE<br>Legacy PXE OPRM<br><u>Note:</u> This option will grey-out the PXE Boot capability option.                                                           |
| PXE Boot capability                         | Disabled /<br>UEFI : IPv4 /<br>UEFI : IPv6 /<br>UEFI : IPv4/IPv6 | Disabled: Support Network Stack<br>UEFI PXE: IPv4/IPv6<br>Legacy: Legacy PXE OPRM only<br><u>Note:</u> This option is only configurable if 'Network Stack' is enabled.                                                                              |
| Power up In Standby Support                 | Enabled / Disabled                                               | Enable or disable the Power Up in Standby Support (PUIS). The PUIS feature allows devices to be powered-up into the Standby power management state to minimize inrush current at power-up and to allow the host to sequence the spin-up of devices. |
| Storage PCI Option Rom access right Support | Enabled / Disabled                                               | Disable or enable storage PCI option rom access right. This feature will enable or disable storage PCI option rom being load and dispatched.                                                                                                        |
| ESATA drive boot access right Support       | Enabled / Disabled                                               | Disable or enable ESATA drive boot access right. This feature will allow or deny boot up an ESATA storage device.                                                                                                                                   |
| Add Boot Options                            | First / Last / Auto                                              | Position in Boot Order for Shell, Network and Removables.                                                                                                                                                                                           |
| ACPI Selection                              | Acpi1.0B / Acpi3.0 / Acpi4.0 /<br>Acpi5.0 / Acpi6.0 / Acpi6.1    | Select booting to ACPI selection.                                                                                                                                                                                                                   |
| USB Boot                                    | Enabled / Disabled                                               | Enable or disable booting to USB boot device.                                                                                                                                                                                                       |
| UEFI OS Fast Boot                           | Enabled / Disabled                                               | If enabled the system firmware does not initialize keyboard and check for firmware menu key.                                                                                                                                                        |
| USB Hot Key Support                         | Enabled / Disabled                                               | Enable or disable to support USB hot key while booting. This will decrease the time needed to boot the system, however, it is not possible to get into BIOS menu by pressing <ESC> while booting. The change into BIOS has to be done over OS.      |
| Timeout                                     | 0 – 10                                                           | The number of seconds that the firmware will wait before booting the original default boot selection.                                                                                                                                               |
| Automatic Failover                          | Enabled / Disabled                                               | Enable: If boot to default device fail, it will directly try to boot next device.<br>Disable: If boot to default device fail, it will pop warning message then go into firmware UI.                                                                 |
| EFI                                         | See submenu                                                      | Option to adapt boot order. Selection depends on boot devices connected.<br><u>Note:</u> Add Boot Options has to be configured as First or Last. The order can be changed by pressing <F5> or <F6>.                                                 |

#### 6.6.6 Exit

| Menu Item                | Option | Description                                                                                       |
|--------------------------|--------|---------------------------------------------------------------------------------------------------|
| Exit Saving Changes      |        | Save changes and reboot system afterwards.<br><F10> can be used for this operation.               |
| Save Change Without Exit |        | Save changes without reboot system.                                                               |
| Exit Discarding Changes  |        | Exit InsydeH2O Setup Utility without saving any changes.<br><ESC> can be used for this operation. |
| Load Optimal Defaults    |        | Load optimal default values for all setup items.<br><F9> can be used for this operation.          |
| Load Custom Defaults     |        | Load custom default values for all setup items.                                                   |
| Save Custom Defaults     |        | Save custom defaults for all setup items.                                                         |
| Discard Changes          |        | Discard all changes without exiting InsydeH2O Setup Utility.                                      |

## 7. BIOS – UPDATE

The uEFI BIOS update instruction serves to guarantee a proper way to update the uEFI BIOS on the TQMx110EB.

Please read the entire instructions before beginning the BIOS update.

By disregarding the information you can destroy the uEFI BIOS on the TQMx110EB!

This document will guide the customer to update the uEFI BIOS on the TQMx110EB by using the Insyde Flash Firmware Tools.

The InsydeH2O Tools are only available on [request](#).

Please contact [support@tq-group.com](mailto:support@tq-group.com) for more information about the BIOS Tools and the latest uEFI BIOS version for the TQMx110EB.

### Note: Installation procedures and screen shots



Installation procedures and screen shots in this section are for your reference and may not be exactly the same as shown on your screen.

#### 7.1.1 Step 1: Preparing USB Stick

A USB stick with FAT32 format can be used. Copy the following files to the USB stick.

(See: <https://www.tq-group.com/de/support/downloads/tq-embedded/software-treiber/x86-architektur/>)

- H2OFFT-Sx64.efi (Flash Firmware Tool from Insyde for update via UEFI Shell)
  - Be sure to have H2OFFT Version 200.02.00.02 or later
- InsydeH2OFF\_x86\_WIN folder (Flash Firmware Tool from Insyde for update via Windows 32-bit system)
- InsydeH2OFF\_x86\_WINx64 folder (Flash Firmware Tool from Insyde for update via Windows 64-bit system)
- BIOS.bin file e.g. xx.bin

#### 7.1.2 Step 2: Preparing Management Engine (ME) FW for update

Enter the BIOS menu by pressing <ESC> while booting (POST phase) and change to the following page:

**Setup Utility ⇒ Advanced ⇒ PCH-FW Configuration ⇒ Firmware Update Configuration**

Then, set option "Me FW Image Re-Flash" to "enabled", save and exit by pressing <F10> and <Enter>.

### Note: Option availability



This option will only be valid for the next boot.




Figure 10: PCH-FW Configuration menu




Figure 11: Firmware Update Configuration menu




Figure 12: ME FW Image Re-Flash option

### 7.1.3 Step 3a: Updating uEFI BIOS via EFI Shell

Insert the USB stick into the board on which you want to update the uEFI BIOS and switch on the board. The board will boot and go to the internal EFI shell. Note: If a boot device is plugged change to "Boot Manager" over Front Page and select "Internal EFI Shell".

```
Mapping table
FS0: Alias(s):HD0d0b0b:;BLK1:
    PciRoot(0x0)/Pci(0x14,0x0)/USB(0x3,0x0)/USB(0x1,0x0)/HD(1,HBR,0x00000000,0x2000,0x1E1D800)
BLK0: Alias(s):
    PciRoot(0x0)/Pci(0x14,0x0)/USB(0x3,0x0)/USB(0x1,0x0)
Shell>
```

Figure 13: EFI Shell

Please see device mapping table on the screen and select the removable hard disk file system "fsX" (X = 0, 1, 2, ...).

Move operating directory to USB drive with e.g. "fs0:"

Then, enter into the BIOS folder (e.g. "cd tqmx110eb") to execute the Insyde BIOS update tool:

```
H2OFFT-Sx64.efi <BIOS file> -ALL -RA
```

If the argument "-RA" is set the SMBIOS data will not be overwritten and the UUID included in SMBIOS data will be preserved. However, this argument is not mandatory.

```
Shell> fs0:
FS0:\> H2OFFT-Sx64.efi TQMx110EB_05.43.12.47.01.bin -all -ra
```

Figure 14: EFI Shell uEFI BIOS Update




Figure 15: Screen during BIOS Update

#### 7.1.4 Step 3b: Updating uEFI BIOS via Windows Operating System

Boot the Windows operating system (64-bit) and insert the USB stick into the board on which you want to update the uEFI BIOS. Start the Command Prompt (CMD). It is important to note that the Command Prompt must be started in the administrator mode!

Select the BIOS update folder with the Insyde Windows 64-bit update tool and execute the Insyde BIOS update tool.

```
H2OFFT-Wx64.exe <BIOS file>.bin -all -ra
```

For the <BIOS file> argument, please specify the .bin file with the full path (e. g.: D:\TQMxXXXX\_X.xx.xx.xx.xx.bin).

If the argument “-RA” is set the SMBIOS data will not be overwritten and the UUID included in SMBIOS data will be preserved. However, this argument is not mandatory.

Start the BIOS update with the Insyde Windows 64-bit update tool.

#### 7.1.5 Step 4: BIOS update check on the TQMx110EB Module

After the uEFI BIOS update, the new uEFI BIOS configures the complete TQMx110EB hardware and this results in some reboots and the first boot time takes longer (up to 1 minute).

The TQMx110EB includes a dual colour Debug LED providing boot and uEFI BIOS information.

If the green LED is blinking the uEFI BIOS is booting. If the green LED is lit permanently the uEFI BIOS boot is finished.



Figure 16: TQMx110EB Debug LED

After the uEFI BIOS has been flashed completely, please check whether the uEFI BIOS has been flashed successfully. The BIOS Main menu includes the board and hardware information and it shows the installed BIOS version.




Figure 17: EFI BIOS Main Menu





## 8. SAFETY REQUIREMENTS AND PROTECTIVE REGULATIONS

### 8.1 EMC

The TQMx110EB was developed according to electromagnetic compatibility requirements (EMC). Depending on the target system, anti-interference measures may still be necessary to guarantee the adherence to the limits for the overall system.

### 8.2 ESD

In order to avoid interspersions on the signal path from the input to the protection circuit in the system, the protection against electrostatic discharge should be arranged directly at the inputs of a system. As these measures always have to be implemented on the carrier board, no special preventive measures were done on the TQMx110EB.

### 8.3 Shock & Vibration

The TQMx110EB is designed to be insensitive to shock and vibration and impact.

### 8.4 Operational Safety and Personal Security

Due to the occurring voltages ( $\leq 20$  V DC), tests with respect to the operational and personal safety haven't been carried out.

### 8.5 Cyber Security

A Threat Analysis and Risk Assessment (TARA) must always be performed by the customer for their individual end application, as the TQMx110EB is only a sub-component of an overall system.

### 8.6 Export Control and Sanctions Compliance

The customer is responsible for ensuring that the product purchased from TQ is not subject to any national or international export/import restrictions. If any part of the purchased product or the product itself is subject to said restrictions, the customer must procure the required export/import licenses at its own expense. In the case of breaches of export or import limitations, the customer indemnifies TQ against all liability and accountability in the external relationship, irrespective of the legal grounds. If there is a transgression or violation, the customer will also be held accountable for any losses, damages or fines sustained by TQ. TQ is not liable for any delivery delays due to national or international export restrictions or for the inability to make a delivery as a result of those restrictions. Any compensation or damages will not be provided by TQ in such instances.

The classification according to the European Foreign Trade Regulations (export list number of Reg. No. 2021/821 for dual-use-goods) as well as the classification according to the U.S. Export Administration Regulations in case of US products (ECCN according to the U.S. Commerce Control List) are stated on TQ's invoices or can be requested at any time. Also listed is the Commodity code (HS) in accordance with the current commodity classification for foreign trade statistics as well as the country of origin of the goods requested/ordered.

### 8.7 Warranty

TQ-Systems GmbH warrants that the product, when used in accordance with the contract, fulfills the respective contractually agreed specifications and functionalities and corresponds to the recognized state of the art.

The warranty is limited to material, manufacturing and processing defects. The manufacturer's liability is void in the following cases:

- Original parts have been replaced by non-original parts.
- Improper installation, commissioning or repairs.
- Improper installation, commissioning or repair due to lack of special equipment.
- Incorrect operation
- Improper handling
- Use of force
- Normal wear and tear

### 8.8 Reliability and Service Life

The MTBF according to MIL-HDBK-217F N2 is approximately 362546 h, Ground Benign, @ +40 °C.



## 8.9 RoHS

The TQMx110EB is manufactured RoHS compliant.

- All components and assemblies are RoHS compliant
- The soldering processes are RoHS compliant

## 8.10 WEEE®

The company placing the product on the market is responsible for the observance of the WEEE® regulation.

To be able to reuse the product, it is produced in such a way (a modular construction) that it can be easily repaired and disassembled.

## 8.11 REACH®

The EU-chemical regulation 1907/2006 (REACH® regulation) stands for registration, evaluation, certification and restriction of substances SVHC (Substances of very high concern, e.g., carcinogen, mutagen and/or persistent, bio accumulative and toxic). Within the scope of this juridical liability, TQ-Systems GmbH meets the information duty within the supply chain with regard to the SVHC substances, insofar as suppliers inform TQ-Systems GmbH accordingly.

## 8.12 EuP

The Eco Design Directive, also Energy using Products (EuP), is applicable to products for the end user with an annual quantity >200,000. The TQMx110EB must therefore always be seen in conjunction with the complete device. The available standby and sleep modes of the components on the TQMx110EB enable compliance with EuP requirements for the TQMx110EB.

## 8.13 Statement on California Proposition 65

California Proposition 65, formerly known as the Safe Drinking Water and Toxic Enforcement Act of 1986, was enacted as a ballot initiative in November 1986. The proposition helps protect the state's drinking water sources from contamination by approximately 1,000 chemicals known to cause cancer, birth defects, or other reproductive harm ("Proposition 65 Substances") and requires businesses to inform Californians about exposure to Proposition 65 Substances.

The TQ device or product is not designed or manufactured or distributed as consumer product or for any contact with end-consumers. Consumer products are defined as products intended for a consumer's personal use, consumption, or enjoyment. Therefore, our products or devices are not subject to this regulation and no warning label is required on the assembly.

Individual components of the assembly may contain substances that may require a warning under California Proposition 65. However, it should be noted that the Intended Use of our products will not result in the release of these substances or direct human contact with these substances. Therefore you must take care through your product design that consumers cannot touch the product at all and specify that issue in your own product related documentation.

TQ reserves the right to update and modify this notice as it deems necessary or appropriate.

## 8.14 Battery

No batteries are assembled on the TQMx110EB.

## 8.15 Packaging

By environmentally friendly processes, production equipment and products, we contribute to the protection of our environment. To be able to reuse the TQMx110EB, it is produced in such a way (a modular construction) that it can be easily repaired and disassembled. The energy consumption of this subassembly is minimised by suitable measures. The TQMx110EB is delivered in reusable packaging.

## 8.16 Other Entries

By environmentally friendly processes, production equipment and products, we contribute to the protection of our environment. The energy consumption of this subassembly is minimised by suitable measures.

Printed PC-boards are delivered in reusable packaging.

Modules and devices are delivered in an outer packaging of paper, cardboard or other recyclable material.

Due to the fact that at the moment there is still no technical equivalent alternative for printed circuit boards with bromine-containing flame protection (FR-4 material), such printed circuit boards are still used.

No use of PCB containing capacitors and transformers (polychlorinated biphenyls).

These points are an essential part of the following laws:



- The law to encourage the circular flow economy and assurance of the environmentally acceptable removal of waste as at 27.9.94  
(source of information: BGBl I 1994, 2705)
- Regulation with respect to the utilization and proof of removal as at 1.9.96  
(source of information: BGBl I 1996, 1382, (1997, 2860))
- Regulation with respect to the avoidance and utilization of packaging waste as at 21.8.98  
(source of information: BGBl I 1998, 2379)
- Regulation with respect to the European Waste Directory as at 1.12.01  
(source of information: BGBl I 2001, 3379)

This information is to be seen as notes. Tests or certifications were not carried out in this respect.

## 9. APPENDIX

### 9.1 Acronyms and Definitions

The following acronyms and abbreviations are used in this document.

Table 21: Acronyms

| Acronym          | Meaning                                               |
|------------------|-------------------------------------------------------|
| AHCI             | Advanced Host Controller Interface                    |
| AMI              | American Megatrends, Inc.                             |
| ATA              | Advanced Technology Attachment                        |
| AVC              | Advanced Video Coding                                 |
| BIOS             | Basic Input/Output System                             |
| CAN              | Controller Area Network                               |
| CMOS             | Complementary Metal Oxide Semiconductor               |
| CODEC            | Code/Decode                                           |
| COM              | Computer-On-Module                                    |
| CPU              | Central Processing Unit                               |
| CSM              | Compatibility Support Module                          |
| cTDP             | Configurable Thermal Design Power                     |
| DC               | Direct Current                                        |
| DDC              | Display Data Channel                                  |
| DDI              | Digital Display Interface                             |
| DDR              | Double Data Rate                                      |
| DMA              | Direct Memory Access                                  |
| DP               | DisplayPort                                           |
| DVI              | Digital Visual Interface                              |
| DXVA             | DirectX Video Acceleration                            |
| EAPI             | Embedded Application Programming Interface            |
| ECC              | Error-Correcting Code                                 |
| EDID             | Extended Display Identification Data                  |
| eDP              | embedded DisplayPort                                  |
| eDRAM            | Embedded DRAM                                         |
| EEPROM           | Electrically Erasable Programmable Read-Only Memory   |
| EFI              | Extensible Firmware Interface                         |
| EMC              | Electromagnetic Compatibility                         |
| ESD              | Electrostatic Discharge                               |
| FAE              | Field Application Engineer                            |
| FIFO             | First In First Out                                    |
| flexiCFG         | Flexible Configuration                                |
| FPGA             | Field Programmable Gate-Array                         |
| FR-4             | Flame Retardant 4                                     |
| GPIO             | General Purpose Input/Output                          |
| HD               | High Definition                                       |
| HDA              | High Definition Audio                                 |
| HDMI             | High Definition Multimedia Interface                  |
| HEVC             | High Efficiency Video Coding                          |
| HSP              | Heat Spreader                                         |
| HT               | Hyper-Threading                                       |
| I                | Input                                                 |
| I PD             | Input with internal Pull-Down resistor                |
| I PU             | Input with internal Pull-Up resistor                  |
| I/O              | Input/Output                                          |
| I <sup>2</sup> C | Inter-Integrated Circuit                              |
| IDE              | Integrated Drive Electronics                          |
| IEC              | International Electrotechnical Commission             |
| IoT              | Internet of Things                                    |
| IP00             | Ingress Protection 00                                 |
| IRQ              | Interrupt Request                                     |
| JEIDA            | Japanese Electronics Industry Development Association |
| JPEG             | Joint Photographic Experts Group                      |
| JTAG®            | Joint Test Action Group                               |
| LED              | Light Emitting Diode                                  |
| LPC              | Low Pin Count                                         |
| LVDS             | Low Voltage Differential Signal                       |



## 9.1 Acronyms and Definitions (continued)

Table 21: Acronyms (continued)

| Acronym | Meaning                                                  |
|---------|----------------------------------------------------------|
| ME      | Management Engine                                        |
| MMC     | Multimedia Card                                          |
| MPEG    | Moving Picture Experts Group                             |
| MST     | Multi-Stream Transport                                   |
| MT/s    | Mega Transfers per second                                |
| MTBF    | Mean operating Time Between Failures                     |
| N/A     | Not Available                                            |
| NC      | Not Connected                                            |
| O       | Output                                                   |
| OD      | Open Drain                                               |
| OpROM   | Option ROM                                               |
| OS      | Operating System                                         |
| PC      | Personal Computer                                        |
| PCB     | Printed Circuit Board                                    |
| PCH     | Platform Controller Hub                                  |
| PCI     | Peripheral Component Interconnect                        |
| PCIe    | Peripheral Component Interconnect express                |
| PCMCIA  | People Can't Memorize Computer Industry Acronyms         |
| PD      | Pull-Down                                                |
| PEG     | PCI-Express for Graphics                                 |
| PICMG®  | PCI Industrial Computer Manufacturers Group              |
| POST    | Power-On Self-Test                                       |
| PU      | Pull-Up                                                  |
| PWM     | Pulse-Width Modulation                                   |
| RAID    | Redundant Array of Independent/Inexpensive Disks/Drives  |
| RAM     | Random Access Memory                                     |
| RMA     | Return Merchandise Authorization                         |
| RoHS    | Restriction of (the use of certain) Hazardous Substances |
| RSVD    | Reserved                                                 |
| RTC     | Real-Time Clock                                          |
| SATA    | Serial ATA                                               |
| SCU     | System Control Unit                                      |
| SD      | Secure Digital                                           |
| SD/MMC  | Secure Digital Multimedia Card                           |
| SDIO    | Secure Digital Input/Output                              |
| SDRAM   | Synchronous Dynamic Random Access Memory                 |
| SIMD    | Single Instruction, Multiple Data                        |
| SMART   | Self-Monitoring, Analysis and Reporting Technology       |
| SMBus   | System Management Bus                                    |
| SO-DIMM | Small Outline Dual In-Line Memory Module                 |
| SPD     | Serial Presence Detect                                   |
| SPI     | Serial Peripheral Interface                              |
| SPKR    | Speaker                                                  |
| SSD     | Solid-State Drive                                        |
| STEP    | Standard for Exchange of Products                        |
| TDM     | Time-Division Multiplexing                               |
| TDP     | Thermal Design Power                                     |
| TPM     | Trusted Platform Module                                  |
| UART    | Universal Asynchronous Receiver/Transmitter              |
| uEFI    | Unified Extensible Firmware Interface                    |
| USB     | Universal Serial Bus                                     |
| VC-1    | Video Coding (format) 1                                  |
| VESA    | Video Electronics Standards Association                  |
| VGA     | Video Graphics Array                                     |
| VP8     | Video Progressive (compression format) 8                 |
| WDT     | Watchdog Timer                                           |
| WEEE®   | Waste Electrical and Electronic Equipment                |
| WES     | Windows® Embedded Standard                               |
| XPDM    | Windows XP Display Driver Model                          |



## 9.2 References

Table 22: Further Applicable Documents and Links

| No. | Name                                                           | Rev., Date               | Company               |
|-----|----------------------------------------------------------------|--------------------------|-----------------------|
| (1) | 11th Generation Intel® Core™ and XEON® H series Product Brief  | –                        | <a href="#">Intel</a> |
| (2) | PICMG® COM Express™ Module Base Specification                  | Rev. 3.0, March 31, 2017 | <a href="#">PICMG</a> |
| (3) | PICMG® COM Express™ Carrier Design Guide                       | Rev. 2.0, Dec. 6, 2013   | <a href="#">PICMG</a> |
| (4) | PICMG® COM Express™ Embedded Application Programming Interface | Rev. 1.0, Aug. 8, 2010   | <a href="#">PICMG</a> |

